

# EVERYDAY HEADPHONES PRO

---

QUICK START GUIDE  
GUIDE DE DÉMARRAGE RAPIDE  
GUÍA DE INICIO RÁPIDO



**CONNECT**  
**RELIER**  
**CONECTAR**



[38]

 **Pairing mode**  
Mode d'appariement  
Modo de emparejamiento

**FUNCTIONS**  
**LES FONCTIONS**  
**FUNCIONES**





● TAP  
TAPOTER  
TOCAR

■ HOLD  
TENIR  
MANTENER

<b>1</b>	<b>2</b>	<b>3</b>
● [3s]	●	●
● [3s]	▶▶ [2s]	◀◀ [2s]
▶  ●		
●		
●		
●		
●		
●		

**SOUND PROFILE & ACTIVE NOISE CANCELLATION**  
**PROFIL SONORE ET SUPPRESSION ACTIVE DU BRUIT**  
**PERFIL DE SONIDO Y ANULACION ACTIVA DEL RUIDO**



4 [1.5s]

**BALANCED SOUND**  
 SON ÉQUILIBRÉ  
 SONIDO BALANCEADO

**BASS SOUND**  
 SON DE BASSE  
 SONIDO BAJO

**PURE SOUND**  
 SON PUR  
 SONIDO PURO

**ANC ON**  
 ANC ACTIVÉ  
 ANC ENCENDIDO

**ANC OFF**  
 ANC DÉACTIVÉ  
 ANC DESACTIVADO

**AWARENESS MODE**  
 MODE DE SENSIBILISATION  
 MODO DE CONCIENCIA

**MULTIPOINT CONNECTION**  
 CONNEXION MULTIPOINT  
 CONEXIÓN MULTIPUNTO





**FULL USER MANUAL**  
**MANUEL UTILISATEUR COMPLET**  
**MANUEL UTILIZADOR COMPLETO**



<https://rayconglobal.com/pages/the-everyday-headphones-pro-full-user-manual>