

## Setup Photo

Test positions for body:

According to the antenna position, the Body SAR is tested at the following 3 test positions all with the distance =0mm between the EUT and the phantom bottom:

|   |  |
|---|--|
| Front in body position  | Right Side in body position  |
|    |  |
| EUT Setup Configuration 1   | EUT Setup Configuration 2  |
| Top Side in body position   |  |
|  |  |
| EUT Setup Configuration 3   |  |