


8+  
AGES

# INSTRUCTION FOR USE



For proper operation of the car, please read this manual carefully and keep it for future reference.

## Note:


Electronically controlled product  
The product is not suitable for children 3 years or younger.  
Be cautious and prevent electric shock for all electronic products while they are in use.  
● Please use the product under the supervision of an adult  
Warning: please use this product correctly in compliance with the instructions.

## Maintenance and Repair

1. Wipe the vehicle gently with a damp cloth.
2. Do not place the toy in high temperature, humidity and direct sunlight.
3. Do not place the toy in water, which may do harm to its electronic components.
4. Once the product is sold, we will not assume any safety liability incurred by operation, use and control and other aspects.
5. When there is something wrong with the use, operation, maintenance of the product, etc., we will entrust dealers to offer technical support and render after-sales services, and contact local dealers as well.

## Introduction to remote controller and car

### Fine-tune Steering



## Trimmer and calibration

If the car tends to move the left, move the trimmer button to the right until the vehicle restore to straight driving.





If the car tends to move the right, move the trimmer button to the left until the vehicle restore to straight driving.



## Battery installation method

1. Open the battery cover, put four "AA" batteries into the remote controller as shown in Figure 1 and close the cover.
2. Open the battery cover and insert the battery pack interface into the power interface of the car.
3. Assemble the battery pack into the battery box of the car and close the cover.




## For frequency



3. When the remote control indicator and lights are always on, it means that the frequency Success.

## Operation methods



1. Forward: push up the left lever, the remote control car forward Travel.

2. Backward: Pull down the left lever to move the remote control car to backward.



3. Left turn forward: push up the left lever and at the same time toggle the right lever to the left, the RC car turns left forward.

4. Right turn forward: push up the left lever and at the same time toggle the right lever to the right, the RC car turns right forward.



5. Left turn to reverse: pull down the left operation lever, while Toggle the lever to the left, the remote control car turn left to reverse.



6. Turn right to reverse: pull down the left operation lever, while Toggle the lever to the right, the remote control car turns right and reverses.

## Spray instructions




1. Open the spray on the roof of the car to fill plug of the water outlet, and into the water. Add the right amount of water into the water tank. Then put the plug back on.
2. Short press the spray on/off button to Turn on the spray function.
3. Spray appears at the rear of the car.
4. Short press the spray on/off button again to turn off the spray function.

## Instructions for charging

### 6V version

Take out the battery from the car, link the one end of the USB cable to the 5V adapter interface, and link another end to the battery. The USB light will turn on as charging, the USB light will put it in full charge. The charging time is 150-180 min.



Notes: Please use the 5V adapter for charging, for fear of damaging the battery.

## Cautions during driving

- When the car is moving, please do not touch the four wheels of the car, for fear of wringing and cutting.
- When the batteries of the remote controller or the remote control car are low, the remote control distance will be influenced, and the car will drive slowly or has difficulty in climbing.
- Please do not let the remote control car fall from a high place or severely collide, for it will damage the car or shorten the life of the car.
- Please do not play in roadsides, puddles, mud or other dangerous places to avoid danger.

## Precautions before Battery Use

- There are certain risks in the use of batteries, which may cause enormous personal and property losses. Users shall assume all relevant liabilities on their own. Manufacturers and dealers will not control the use of batteries (charging, discharging and storage, etc.) or take responsibility for the losses incurred to people and property.
- If any battery leaks, please avoid liquid contact with skin and eyes. In the event that the liquid contacts with skin, please wash your skin immediately with soap and water. In case of liquid contact with eyes, please rinse your eyes immediately with large amounts of cold water and seek medical advice at once.
- If there is a suspicious odor, noise or smoke from the charger, remove the power supply at once.
- Please strictly comply with the following requirements, otherwise it will result in fire, electric shock or explosion.

## Chargers and charging

- Do not overcharge the batteries. When the batteries are fully charged, please unplug the charger. After charging is over, please do not recharge the batteries so as to avoid overheating.
- Do not charge the batteries near flammable materials or on the surface of flammable (carpet, wooden floor, solid wood furniture, etc.) or conductive objects, and observe the batteries at any time.
- Do not charge the batteries immediately while they are still hot after use.
- The temperature of the batteries should be between 0°C and 40°C.
- Please unplug the charger when the batteries are not being charged.

## Use and Storage

- It is strictly forbidden to pack damaged batteries with plastics.
- Do not insert or remove the batteries when the product is in use.
- Do not expose the batteries to excessive physical impact.
- It is strictly forbidden to use expanded, leashed or broken batteries or those emitting peculiar smell.
- Children are forbidden from touching the batteries.
- Do not put the batteries in the fire to avoid contact between the batteries and liquid. It is strictly forbidden to get the product wet in the rain or place it in a damp place.
- Do not put the batteries in a microwave oven or a pressure tank.
- Do not disassemble, drill, deform or cut the batteries. It is strictly forbidden to carry heavy objects on batteries or chargers or knock the batteries.
- Do not clean the charger with solvents, industrial alcohol or other flammable solvents.
- Be cautious about short circuit. Avoid direct contact with electrolytic substances in batteries. Electrolytic substances and electrolytic steams are harmful to the body.
- Store the product in a greenhouse. Do not expose the product to extreme temperatures. Avoid substantial changes in the temperature of the place where the product is stored.
- Do not place the product near the accessories of heating source.
- The batteries should be taken out when the product is not in use.

## Recovery

- Do not treat the product as daily garbage. Damaged or unusable batteries should be placed in special containers for designated purposes.
- The product is made up of electronic components and batteries. Please treat the garbage of electrical and electronic equipment in line with special requirements.
- Please get familiar with the centralized treatment method for garbage in local places. Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or re-chargable batteries.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 0cm the radiator your body: Use only the supplied antenna.