

165.1

82.55

82.55

76.2

76.2

FRONT

BACK

LEGALESE :100G OFFSET PAPER

IMPORTANT SAFETY INSTRUCTIONS

WARNING: When using electrical products, basic precautions should always be followed, including the following. Read all the instructions before using this product. To reduce the risk of injury, close supervision is necessary when a product is used near children. KEEP OUT OF REACH OF CHILDREN AND PETS. DO NOT put fingers, hands, metal or other objects into the unit. Do not touch the unit when it is plugged into the wall outlet. Do NOT refill fragrance bottle. Avoid hard knocks. If the diffuser unit falls or is damaged, remove from socket. This product is not a toy. Intended for adult use only. There are no small parts. Do not use if damaged. Do not use if the unit is damaged or if the unit is SWALLOWED. DO NOT INDUCE VOMITING. Seek medical advice immediately or contact poison control. EYE & SKIN IRRITANT: Contact with liquid fragrance may cause eye or skin irritation. If contact occurs, remove the unit from the wall outlet immediately and flush with water. If contact occurs with eyes, flush with water for 15 minutes. If contact occurs with skin, wash with soap and water. DO NOT use extension cords. Use only in properly functioning 120 volt electrical outlet. DO NOT use extension cords. DO NOT disassemble the dispenser unit or modify the plug in any way. Use ONLY Pure Aroma diffusers. Do not use with other diffusers. Do not use with other diffusers. Use with care around birds and other sensitive household pets. Use only as directed.

INSTALLATION INSTRUCTIONS

Plug diffuser unit into properly functioning 120-volt wall outlet. (NO extension cords) in a well-ventilated area with 12-inch clearance above the unit.

- Remove cover from diffuser unit.
- Insert the cap on fragrance refill and screw side.
- Unscrew the cap on fragrance refill and set aside.
- Insert the vial completely into diffuser until you hear a click.
- Replace cover on diffuser unit.
- Discard empty refill.

USER MAINTENANCE

Plug diffuser unit into properly functioning 120-volt wall outlet. (NO extension cords) in a well-ventilated area with 12-inch clearance above the unit.

- Remove cover from diffuser unit.
- Insert the cap on fragrance refill and screw side.
- Unscrew the cap on fragrance refill and set aside.
- Insert the vial completely into diffuser until you hear a click.
- Replace cover on diffuser unit.
- Discard empty refill.

May cause damage to polished, painted, plastic or wood surfaces.

MOVING AND STORAGE:
Unplug diffuser from outlet. Remove vial from diffuser and screw caps onto fragrance bottles. Store vial upright with the diffuser in a dry location. Placing the vial or the diffuser with the vial inserted on its side or upside down will cause leakage.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are supervised by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. The appliance is only to be used with the recommended vaporizing medium. The use of other substances may give rise to a toxic or fire risk.

THIS DOCUMENT CONTAINS INFORMATION THAT IS SUBJECT TO CHANGE WITHOUT NOTICE.

IC ID: 30268-RURAMN1V1

Federal Communication Commission Interference Statement: This equipment has been tested and found to comply with the requirements for Class B digital devices, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio reception. It is the responsibility of the user to ensure that this equipment does not cause harmful interference to radio or television reception. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Plug the equipment into a different outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
 - This device must accept any interference received, including interference that may cause undesired operation of the device.
- Exposure Limits: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be used in conjunction with any other transmitting devices. This End equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Canada

This device complies with ISED Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. The device must not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Exposure Limits: This equipment complies with ICES RSS-102 Canadian radio communication equipment limits. L'exposition aux ondes radio est conforme aux limites d'exposition de l'ICES RSS-102.

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est temporaire et non contrôlé.

This equipment complies with FCC and ICES RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 centimeters between the radiator and your body. This End equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.