





包装设计方案


项目: **DEXNOR** 三星妙控键盘说明书 | 材质: 铜版纸 | 克数: **128g | 工艺: 骑马钉** 时间: 2023.5.17




















GD制图确认

Terry

自核

Linda

确认

ancehuang

包装设计方案

材质:铜版纸 项目: DEXNOR 三星妙控键盘指示卡

TO DEXNOR

1. TABLET INSTALLATION

Hold your Tablet with both hands and attach it to the

Store your Tablet into the keyboard case and fold it

back cover magnetically.

for on the go.

克数:300g

-270 mm

QUICK-START GUIDE

2. KEYBOARD CONNECTION

Toggle the switch to ON.


Press and hold "Fn" and "Backspace" key

simultaneously for 3 seconds to enter pairing mode.

Dexnor Keyboard

Click "Pair" to connect.

Galaxy Watch Active2(3395) LE Go to the Tablet's Settings > Connections > Bluetooth (Turn It On). Click "Scan" and find "Dexnor Keyboard" under "Available devices".



制图:Terry

时间: 2023.5.17