


PRODUCT MANUAL

产品手册

V1.1



NO.128-6618
NO.128A-36



1. According to the instructions provided in the manual. Some of the parts need to be assembled and adjusted by adults.
2. Please use it under the guidance of an adult.
3. Please promptly put away the packing materials so as not to cause harm to children.
4. Do not operate on a location where water is trapped or under the rain. Parts of the product may malfunction if exposed to water.
5. Do not touch the rotating wheel to avoid injury.
6. The product contains small parts that may pose a risk of ingestion or suffocation.
7. To remotely control the product on the road or in a crowd to avoid accidents.
8. Disconnect the rechargeable USB cable before cleaning, the toy.
9. If you observe electrical charges during product usage turn off the device immediately.
10. When installing or replacing the battery, pay attention to the correct polarity of the battery.
11. The product uses 1.5V AA batteries.
12. It is strictly prohibited to do the following actions such as but not limited to disassemble, modify, crash, puncture, drop, throw in a fire or any other means of causing damage to the product to avoid harm to the user and other participants.
13. Do not expose the battery to prolonged exposure to sunlight to prevent danger.
14. It is advisable to store the battery at a temperature below 30°C. Do not store it in a place with heat, high temperature, or humidity to avoid danger.
15. Non-rechargeable batteries cannot be charged.
16. Do not mix old and new or different types of batteries.
17. Do not disassemble the battery or modify the battery to avoid the risk of fire or explosion.
18. After the battery is used, it should be taken out of the product.
19. Stop using the battery as soon as it gives a foul smell or suddenly becomes hot, deformed, discolored, or other abnormal situation during use or charging.

20. Drained batteries should be removed immediately.
21. Do not cause the electrical supply of the wiring port to short circuit.
22. If you do not use the product for a long time, remove the batteries of the remote control car and remote control.
23. Instructions contain important product information, please take time to read for a better product experience.

一般信息
GENERAL INFORMATION



FCC注意:
本设备符合FCC规则第15部分。
操作受以下两个条件限制：
(1)本设备不能造成有害干扰,且本设备必须接受任何接收到的干扰,包括可能导致不希望的操作干扰。

FCC Notice:
This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

注:根据FCC规则第15部分,本设备已经过测试,符合B类数字设备的限制。这些限制旨在为住宅设施提供合理的保护,防止有害干扰。

该设备产生使用并能辐射射频能量,如果不按照说明书安装和使用,可能会对无线电通信造成有害干扰。但是,不能保证在特定的安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰,可以通过关闭和打开设备来确定,鼓励用户尝试通过以下一种或多种方法来纠正干扰。

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment



4. Never use anything other than the approved charger battery. Always use a balancing charger for battery. It is recommended that you do not use any other charger than the one provided with the product.
5. The battery temperature must never exceed 60°C (140°F) otherwise the battery could be damaged or ignite.
6. Never charge on a flammable surface, near flammable products or inside a vehicle (preferably place the battery in a non-flammable and non-conductive container).
7. Never expose the battery to moisture or direct sunlight, or store it in a place where temperatures could exceed 60°C (car in the sun, for example).
8. Always keep it out of reach from children.
9. Improper battery use may result in a fire, explosion or other hazard.
10. Non-rechargeable batteries are not rechargeable. Rechargeable batteries are only to be charged with the supervision of an adult.
11. Different types of batteries or new or used batteries which are different are not be mixed.
12. Batteries are to be inserted with the correct polarity.
13. The supply terminal should be used well to avoid a short circuit. Examination of the transformer and battery charger regularly is encouraged to check any damage in the cord, plug, enclosure and other parts. If damage is observed, it must not be used until it has been repaired.
14. The packaging has to be kept since it contains important information.
15. The toy is only to be connected to Class II equipment bearing the symbol.

制造商的信息
汕头市澄海区南鸿玩具厂
广东省汕头市澄海区广益街道龙田黄青芒1号

MANUFACTURER INFORMATION
Manufactured by
Shantou Chenghai Nanhong Toys Factory No. 1,
Huangqingshang, Longtian, Guangyang Street,
Chenghai District, Shantou City, Guangdong Province

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.