

REGRSI® NY-HG333 User Manual

Production description:

The wireless earphone is a high quality stereo wireless headphone which possesses wireless music、calling、radio and MP3 function. Appearance vogue, beautifully designed, easy to carry, suitable for household, outdoor travel and other places, enjoy music anytime and anywhere. Provide super perfect sound quality for your computer, digital music players, and mobile phones and so on audio-visual products.

Function features:

【Wireless Play】Support pairing wireless devices to play music such as mobile phone, tablet, TV.

【Hands-free calls】Support for hands-free calls function, built-in high sensitive microphones, making phone calls have carefree to enjoy.

【Function of Multi Pairing】Support to connect two mobile phones, more convenient to use.

【Voice Prompt Coming Calls】It will prompt the phone number when you have a coming call, it is more convenient.

【IOS Battery Display】IOS mobile phone real-time display the earphone battery, let you know the earphone battery.

【Smart Power-off】If not connected wireless mode, it will turn off automatically after 5 minutes, don't worry about waste of electricity for standby.

【MP3 Play】Play the TF card MP3 files directly.

【Radio】Digital stereo radio, automatic search and memory radio, save time and effort.

【Audio Input】Stereo audio input ports ,easy to connect the computer, digital music player, mobile phone and other audio-visual products so on all kinds of audio source.

【Rechargeable Lithium Electricity】The built-in rechargeable lithium battery, environmental protection, economical and practical.

【Intelligent Charging】The voice prompt please charge when the battery is low, when full charge it will automatically cut off power to avoid battery charging too much to damage to the battery.

Function definition of product buttons and slot :

① Ⓞ

② +

③ -


④Type-c USB Charging Ports

⑤Audio Input Ports

⑥TF CARD Slot

⑦Status Indicator Lamp

⑧Built-in Mic



① Ⓞ： Long press on, the blue red light flashes, then enter the wireless pairing state. Again long press to power off, indicator light will be off. In listening to TF card music or mobile phone music via wireless, short press this button the music was suspended short press again music from the new play. In listening to the radio, short press for all automatic channel search platform, and store the search to radio down (for the first time to use this headphones listening to the radio, please make a full channel searching operation), it will take about 1 minute to complete the whole channel searching time. After the success connection of the wireless and phone, when short press for answering the phone call, long press can refuse to answer the phone. After the call short press for hang up, continue press two times will redial the last time phone number.

②+： In listening to TF card music or mobile phone music via wireless, long press for play the next song. Listening to the radio, long press to select radio stations that broadcast the next stored. Short press for turn up the volume in any mode.

③-： In listening to TF card music or mobile phone music via wireless, long press for selection play the previous song; Listening to the radio, long press to select radio stations that broadcast the previous stored. Short press for turn down the volume in any mode.

★Notice:Long press the “+” key and “-” key at the same time can switch to radio, wireless, TF card mode (only insert TF card can switch to the TF card mode) in turn.

④【Type-c USB Charging Ports】： Power input jack, can use the special charging cable from the standard package or the universal Type-c USB port charging cable of the mobile phone for charging.

⑤【Audio Input】： Use the audio cable contact to the digital music player, mobile phone and other audio-visual products so on all kinds of audio source.

⑥【TF CARD Slot】： Insert the TF Card to play the music.

Wireless pairing operation method:

In the wireless mode, the blue light and red light alternately flashes, it is the state of the wireless pairing. At this time search the corresponding wireless device name on the phone, click the device name on the mobile phone for the wireless pairing, hear “DING DONG” means the pairing is successful, the Status indicator lamp lights blue color.

Operation method of multi pairing:

Search the earphone pairing name on the mobile phone A and mobile phone B at the same time, click the pairing name on the mobile phones separately, and when hear “DING DONG” means the pairing is successful. If you want to listen to music on the mobile phone B when you are listen to music on mobile phone A, you should pause the music on the mobile phone A by hand and click the music on the mobile phone B to listen to music and control the mobile phone B.

The radio function using method:

1. Automatic searching

In radio mode, short press “ Ⓞ ” key to start searching automatically. Indicator lights flashing when searching, automatic memory and save the stored after the completion searching.

2. Memory channel selection

After automatically searching, long press the “-” or “+” key can select the radio has been saved.

Method of turn to ordinary headphone:

Insert the 3.5mm audio line jack into the audio input ports, the wireless headphone will automatically power off, can use the wireless headphone as ordinary headphone now, at the same time the function of the wireless headphone are useless(power off status) to save the electricity.

Method of charging:

Insert the end of the charging cable to native Type-c USB socket, the other end of the USB plug into the mobile phone charger, the indicator light turns red when charging, the red light will extinguish when full of.

Low battery:

When there was a low voltage power, the machine will prompt “Low battery, please charge”, please recharge in time at this time. If it is not to be used for a long time, charging one time every month at least, it can protect the battery and extend battery life.

Auto power off:

If not connected wireless mode, it will turn off automatically after 5 minutes, don't worry about waste of electricity for standby.

Reset:

When the headphone suddenly crashed, please long press the power button for 8s, the headphone will boots again and back to normal state.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to

the following two conditions: (1) this device may not cause harmful

interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits

for a Class B digital device, pursuant to Part 15 of the FCC Rules. These

limits are designed to provide reasonable protection against harmful

interference in a residential installation. This equipment generates, uses and

can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio

communications. However. there is no guarantee that interference will not

occur in a particular installation.

If this equipment does cause harmful interference to radio or television

reception which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the

following measures:

--Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in

conjunction with any other antenna or transmitter

The device has been evaluated to meet general RF exposure requirement.

The device

can be used in portable exposure condition without restriction.

REGRSI® NY-HG333使用说明书

产品概述:

本耳机是具有无线音乐、通话、收音机、MP3功能的高品质立体声蓝牙耳机。外观时尚,设计精美,携带方便,适用于家居,户外旅游等场所,随时随地地享受音乐带来的轻松。为您的电脑,数码音乐播放器,手机等视听产品提供超值完美的音质。

功能特点:

【蓝牙播放】支持手机、平板电脑、电视等蓝牙设备配对播放音乐。

【免提通话】支持免提通话功能,内置高灵敏度麦克风,让手机通话拥有无比畅快的通话享受。

【一拖二】支持连接两部手机,使用更方便。

【来电报导】来电智能真人语音报号码。

【IOS电量显示】IOS系统手机实时显示耳机电量,让您对耳机电池电量了如指掌。

【智能关机】本机在蓝牙模式下未连接蓝牙的状态五分钟后会自动关机,无需担心因待机而浪费电量。

【MP3播放】直接播放TF卡MP3文件。

【收音机】数字立体声收音机,自动搜索及存储记忆电台,省时省力。

【音频输入】立体声音频输入接口,轻松连接电脑,数码音乐播放器,手机等视听产品各类音源。

【可充锂电】内置可充电锂电池,环保,节约,实用。

【智能充电】当电池电量最低时,有真人语音提示充电;当电池充满电时,自动切断电源,以免电池过量充电损害电池寿命。

产品的按键、插孔功能定义:

① Ⓞ

② +

③ -


④Type-c USB充电插口

⑤音频输入插口

⑥TF CARD插口

⑦状态指示灯

⑧内置麦克风



① Ⓞ： 长按开机, 红蓝光交替闪烁, 此时进入蓝牙配对状态, 再长按关机, 指示灯熄灭。在听TF卡音乐或者通过蓝牙听手机音乐时, 短按音乐被暂停, 再短按一次音乐重新播放; 在听收音时, 短按为自动全频道搜台, 并把搜索到的电台存储下来 (首次用本耳机听收音时, 请进行一次全频道搜台操作), 完成全频道搜台时间大约1分钟左右。

当有来电时短按为接听电话或者持续长按为拒接电话; 通话完毕后短按为挂电话; 连续短按两次为拨打手机通话记录最后一次拨打的号码。

②+： 听TF卡音乐或通过蓝牙听手机音乐时, 长按为选择播放下一首歌曲; 听收音时, 长按为选择播放下一个已存储的电台; 在任何模式下短按为调大音量。

③-： 听TF卡音乐或通过蓝牙听手机音乐时, 长按为选择播放上一首歌曲; 听收音时, 长按为选择播放上一个已存储的电台; 在任何模式下短按为调小音量。

★注意: 同时长按 “+” 和 “-” 键2秒, 可依次循环切换收音, 蓝牙, TF卡模式 (只有插入了TF卡才可以切换到TF卡模式)

④【Type-c USB充电插口】： 电源输入插孔, 可使用本机配送的专用USB电源线或者带Type-c USB头的充电线连接手机充电器进行充电。

⑤【音频输入插口】： 用本机配送的音频线连接电脑, 数码音乐播放器, 手机等视听产品各类音源输入。

⑥【TF CARD插口】： 插入TF卡播放MP3音乐。

蓝牙配对操作方法:

在蓝牙模式下, 蓝红光交替闪烁, 此时进入蓝牙配对状态, 在手机上搜索到相应的蓝牙设备名称, 点击手机上蓝牙设备名称进行蓝牙配对, 听到“叮咚”为配对成功, 指示灯亮蓝灯。

一拖二使用操作方法:

用A、B两部手机同时搜索到耳机的配对名, 分别点击手机上的配对名, 听到“叮咚”为配对成功。当前听A手机的歌曲, 要转听B手机的歌曲, 需要手动把当前A手机的歌曲暂停后, 再按B手机上的歌曲, 耳机就可以听B手机歌曲, 且控制B手机。

收音机功能使用方法:

1.自动搜台: 在收音模式, 短按“ Ⓞ ”键开始自动搜台。搜台时指示灯闪烁, 搜台完毕后自动记忆保存电台。

2.记忆选台: 自动搜台完毕后, 长按“-”或“+”键可选择上下已被保存的电台。

转普通耳机使用操作方法:

将3.5头音频线插头插入音频输入接口, 这时蓝牙耳机自动断电, 便可以将蓝牙耳机当做普通耳机使用, 此时蓝牙耳机的其他功能无用 (断电状态) 以便节省电量。

充电使用方法:

将电源线一端插入本机的Type-c USB插孔, 另一端USB插头插入手机充电器接口, 充电中“红色灯”常亮, 充满电量后“红色灯”熄灭。

电池电量低:

当电量出现低电压时, 本机有语音“电量低, 请充电”提示, 此时请及时充电; 如果长时间不使用本机, 至少每月充电一次, 可保护电池延长电池寿命。

自动关机功能:

本机在蓝牙模式下未连接蓝牙无任何操作的情况下五分钟后会自动关机。

复位:

当本耳机意外死机时, 请长按开机键8s, 耳机会重新开机恢复正常状态。

警告:

该设备符合FCC规则第15部分。操作需满足以下两个条件:

(1) 本设备不得产生有害干扰, 并且 (2) 本设备必须接受接收到的

的任何干扰, 包括可能导致不希望的操作的干扰。

未经合规责任方明确批准的更改或修改可能导致用户操作设备的权限失效。

附注: 本设备已经过测试, 符合B类数字设备的限制, 根据FCC规则

第15部分。这些限制旨在为住宅安装中的有害干扰提供合理的保护。

本设备产生、使用并能辐射射频能量, 如果不按照说明书安装和使用,

可能会对无线电通信造成有害干扰。然而。不能保证在特定的

安装中不会发生干扰。

如果本设备确实对无线电或电视接收造成有害干扰 (可通过开关设备来确定), 则鼓励用户尝试通过以下一种或多种措施来纠正干扰:

--调整接收天线的方向或位置。

-增加设备与接收器之间的距离

--将设备连接到与接收器连接的电路不同的插座上。

--请咨询经销商或有经验的无线电/电视技术人员以获得帮助

附注: 本设备及其天线不得与任何其他天线或发射器一起放置或操作

该设备已被评估, 以满足一般的射频暴露要求。该装置

可在便携式曝光条件下不受限制地使用。