

包装图纸

正面

背面

80.00 mm	128.00 mm		<p>•耳机配对</p> <p>开机后耳机会自动进入配对模式。打开手机蓝牙搜索“Hamedal HP40”并点击连接(若有连接记录, 耳机开机自动回连有连接记录的设备。如需重新进入配对模式, 请在关机情况下长按多功能键4秒)。</p> <p>•耳机配对</p> <p>同时连接两台设备</p> <p>A设备已蓝牙连接耳机, 关闭A设备的蓝牙, 耳机进入配对模式, 红灯交替闪烁。打开B设备的蓝牙, 搜索“Hamedal HP40”并连接, 之后再打开A设备的蓝牙并连接耳机。</p>	<p>•恢复出厂设置</p> <p>耳机开机状态下同时按住音量加减键10秒直至红灯闪烁3次, 耳机进入配对模式, 恢复出厂设置完成。</p> <p>•亮灯提示</p> <p>连接状态: 白灯10秒一闪</p> <p>充电中: 红灯长亮</p> <p>充满电: 白灯长亮</p>	<p>•FAQ</p> <p>Q: 手机提示无法连接怎么解决?</p> <p>A: 将手机上的配对记录删除, 删除后重新进行搜索配对连接即可。</p> <p>Q: 听歌/通话声音怎么解决?</p> <p>A: 先尝试音量+键, 若无声音, 再进行如下操作:</p> <p>安卓手机在蓝牙连接名字的右边有个设置图标, 点击进入, 关闭手机音频设备选择, 再重新开回, 若还是无声, 请将耳机电量与手机电量充满。</p> <p>Q: 为什么电脑/游戏有延迟?</p> <p>A: 受使用环境、网络、手机编解码等因素的影响, 会引起手机传达音频数据到耳机时有不同程度的延迟。</p> <p>Q: 听歌的声音卡顿/断连怎么解决?</p> <p>A: 在使用时若周围有大功率Wi-Fi、5G/4G信号、大功率电器等等产生干扰, 可能会引起卡顿、断连的情况, 换个环境或者重新配对连接就可以解决了。</p> <p>▲警告:</p> <p>操作耳机前, 请务必阅读以下安全警告:</p> <ol style="list-style-type: none">1. 请将设备存放在干燥的环境下, 切勿在潮湿环境下使用。2. 切勿将电池或装有电池的设备的暴露在高温的环境下, 如阳光、明火之类的场所。3. 如果电池更换不当会有爆炸危险; 请使用同样类型的电池来更换。4. 充电时请勿自行拆卸、更改或损坏充电器或电源线等。5. 请勿自行拆卸或更改产品, 点按或更改配件, 如要修理请咨询官方售后。6. 请勿在易燃易爆的环境下使用。7. 请勿在充电时充电。8. 请勿在充电时拆卸、更改、电池或其他电子元件, 避免对环境造成破坏。9. 为避免听力损伤, 请勿长时间以较大音量使用设备。10. 请勿在充电、开车或操作机器时使用设备, 以免引发安全事故。

80.00 mm	128.00 mm		<p>•How to Connect</p> <p>Power on headset and it will auto turn connectable. On phone, search Nurmum HP40 and tap to connect. It will auto reconnect to the last device in connectivity record if any. If you need to make it turn connectable again, power it off and press and hold MFB for 4s.</p> <p>•Factory Setting</p> <p>Power on headset, press and hold both volume + and - for 10s or until LED blinks red 3 times to reset it factory. It will then auto turn connectable.</p>	<p>•Functions</p> <p>① Power-on/hold MFB for 2s</p> <p>② Power-off: Hold MFB for 4s</p> <p>③ Answer/end call: Press MFB</p> <p>④ Ignore call: Hold MFB for 1.5s</p> <p>⑤ Skip track backward: Hold Volume- for 1s</p> <p>⑥ Skip track forward: Hold Volume+ for 1s</p> <p>⑦ Volume up: Press Volume+</p> <p>⑧ Volume down: Press Volume-</p> <p>⑨ Voice assistant: Triple press MFB</p> <p>⑩ Playback/pause: Press MFB</p> <p>⑪ Gaming mode: Double press MFB</p> <p>⑫ Switch mode: Press ANC Button to switch among ANC ON, ANC OFF and Transparency</p> <p>⑬ ANC ON: Double press ANC Button to switch off ANC Adaptive.</p>	<p>▲Warnings:</p> <p>Please read the following safety instructions before using the product:</p> <ol style="list-style-type: none">1. Please store the product in a cool and dry place. Do not use in a humid environment.2. Do not expose batteries or battery equipped devices to extremely high temperatures, such as sunlight and open flames.3. If the battery is not replaced properly, it will explode. It should only be replaced with the same type of battery.4. Do not replace the battery every by yourself. If the battery is damaged, contact professional personnel.5. Do not disassemble the product for maintenance or replacement of accessories without authorization. For the repair service, please consult the official sales support.6. Please purchase the accessories/accessories specified by the manufacturer.7. Please clean the product with dry cloth.8. Properly dispose of packaging materials, equipment, battery, and other electronic components to avoid damage to the environment.9. Do not use the product at a high volume for a prolonged period of time to avoid hearing damage.10. Do not use the product while walking, driving or riding to avoid traffic accidents. <p>EU Conformity Statement</p> <p>This product complies with the applicable CE marking directives and standards: Electromagnetic Compatibility (EMC) Directive 2014/53/EU, Low Voltage Directive (LVD) 2014/35/EU, Restriction of Hazardous Substances (RoHS) Directive 2011/65/EU and its amending Directive (EU) 2015/863.</p> <p>2012/18/UE (WEEE directive)</p> <p>Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at a designated collection point. For more information see: www.auditoryworks.info</p> <p>Battery Directive 2013/56/EC</p> <p>Battery in the product complies with the European Battery Directive 2013/56/EC. For proper recycling, return the battery to your supplier or to a designated collection point.</p> <p>Warning</p> <p>High sound Pressure.</p> <p>To avoid hearing damage, do not listen for long periods at high volume. Do not turn the volume up high that you are unable to hear your surroundings.</p> <p>Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.</p> <p>Do not use at a dangerous place unless the surrounding sound can be heard.</p> <p>DECLARATION OF CONFORMITY</p> <p>Hereby, we declare that the product is compliance with Radio Equipment Directive (RED) 2014/53/EU. The full text of the EU declaration of conformity is available at the internet address as shown on the packing box.</p> <p>This product can be used in any EU member states.</p> <p>Bluetooth radio power: 1.0dBm</p> <p>FCC Statement</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <ol style="list-style-type: none">(1) This device may not cause harmful interference, and(2) This device must accept any interference received, including interference that may cause undesired operation. <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio communications, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">-Reorient or relocate the receiving antenna.-Increase the separation between the equipment and receiver.-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-Consult the dealer or an experienced radio/TV technician for help. <p>-Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p>

技术要求:

料 号: Z.BS.XXXXXXX

文件名: HP40_中性说明书-V0

尺 寸: 80x128mm

材 质: 157g铜版纸, 黑白印刷, 双面折页。

特别说明:

AUDITORYWORKS
蛙声科技

宁波蛙声科技有限公司
NINGBO AUDITORYWORKS CO., LTD.

TITLE(名称) HP40_中性说明书-V0	UNITS: MM 单位: 毫米	COLOR: 颜色: 单色	DRAW: 制图: 曾茵秀
			CHKD: 审核: 姓名
MATERIAL NO(物料编码) Z.BS.XXXXXXX	MODEL: 产品型号: HP40		APPD: 审批: 姓名
SCALE: 比例: 1: 1			
REV.(版本):	V0	SHEET(页数):	1 OF 1
DESCRIPTION(描述):	打样文件	DATE(日期):	2023/07/08