









































| Condition | Mode | Frequency (MHz) | Antenna | Duty Cycle (%) | Correction Factor (dB) | 1/T (kHz) |
|-----------|------|-----------------|---------|----------------|------------------------|-----------|
| NVNT      | a    | 5180            | AntB    | 100            | 0                      | 0         |
| NVNT      | a    | 5200            | AntB    | 100            | 0                      | 0         |
| NVNT      | a    | 5240            | AntB    | 100            | 0                      | 0         |
| NVNT      | n20  | 5180            | AntB    | 100            | 0                      | 0         |
| NVNT      | n20  | 5200            | AntB    | 100            | 0                      | 0         |
| NVNT      | n20  | 5240            | AntB    | 100            | 0                      | 0         |
| NVNT      | n40  | 5190            | AntB    | 100            | 0                      | 0         |
| NVNT      | n40  | 5230            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5180            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5200            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5240            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac40 | 5190            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac40 | 5230            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac80 | 5210            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5180            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5200            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5240            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax40 | 5190            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax40 | 5230            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax80 | 5210            | AntB    | 100            | 0                      | 0         |











































| Condition | Mode | Frequency (MHz) | Antenna | Duty Cycle (%) | Correction Factor (dB) | 1/T (kHz) |
|-----------|------|-----------------|---------|----------------|------------------------|-----------|
| NVNT      | a    | 5260            | AntA    | 100            | 0                      | 0         |
| NVNT      | a    | 5280            | AntA    | 100            | 0                      | 0         |
| NVNT      | a    | 5320            | AntA    | 100            | 0                      | 0         |
| NVNT      | n20  | 5260            | AntA    | 100            | 0                      | 0         |
| NVNT      | n20  | 5280            | AntA    | 100            | 0                      | 0         |
| NVNT      | n20  | 5320            | AntA    | 100            | 0                      | 0         |
| NVNT      | n40  | 5270            | AntA    | 100            | 0                      | 0         |
| NVNT      | n40  | 5310            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5260            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5280            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5320            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac40 | 5270            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac40 | 5310            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac80 | 5290            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5260            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5280            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5320            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax40 | 5270            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax40 | 5310            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax80 | 5290            | AntA    | 100            | 0                      | 0         |











































| Condition | Mode | Frequency (MHz) | Antenna | Duty Cycle (%) | Correction Factor (dB) | 1/T (kHz) |
|-----------|------|-----------------|---------|----------------|------------------------|-----------|
| NVNT      | a    | 5260            | AntB    | 100            | 0                      | 0         |
| NVNT      | a    | 5280            | AntB    | 100            | 0                      | 0         |
| NVNT      | a    | 5320            | AntB    | 100            | 0                      | 0         |
| NVNT      | n20  | 5260            | AntB    | 100            | 0                      | 0         |
| NVNT      | n20  | 5280            | AntB    | 100            | 0                      | 0         |
| NVNT      | n20  | 5320            | AntB    | 100            | 0                      | 0         |
| NVNT      | n40  | 5270            | AntB    | 100            | 0                      | 0         |
| NVNT      | n40  | 5310            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5260            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5280            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5320            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac40 | 5270            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac40 | 5310            | AntB    | 100            | 0                      | 0         |
| NVNT      | ac80 | 5290            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5260            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5280            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5320            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax40 | 5270            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax40 | 5310            | AntB    | 100            | 0                      | 0         |
| NVNT      | ax80 | 5290            | AntB    | 100            | 0                      | 0         |



































| Condition | Mode | Frequency (MHz) | Antenna | Duty Cycle (%) | Correction Factor (dB) | 1/T (kHz) |
|-----------|------|-----------------|---------|----------------|------------------------|-----------|
| NVNT      | a    | 5500            | AntA    | 100            | 0                      | 0         |
| NVNT      | a    | 5580            | AntA    | 100            | 0                      | 0         |
| NVNT      | a    | 5700            | AntA    | 100            | 0                      | 0         |
| NVNT      | n20  | 5500            | AntA    | 100            | 0                      | 0         |
| NVNT      | n20  | 5580            | AntA    | 100            | 0                      | 0         |
| NVNT      | n20  | 5700            | AntA    | 100            | 0                      | 0         |
| NVNT      | n40  | 5510            | AntA    | 100            | 0                      | 0         |
| NVNT      | n40  | 5550            | AntA    | 100            | 0                      | 0         |
| NVNT      | n40  | 5670            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5500            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5580            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac20 | 5700            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac40 | 5510            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac40 | 5550            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac40 | 5670            | AntA    | 100            | 0                      | 0         |
| NVNT      | ac80 | 5530            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5500            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5580            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax20 | 5700            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax40 | 5510            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax40 | 5550            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax40 | 5670            | AntA    | 100            | 0                      | 0         |
| NVNT      | ax80 | 5530            | AntA    | 100            | 0                      | 0         |

