







Band71 QPSK BW=5MHz Channel=133297 RB Size=1 Position=#0




Band71 16QAM BW=5MHz Channel=133297 RB Size=1 Position=#0




Band71 QPSK BW=5MHz Channel=133447 RB Size=1 Position=#0




Band71 16QAM BW=5MHz Channel=133447 RB Size=1 Position=#0




Band71 QPSK BW=10MHz Channel=133172 RB Size=1 Position=#0




Band71 16QAM BW=10MHz Channel=133172 RB Size=1 Position=#0




Band71 16QAM BW=10MHz Channel=133297 RB Size=1 Position=#0




Band71 QPSK BW=10MHz Channel=133297 RB Size=1 Position=#0




Band71 QPSK BW=10MHz Channel=133422 RB Size=1 Position=#0




Band71 16QAM BW=10MHz Channel=133422 RB Size=1 Position=#0




Band71 QPSK BW=15MHz Channel=133197 RB Size=1 Position=#0




Band71 16QAM BW=15MHz Channel=133197 RB Size=1 Position=#0




Band71 QPSK BW=15MHz Channel=133297 RB Size=1 Position=#0




Band71 16QAM BW=15MHz Channel=133297 RB Size=1 Position=#0




Band71 QPSK BW=15MHz Channel=133397 RB Size=1 Position=#0




Band71 16QAM BW=15MHz Channel=133397 RB Size=1 Position=#0




Band71 QPSK BW=20MHz Channel=133222 RB Size=1 Position=#0




Band71 16QAM BW=20MHz Channel=133222 RB Size=1 Position=#0




Band71 16QAM BW=20MHz Channel=133297 RB Size=1 Position=#0



Band71 QPSK BW=20MHz Channel=133297 RB Size=1 Position=#0



Band71 QPSK BW=20MHz Channel=133372 RB Size=1 Position=#0



Band71 16QAM BW=20MHz Channel=133372 RB Size=1 Position=#0

