







TRANSFORMERS




TF-T15 Headphones with hanging ears
Instruction manual

Packing list

	Headphones *2		Type-C Charging cable *1
	Charging case *1		Instructions and Warranty card *1
	Lanyard *1		

Product diagram



Tips

- 1.Except for the operation methods specifically marked in the manual,please do not try to disassemble or replace any parts in the earbuds.
- 2.Don't put the earbuds in the water or any others liquid.The earbuds are not waterproof.
- 3.If any liquid enters the product by accidentally,please disconnect and remove the connection immediately.
- 4.Please make sure that there is no water on your hands when installing

or uninstalling the product to avoid electricshock.

5.Do not put the product near by the heat source or expose it to the fire source directly.

6. Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product specification

BT version: V5.4

Transmission distance: ≥10m

Speaker unit: $\phi 16.2\text{mm}16\Omega$

Frequency response range: 20Hz-20KHz

Horn sensitivity: 110dB±3dB

Music playing time: ≈5hours

Charging time (charging case) : ≈1.5hours

Rated current (charging case) : 400mA

Battery capacity (charging case) : 400mAh

Charging time (headset): ≈ 1.5hours

Rated current (headset): 50mA

Battery capacity(headset): 50mAh

Charging bin charging specifications

Reminder: When the battery level of the earphones is below 3.3V, a low battery reminder will be played.(Sound prompt "battery low"), the earphones sound a prompt sound once a minute and turn on a red light every five seconds. Please charge the earphones in a timely manner.



Product operation instructions

① Boot:

Method 1. Turn on the headphones and they will automatically turn on.

Method 2. Press and hold the left/right touch area for 3 seconds, and the blue light will turn on the headset for 1 second. (Voice prompt tone: "power on")

② Shutdown:

Method 1. Put it back in the charging case, and the headset automatically shuts down and charges.

Product operation instructions

Method 2. The device is disconnected and automatically shuts down after 3 minutes. (Voice prompt tone: "power off")

③ BT pairing:

1. Take out the earphones from the charging case, and the left and right earphones automatically connect and enter the pairing state with the phone. (Audio notification tone: "pairing")
2. Turn on BT on the mobile phone, search the device name "TF-T15", and click to enter the connection. (Voice prompt tone: "connected")



Enter the device pairing state:
The red and blue lights in the primary ear flash alternately, and the secondary ear turns off



LED indicator status

Power on	The blue light on the earphones stays on for 1 second
Power Off	The red light on the earphones lights up three times
TWS pairing status	The red and blue lights on left/right earphones flash alternately
The device pairing status is displayed	The red and blue lights in the primary ear flash alternately, and the secondary ear turns off
Connection successful	Headphone indicator light off
Low battery	It beeps once a minute and blinks red every five seconds
Earphone charging	The headset's red light keeps on
Headphones fully charged	Headphone red light goes off
Charging bay charging	RGB seven color lights cycle flashing
The charging bay is fully charged	RGB Rainbow Lights Off
factory data reset	The red light on the earphones flashes three times and goes out

Touch operation

■ General mode



- Voice Assistant: Press and hold the touch area of the left headset for 2 seconds to start
- Volume Increase: Click on the right earphone touch area
- Volume minus: Click on the left earphone touch area

■ Music playback mode



- Play/Pause: Double click on any earphone touch area
- Previous: Three hits left earphone touch area
- Next: Three hits right earphone touch area

■ Call mode



- Answer/hang up a call: Double click on any earphone touch area
- Reject incoming calls: Press and hold any earphone touch area for 2 seconds

■ Game/ Music mode switch



- Music Mode: Press and hold the right earphone touch area for 2 seconds (Voice prompt tone "music mode")
- Game mode: Press and hold the right earphone touch area for 2 seconds (Voice prompt tone "game mode")

Restore factory settings

When the earphone is connected to the BT device, tap the left/right earphone five times. After hearing the tone, click within 3S press and hold the headset 10S to clear the pairing information between the headset and the BT device, and then "power off ")

The name and content of harmful substances in the earbuds

Part Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.

O:Indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572.

X:Indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572.

The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components:

Including printed circuit boards and their parts,electronic components, etc.and depending on the product model,the earbuds you purchased may not contain all the above components.



Refers to not containing 6 toxic and harmful substances or containing but less than the limit value, with the letter "e" representing the english letter (electronic).(Electronic)
The first letter of the (environment); The curved arrows surrounding indicate recyclability.

Warranty statement

Disclaimer

This user manual does not have any form of guarantee,position expression or other implication.The mentioned products,specifications and information are for reference only,and the content will also be updated on the web at any time without additional separate notice

Warranty statement:

The product attached to this document is guaranteed as follows:If the product is twelve (12) months from the date of purchase("Warranty Period"),under normal conditions of use due to quality defects damaged,can be repaired.Free repair;free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product.Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days).Purchased by sale the ticket date shall prevail;if the purchase date cannot be determined,the warranty period shall be 13 (13) months

If you apply for a warranty,please call the product service hotline first and execute it in the manner instructed by us.When applying for warranty,you need to provide an accurate,complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:

- 1.Exceeding the validity period of the three packs;
- 2.Altering the warranty card and product code does not match the product body;
- 3.Causes caused by misuse,abuse or improper transportation,use,maintenance or storage obstacles or damage;
- 4.Failure or damage caused by force majeure (such as earthquake,war,disaster,etc.) or accident bad;
- 5.The zipper and tower buckle are damaged due to excessive force;
- 6.Disconnection or tearing caused by excessive load;
- 7.Any damage caused by sharp objects;
- 8.Products with signs of burning of flooding;
- 9.Damage caused by unauthorized disassembly;
- 10.Aging,discoloration,abrasion,rupture and other losses that occur during the normal use of the product.
- 11.If the original identification label of the product is changed or damaged,this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee.You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products,and are only applicable in mainland China.Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

Service supervision hotline: 400-885-8808



Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info

User name		Email	
Contact number		Postal code	
Mailing address			

Product information

Product name		Product number	
Product barcode / Serial number / Batch number			

Vendor information

Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

Certificate of Approval

Product No: _____

Production Time: _____

QC: _____



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.