


FRONT

90 mm

# WIZCHARK

## Wireless Charger




AB0553

### Instruction manual

60 mm

#### Product Diagram:



- 1 -

#### Packing List:

Wireless charging	x1
Charging cable	x1
Manual	x1

#### Product Parameters:

Product Name: Wireless Charger  
Input: DC 5V/3A, 9V/3A  
Wireless charging output (left): 15W max  
Wireless charging output (middle): 1.5W max  
Wireless charging output (right): 3W max  
TYPE-C cable length: 100cm  
Size: 247\*72\*9.5mm  
Weight:  
Manufacturer: Dongguan Yuet Electronic Technology Co., Ltd.  
Address: 12 Guang Yuan Street, Zhufo Ling, Tangxia, Dongguan, Dongguan

#### Usage:

- This product has 3 LED indicators. Wireless charging indicator 1 green LED; Wireless charging Bluetooth headset Indicator light 1 blue LED; Watch charging indicator light 1 red LED
  - After connecting well, power on, the LED light goes out immediately under the light; when charging with wireless charger, the LED light is always on; Blinking when there is a foreign object in the middle or the temperature is too high.
  - Phones, watches, and AirPods start charging automatically.
- ⚠ Attention: When using the wireless charging feature, if the LED indicator flashes, the device does not support wireless charging or there is foreign matter between the device and the wireless charging surface, or overheating.

- 2 -

#### Points to note:

- Before using this product, please be sure to read the product manual, and according to the instructions of the use of the correct operation.
- Do not disassemble the device by yourself. This product is not equipped with any self-disassembly/maintenance parts.
  - Wireless charger with multiple protection functions, charging abnormal, check the status of the mobile phone and watch, after re-placed mobile phone and watch.
  - For optimal charging performance, our chargers are recommended.
  - If mobile phones and watches are not placed correctly, it may lead to mobile phones and watches can not be charged properly.
  - Do not place anything between the phone or I watch and the charger.
- ⚠ Note: If magnetic holders, protective cases, metal objects or room cards are placed between the phone, I watch, headphones and charger, NFC or RFID chips such as public transportation cards, bank cards, passports, etc. between your phone, I watch, and charger, it may degrade the charger's performance, cause heat generation, or even damage the item. It may reduce the performance of the charger, cause heat generation, or even damage the item. Please stop using the charger immediately if the product has abnormal heat generation.

#### Security information:

- Please read and follow the following notes before using and operating the device.
- In medical and health-care settings where the use of wireless devices is explicitly prohibited, please comply with the site regulations and turn off the devices.
  - When using this device, keep at least 30 cm away from the implanted medical device (such as pacemaker, cochlear implant, etc.) .
  - Please keep the equipment dry. Please do not use the equipment in the dusty, damp place, in order to avoid causing equipment failure.
  - Please do not use this equipment in the thunderstorm day, lest cause the equipment failure or the electric shock danger.

- 4 -

BACK

90 mm

- Please use this equipment within the temperature range of -10 C~+45 C, and store it within the temperature range of -40 C~+70 C to avoid causing equipment malfunction, storage, so as not to cause equipment malfunction.
- Do not expose the equipment to high temperatures or heat generating equipment such as sunlight, heaters, microwaves, ovens, or water heaters or water heaters.
- Do not overcharge your cell phone and watch. The temperature may rise when this product is overused. Cell phones and watches Remove when fully charged. Do not charge the cell phone and watch for more than 7 hours at a time.
- It is prohibited to use this product beyond its maximum output parameters. Overloading the output may result in risk of fire or injury.
- Please dispose of the equipment according to local regulations and do not dispose of the equipment as household waste. Please observe the local ordinances for the disposal of this equipment and its accessories disposal local ordinances and support recycling initiatives.
- Do not allow children or pets to chew on the device as this may cause injury to them.
- This device and its accessories may contain small parts, so keep the device and its accessories out of the reach of children. Keep the device and its accessories out of the reach of children. Children may unintentionally damage the device and its accessories or swallow small parts, resulting in choking or other hazards. Children may unintentionally damage the device and its accessories or swallow small parts, resulting in choking or other hazards.
- Do not drop, crush or puncture the device as this may cause it to malfunction.
- Use of unauthorized or incompatible power supplies, chargers, or batteries can cause fire or other hazards.

- 5 -

#### FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

- 6 -

#### FCC Radiation Exposure Statement:

This equipment complied with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Made in China

- 7 -

#### Warranty card

Sincerely thank you for buying and using our products!  
This product has passed the strict quality inspection. According to the warranty card, we will be responsible for the free maintenance during the warranty period if the hardware malfunction is caused by the quality problem of the product. For more information, please consult US, thank you!

Warranty description (warranty scope is limited to the main unit only, not including accessories and freebies)

- Customers who purchase our series products will enjoy after-sales service according to the relevant regulations of the state.
  - If there is a quality issue with the product you purchase. It can be replaced within 15 days without man-made damage, disassembly and repair, and packing intact.
  - Purchase this product to enjoy one year free maintenance service.
  - The warranty shall expire and maintenance services shall be provided free of charge, provided that the corresponding accessories and manual repair fees shall be charged for the maintenance:
- The damage caused by human factors, including abnormal working conditions, not according to the use of the manual, caused by damage, etc. .
  - The user disassembles the machine, repairs and refits by himself, and is maintained by a maintenance department of the company or by an unauthorized organization.
  - Damaged by force majeure.
  - Without the product warranty card and valid purchase certificate, and unable to verify the user's information files.
  - The Bar Code and the date of manufacture of the goods were torn (outer packing) .
  - Past expiration date.

#### Form filling

User Name:	Date Of Purchase:
Contact Number:	Sales Unit:
Model:	Sales Address:
Client Address:	

\*This warranty card is properly kept by the customer as the warranty certificate of the product without any alteration.