This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- -- Reorient or relocate the receiving antenna.

2.4G

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmfu interference, and (2) this device must accept any interference received, including interference that may cause undesired operation changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate

Item NO: UJ99-P220

Product Name: REMOTE CONTROL CAR SERIES



Battery Installation Replacing batteries of the transmitter 1.5V 2x1.5V"AA" **USE 3 "AA 1.5V" BATTERIES** ON/OFF (NOT INCLUDED)

- 1. Take out the cover of R/C car, instal 3.7V rechargeable battery pack, fasten the cover, turn the switch to 'on '
- 2. Open the battery cover of transmitter, instal two 1.5V batteries, close the cover.
- 3. The charging time is about 2.5 hours support about 25 minutes playing.
- 4. Receiving distance 40m.



The Basic Operation of The Products





1. Press and hold for 3 seconds to turn on the power, and then decode to start the car.





2. Push or pull the trigger of the transmitter to make the car goes forward or backward.

3



3. The clockwise rotation of the steering wheel on the transmitter, the car will turn right.

4. The counterclockwise rotation of the steering wheel on the transmitter, the car will turn left.

CAUTIONS

When the car is in motion, do not touch the wheels by hand to avoid damages to the car.





place, set the cars to different frequency to avoid mutual interference

When there's more than one car played in the same Do not bend the antenna or point it at other





Do not play in a place with puddle, mud or sand.

Do not play on the roads or in any other dangerous places to avoid accidents

BATTERY SAFETY

- (1) The placement or replacement of batteries is to be performed by an adult.
- (2) Remove the rechargeable battery from the chassis before charging. (3) Always remove exhausted batteries from the car and the transmitter.
- (4) Make sure the main switch is set to OFF before installing the
- battery pack into the car body.
- (5) Batteries must be inserted with the correct polarity.
- (6) Non-chargeable batteries shall not be recharged.
- (7) Do not short-circuit the batteries.
- (8) Always remove the batteries from the car and the transmitter after playing. (9) Never throw the batteries into fire to avoid explosion or leakage.
- (10) Do not mix batteries from different producers or new and old
- (11) You should only use batteries of the same or equivalent types as
- (12) Check the batteries on a regular basis to avoid leakage.
- (13) Keep this manual well for future reference as it contains important information about this product.



For best stunt performance, make sure the tires are clean. If the tire is dirty, gently wipe it with a clean damp cloth. Do not soak toys in water.







MADE IN CHINA