

正面

105mm

70mm

Smart Microphone Operation Instruction



L2

*Thank you for purchasing our product. Please read the instruction carefully before use.

PREFACE

Thank you for purchasing our product. Please read the instruction carefully before using the product. Please keep this Manual properly for future reference. Please read this Manual carefully before use to enjoy optimum performance. Please follow the safety instruction on the next page. The pictures in the manual are for reference only, which may be different from the actual product.

⚠ SAFETY WARNING



The lightning shaped sign reminds users to be careful of electric leakage



The exclamation mark indicates that the product operates normally according to the manual


WARNING

- To prevent electric shock, do not expose this product to rain or moisture. Do not remove the cover, the internal voltage may cause damage to your body. In the event of malfunction, please contact the maintenance service agent
- Do not keep the product in humid or dusty place.
- Keep away from high temperature
- Do not disassemble the product
- Do not expose the product in dusty air. Environment Friendly Use Period



The environment friendly use period for this electronic information product is 10 years, during which no pollution to the environment or serious damage to health or property will be caused by the leakage of harmful substances, provided it's operated in accordance with this manual.

PRODUCT FEATURES



风琴折

BASIC BUTTON OPERATION

Pairing the microphone with speaker

1. when the microphone and the speaker are turned on at the same time, the microphone and the Bluetooth speaker are actively connected via Bluetooth.
2. When the Bluetooth speaker is turned on, open the Bluetooth settings of the mobile phone, search for the device, find the corresponding Bluetooth name, and click to connect to Bluetooth.

Microphone Button Function

1. On/Off button: short press for mic mute function; long press for on/off.
2. Mic + button: Short press for Mic Volume plus; long press for previous song
3. Mic - button: Short press for Mic Volume reduce; long press for next song.
4. Sound effect button: short press for changing-over KTV- Magic sound - Baby sound - Original sound (boot default original sound); long press to eliminate the original sound

Speaker Button Function

1. On/Off button: Long press for 3 seconds to turn on/off, short press to cancel the original sound
2. Pause/Play key: Short press to pause playback, long press to switch function mode (BT-TF-AUX-U drive)
3. Volume + button: short press for volume plus; long press for previous song
4. Volume - button: short press for volume reduction; long press for next song.
5. RGB light button: Short press to switch light modes (six light modes): Three color rotation - Breath - Gradient - Phantom rotation - Music follow - Monochrome convergence - Monochrome change, long press to turn off/turn on the light

The speaker interface

1. Type c interface: DC5V charging
2. TF bayonet: read MP3 files in TF
3. AUX: 3.5mm audio input

Microphone interface

1. Type c interface: DC5V charging

MULTI-FUNCTION OPERATION

1.The device cannot be turned on:

- Make sure the device is fully charged, please recharge or activate it and try again

2.The device has noise when using the device

- Check if the device is fully charged, or try again after charging

3.When using the device to play songs, there is no original singing

- Short press the canceling sing key to rule out the situation where the canceling singing mode has been turned on

4.No sound from the microphone

- Continuously short press the "mic+" button to increase the microphone wind volume, excluding the situation that the microphone volume is turned off

5.Microphone without reverberation:

- Rotate the Reverb knob to increase the reverb size/length, make sure the reverb is turned on

6.Microphone whistling

- Do not place the powered microphone close to or facing the speaker

7.Unable to search for the device name

- Check whether there are external devices such as TF card, U disk, AUX, etc., if any of the above external devices are connected, please unplug the device and search for the device name again

8.Play music silently or with low sound

- Rotate the power on/volume knob to increase the music volume
- Check if the phone volume is maxed

9.Unable to read TF/U disk

- Make sure that the TF/U disk is intact, and that there are MP3 files in the TF/U disk

10.Unable to charge

- Replace the charger or USB charging cable to rule out the inconsistency of the charging equipment

PRODUCT PARAMETERS

SPEAKER PARAMETERS

Model:	L2
Bluetooth version:	5.3
Product Size:	125*78*113MM
Bluetooth distance:	≤15M
Operating Voltage:	DC5V
Power supply:	3.6-4.2V
Channel:	Dualtrack
Battery capacity:	1800mAh
Work time:	4H
Supporting device:	Mobile phone Computer TV ect
Charging interface:	TYPE-C
Output Sensitivity:	400Mv
Output Power:	10W
Separation:	92DB
Input interface:	3.5mm
Signal to Noise Ratio:	-90DB
Frequency Range:	50HZ-20KHZ

MICROPHONE PARAMETERS

Bluetooth version:	5.3
Product Size:	38*38*128MM
Bluetooth distance:	≤8M
Operating Voltage:	DC5V
Power supply:	3.6-4.2V
Battery capacity:	500mAh
Work time:	4h
Charging interface:	TYPE-C
microphone:	Capacitor

背面

风琴折

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.