





〈设置

设备 🔆





智能眼镜

SMART GLASSES

使用指南

User Manual

请注意清洁干净)

Power on: Press and hold the red line on both sides for 5 seconds to power on **Shutdown:** Long press the red line on both sides for 5 seconds to shut down

开机:长按两侧红线5秒开机 关机:长按两侧红线5秒关机 (注:如果眼镜上有汗水会影响开关机效果,

(Note: If there is sweat on the glasses, it will affect the switching effect, please pay attention to clean it)



开机后双镜腿自动进行配对 After the boot two miror legs automatically paired



称Glasses-E13并连接。 (**注**:智能眼镜充电自动关机,拔下充电器 或充满电后自动开机,智能眼镜自动识别已 配对设备并自动连接。)

After the smart glasses are turned on, turn on the Bluetooth of the mobile phone, search for the device name E13 and connect. (Note: The smart glasses will automatically turn off when charging, and automatically turn on when the charger is unplugged or fully charged. It will automatically recognize the paired device and connect automatically.)



来电接听/挂断:触摸点击 (左或右) 1下 **拒接电话**:长按触摸键(左或右)2秒 (**注**:通话音量大小在手机上调节)

Incoming call answer/end call: touch (left or right) 1 times Reject a call: long press the touch key (left or right) for 2 seconds
(Note: the volume of the call can be adjusted on the phone)





音乐暂停/播放: 触摸点击(左或右)1下 **音乐切换:** 触摸点击左2下切换上一首 触摸点击右2下切换下一首

Music pause/play: touch (left or right) Music switch: touch and click left 2 down to switch to the previous song Touch and click right 2 down to switch to the next song



Remote camera



遥控拍照:先在手机打开照相机,然后触摸 眼镜 (左或右) 按键2次进行遥控拍照

Remote control photo: First open the mobile phone, then touch the glasses (left or right)
button twice to take a remote photo



Voice assistance



唤醒语音助手:长按两侧红线2秒(左或右)

Turn on voice assistant: Long touch the red lines on both sides for 2 seconds (left or right) Turn off voice assistant: touch and tap (left or right) 1 time

关闭语音助手:触摸点击 (左或右) 1下

中英文语言切换 Chinese and English switching



中英文语言切换:触摸点击(左或右)4下

Chinese and English switching: touch (left or right) 4 times



磁吸式充电: 充电时显示红灯常亮 充满电时显示蓝灯常亮一分 钟后熄灭(需90分钟充满)

Magnetic charging: the red light is always on when charging The blue light a minute turns off after a minute on when fully charged (it takes 90 minutes to fully charge)

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.