



1. Light key: Press this key to open or close the light board. Hold down the button for more than 0.7 seconds to start adjusting the brightness of the light, cycling between maximum and minimum brightness. The lights cycle every eight seconds.
2. Color temperature key: Press this key to switch the color temperature of the light board.
3. Key 1: Press this key to set the fan speed to low.
4. Key 2: Press this key to set the fan speed to medium.
5. Key 0: Press this key to turn on or off the fan.
6. Key 3: Press this key to set the fan speed to high.
7. LED indicator: Press any key of the remote control, the indicator light will light up, and the remote control will issue instructions.
8. Use 2 1.5V # 7 batteries.

Remote control pairing: Within 30 seconds of restoring power to the controller, long press the "0" key on the remote control transmitter for 5 seconds or until the light on the fan flashes. Test the light and fan functions using the remote transmitter to confirm that the learning process is complete.

FCC statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause interference.
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device must operate with a minimum distance of 20 cm between the radiator and user body.