


70*6 X 130mm A面

S1


安全警告

请勿将产品及配件靠近火源或任何过热的环境中。
请勿将产品及配件接触水及湿气，不要在靠近水的地方使用本设备，也不要将产品浸入任何液体中，避免产品及配件受到水滴或水溅。
请勿自行打开或任意拆解、维修电池组件。如果电池更换不当会有爆炸危险，严禁将电池投入水、火中或靠近任何过热的环境中。
本产品由外接电源适配器(5V-1A电源)充电后使用，充完电后可方便的通过拔掉电源适配器插头断开电网电源。
当用户暂不使用本产品时，请将产品电源开关拔至关闭状态关闭电源(参见产品操控示意图)，避免电池电量的流失。
当禁止使用无线设备或设备的使用会引起电子设备的干扰与安全隐患时，请关闭本产品。
在易燃易爆区域，请关闭本产品，并遵守相关标示说明，以免引起爆炸或火灾。易燃易爆区域包括但不限于：加油站、易燃或化工制品运输及储存设备、有爆炸危险标志的区域，有“关掉双向无线电设备”标志的区域。
乘坐飞机时，请遵守航空公司有关规定和条例，在飞机起飞前关闭本产品，以免造成安全隐患。
仅适用于热带气候条件下安全使用，仅适用于海拔2000米以下地区安全使用。

产品介绍



产品介绍



注意事项

- 为了达到话筒扩音最佳效果，请将嘴头放置正面前方1-2cm处对准嘴头处发音，若无语音，可适当调小音量或将机器与嘴头的距离稍做拉扯，以防互相干扰。
- 尽量避免频繁拔插麦克风插口，以免造成插口松动而引起接触不良，不可将话筒和音源插错。
- 为保证锂电池使用寿命，建议使用完再充电，频繁充电将加速电池芯片老化，长时间不用时应每隔两个月充一次电。
- 因喇叭磁性较强，不可将机器和银行卡等带磁性的东西放一起，以免造成失磁而带来不必要的麻烦。
- 本产品所有配件皆按本机工作需要设计，如需更换配件尽量使用本公司原装配件，以达到最佳工作状态。
- 本产品在充电和正常使用过程中可能会轻微变热，这属于正常现象。
- 请使用抗静电软布或清洁擦抹布产品，在清洁本产品时请先关闭电源开关，并断开所有外部连接。请勿用化学物质擦拭(如:酒精、苯等化学洗涤剂或有腐蚀性的清洁擦拭剂)。
- 请勿摔落、抛掷或者踩踏本产品，请勿拆解本产品，否则不能享受本公司的免费保修服务。

FCC警告

该设备符合FCC条例第15部分的规定。
操作受以下两个条件约束：
(1) 此设备可能不会造成有害干扰，以及 (2) 此设备必须接受接收机的任何干扰，包括可能的对其他操作的干扰。

任何未符合规定责任方明确批准的变更或修改都可能使用户失去操作设备的权限。

备注：根据FCC条例第15部分的规定，该设备经过测试发现符合B类数字设备的限制。制定这些限制的目的是提供合理的保护，防止住宅安装中的有害干扰。该设备可能产生使用辐射的射频能量，如果不能按照说明安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰，这可以通过关闭和打开设备来测试，用户可以尝试通过以下一种或多种措施来校正干扰：

- 重新定向或重新定位接收天线。
- 增加设备和接收器之间的间距。
- 将设备连接到与接收器连接的电路不同的电路上的插座。
- 请咨询经销商或咨询收音机/电视方面的专业技术人员以获得帮助。

该装置经过评估，符合一般射频暴露的要求。该设备可以在便携式暴露条件下使用，不受限制。

70 X 125mm A面

SAINTLARK
LISTEN TO THE WORLD



保修条款

一、购买本产品，请认真填写此卡，仔细阅读以下保修条款，以确保产品得到有效保修。
1. 用户在购买产品时认真保管此卡，并请销售商盖章确认。
2. 保修时需同时提供保修卡。
3. 本保修卡附填资料属实，否则无效。
4. 产品保修期为一年，在保修期内如产品发生故障，属机器品质不良或制作问题，本公司提供免费维修及部件更换。

二、下列原因造成产品损坏不能正常使用，不在保修范围内。
1.未按照说明书使用及安装造成的损坏。
2.一切人为故意外造成的产品损坏。
3.未经本公司认可的维修、改装或产品封口贴纸破裂者。
4.产品表面划伤的老化、碰伤及划伤。

三、保修期满后，用户仍可得到本公司提供维权服务，但要支付相应费用。

WWW.SAINTLARK.COM


70*6 X 130mm B面

S1


Safety Caution

- Do not put the product and accessories near the fire source or any overheated environment.
- Do not touch the product and accessories with water and moisture, do not use the equipment near water, and do not immerse the product in any liquid to prevent the product and accessories from being subjected to water drops or splashes.
- Do not open or disassemble or repair the battery yourself. If the battery is replaced improperly, there will be an explosion hazard, Do not put the battery into water, fire or any overheated environment.
- The product is used after being charged by an external power adapter (5V-1A power supply). After charging, it can be conveniently disconnected from the power grid by unplugging the power adapter plug.
- When the user does not use this product temporarily, please turn the power switch of the product to the off state to turn off the power (see the product control diagram) to avoid the loss of battery power.
- When the use of wireless devices is prohibited or the use of devices will cause interference and security risks to electronic devices, please turn off this product.
- In flammable and explosive areas, please close this product and follow the relevant instructions to avoid explosion or fire. Flammable and explosive areas include, but are not limited to gas stations, chemical factories, flammable or chemical products, areas with explosive hazard signs, and areas with the sign "Turn off two-way radio equipment".
- Please abide by the relevant regulations and rules of the airline when taking the plane, and close this product before the plane takes off to avoid potential safety hazards.
- It is only suitable for safe use in non tropical climate conditions and in areas below 2000 meters above sea level.

Product Introduction



Product Introduction



Application Notice

- In order to achieve the best effect of microphone sound reinforcement, please place the microphone 1-2cm in front of the mouth and aim at the microphone to pronounce. If there is a howl, you can appropriately reduce the volume or move the microphone between the machine and the microphone to prevent mutual interference.
- Try to avoid plugging and unplugging the microphone socket frequently to avoid loose socket and poor contact. Do not plug the microphone and sound source incorrectly.
- To ensure the service life of the lithium battery, it is recommended to recharge after use. Frequent charging will accelerate the aging of the battery chip. If it is not used for a long time, it should be charged every two months.
- Due to the strong magnetism of the horn, it is not allowed to put the machine and bank card together and other magnetic things together to avoid unnecessary trouble caused by magnetic loss.
- All parts of this product are designed according to the working requirements of this machine. If you need to replace parts, try to use our original parts to achieve the best working condition.
- This product may become slightly hot during charging and normal use, which is a dry normal phenomenon.
- Please use an anti-static soft cloth to clean this product. Please turn off the power switch and disconnect all external connections before cleaning this product. Do not wipe with chemical substances (such as alcohol, benzene and other chemical solvents or abrasive cleaning agents).
- Do not drop, throw or step on this product. Do not disassemble this product without authorization, or you will not enjoy our free warranty service.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

70 X 125mm B面

SAINTLARK
(保修卡)



描述: _____ 流水号: _____

型号: _____

名字: _____

地址: _____

邮箱: _____

电话: _____

产品日期: _____

(名称和地址)

合格 (QC01)

深圳市圣百灵科技有限公司
深圳市宝安西乡三围航空路兆丰工业园6楼
Tel 0755-23016541 www.saintlark.com

WWW.SAINTLARK.COM

SAINTLARK
(保修卡)



描述: _____ 流水号: _____

型号: _____

名字: _____

地址: _____

邮箱: _____

电话: _____

产品日期: _____

(名称和地址)

合格 (QC01)

深圳市圣百灵科技有限公司
深圳市宝安西乡三围航空路兆丰工业园6楼
Tel 0755-23016541 www.saintlark.com

合格 (QC01)