
## D. Bluetooth Music



You can find Bluetooth Music by clicking the button Apple CarPlay or Android Auto. Turn on Bluetooth of the mobile phone first, and select [Bluetooth Music] option. Click the [BT Manage] option on the interface to connect Bluetooth to the mobile phone and start playing music.




These buttons correspond to [previous song], [play / stop] and [next song]

Click on the Lyrics button [ ] to display the lyrics. Click the Volume button[ ] to adjust the volume.

(Some mobile music player apps do not support displaying lyrics)

## E. Bluetooth



Click the [ BT Manage ] button to open the Bluetooth connection interface.



As shown in the figure above, click the Bluetooth button [ \_\_\_\_\_] to switch on the device after entering the Bluetooth interface.

The page will display the device name, such as: T86-1F4C46, and click the Modify

button [ \_\_\_\_] to modify the Bluetooth name of the device.

Select the device name with Bluetooth, and the remote device name of the phone will appear after successfully connecting.

At this time, you can play mobile phone music and other functions.

After connecting to Bluetooth, you can use the call function:



Click the Disconnect button [ to actively disconnect the Bluetooth.

## G. Setting



As shown in the picture, slide the main page to view the options on the next page, and click the [Setting] button on the second page to enter the setting interface.

Setting

**Icon** 

specification

Image mirror	Can choose to turn it on or off
Time config	Click on [Time config] to enter the settings:  Set up separately: year / month / day / time / minute / second
Screen saver	Click [Screen saver] to enter the settings:  Screen savers can be set to: off / 1 min / 5 min  When set for 1 or 5 minutes, the system operates for no corresponding time, and the screen will automatically extinguish.  After entering the screensaver, then press the power power button to light up the screen.

Voice control	See the instructions below.
Language	Click [Language] to enter the settings:  Language can be set up: Simplified Chinese /  traditional Chinese / English / Russian / Spanish /  French / Germa / Japanese / Korean
Storage Information	Click [Storage Information] to enter the menu: You can view the information of the SD card. The former item indicates the remaining available capacity, and the former item indicates the total capacity.
Format	Click [Format] to enter the settings:  This option formats all data information inserted.
Seset factory	Click [Reset factory] to enter the Settings:  Restore the factory settings, and you restore all the settings to the initial state.
Firmware version	Click on [Firmware Version] to enter the menu:  This option is available in the current basic version for easy confirmation.

Item	Problem	Solution
1	Unable to start T86MP5 supports 7V-32V car use, high voltage cannot be used)	<ol> <li>① Check whether the DC head of the cigarette lighter power cord is damaged or aging.</li> <li>② Check whether the fuse of the power plug is disconnected or burned.</li> </ol>
2	No touch phenomenon	<ol> <li>Touch is invalid during power-on, wait for normal power-on before operation.</li> <li>Check whether the touch is damaged, do not touch the screen with sharp objects, it is easy to scratch and damage.</li> </ol>
3	Machine heat, jam phenomenon	① Avoid direct sunlight or exposure to sunlight during use. The normal operating temperature of T86MP5 is -4 ~ 149 °F. After disconnecting the power supply, the temperature of T86 will be lower than 149 °F and work normally.

		① The first connection takes a little
4	Carplay cannot connect	longer.  ② Only iPhone supports Carplay.  ③ Check that the Bluetooth functions of the mobile phone are normal.  ④ Enter Settings - General -Carplay vehicle, delete all records and reconnect.  ⑤ Restart the iPhone and reconnect it.
5	Android Auto cannot connect	<ol> <li>Only Android phones are supported.</li> <li>Update Auto and related applications on mobile phones to the latest version.</li> <li>Do not enable VPN on the mobile phone.</li> <li>Check that the Bluetooth functions of the mobile phone are normal.</li> <li>Restart the Android phone and connect it again.</li> </ol>
6	The bluetooth music	Please set the screen casting mode to Bluetooth music. Other modes do not support Bluetooth music.

**Reminder:** Please ensure that there is no obstruction between the mobile phone and the device, Bluetooth signal communication is smooth, otherwise the product functions cannot be used smoothly.

## 9. Product parameters

Name	car media player	
Master	High-performance SOC	
Wireless system	Apple Carplay, Android Auto	
Screen	7 inch IPS material,1024*600 resolution	
Storage expansion	SD ≤ 256G Class10	
Wireless module	BT	
Built-in speaker	2 W speaker	
FM launch	Agreement versey #15 is 1551 is	
Operating Voltage	7V-32V Adaptive	
Working power	5-15W	
Size	182*116*66mm	
weight	Approximately 300g including bracket	
Material	ABS/PC	

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.