

135mm\*65mm

# Quick Use Guide

### List of items

### Product introduction

### Power on pairing

Open the cover of the charging compartment and take out the headset. When the LED light flashes, the headset will enter automatic pairing mode.

### Bluetooth pairing

Open the charging compartment and take out the headset.

When the headset is turned on, the device name is searched for JMS for pairing.

Mobile Bluetooth is turned on, and the device name is searched for JMS for pairing.

Pairing succeeded.

Close the lid.

Note: the first time will not automatically connect, you need to open the phone interface to manually search for the pairing name, take out the headset click JMS for pairing connection.

### Operation

**Binaural mode**  
One touch: play/pause incoming call, C2/A Answer, then hang up

**Binaural mode**  
Double click(S): play the previous song  
Double click(Q): play the next song

**Binaural mode**  
Three clicks(Q): volume increases  
Two clicks(Q): volume decreases

**Binaural mode**  
Triple click(Q): long press for 2S SIR: long press 1.5S Manual switch on/off/long press 3S

Tap angle within 130° voluntary adjustment (Q) → (Q)  
Put into the charging compartment and to adjust the angle to the required angle (Q)

### Headset wearing

1. Take out the headset
2. Wear along the back of the ear
3. Rotate to comfortable angle fixed position
4. Headphones ready SNAP!

### Product Parameters

Product name	JMS	Headphone charging time	1.5h
Bluetooth version	Bluetooth 5.3	Bluetooth transmission distance	10M
Headset battery	40MAH	Standby time	120h
Charging chamber battery	300MAH	Music time	6h
Charging interface	Type-c connector		

### WARRANTY

Dear customer, hello!

Thank you for patronizing our products. To ensure your interests, please read the instructions carefully after distributing the product and the following: (The following situations are not covered by the warranty, and our Company can provide paid services, please note!)

1. Failure to operate, use, and store the product in accordance with the instructions may result in damage to the product.
2. Unauthorized repair, repair to product packaging and contents.
3. Unintentional modification of factory setting and disassembly for repair.
4. Accidental factors or man-made damage to the product, such as input of unqualified voltage, high temperature, water damage, etc.
5. Failure and damage caused by force majeure, such as earthquakes, fires, floods, lightning strikes, etc.

### Matters Needing Attention

- Long time use of earphones may cause hearing damage, please average your time reasonably.
- Do not use unqualified chargers and high voltage current charging.
- Do not throw or avoid products falling due to falling.
- Do not disassemble, repair or modify the product by yourself.
- Do not use chemical solvents to wipe the product.

### WARRANTY

- If you put in the charging compartment, the headset does not respond.
- Check whether the charging compartment has electricity.
- If there is no electricity, you need to charge the charging compartment.
- If the headset is not in the charging position, the headset is sufficiently bent, or if the headset is not in the charging position, the headset is sufficiently bent, or you need to break it manually to restore the original position and fit with the charging chamber.