










 <p>索爱 SL6 TWS 蓝牙耳机 TRUE WIRELESS STEREO</p> <p>快速入门指南</p>	<p>前言 感谢您购买索爱公司产品。使用本产品前,请仔细阅读本说明书。请务必保管好此说明书,方便下次查阅,所有内容经过本公司细心编写如有印刷与遗漏问题或错误敬请谅解。</p> <p>注意事项</p> <ul style="list-style-type: none"> ① 不要在极热极冷、多尘及潮湿的环境中使用本机。 ② 使用时勿摔落、撞击、剧烈震动。 ③ 因产品的性能和功能而发生的变化,将另行通知。 ④ 耳机内含电池,不得暴露在日照、火烤或类似过热环境中。 ⑤ 请勿擅自拆卸本机,以免发生危险。如有疑问请与当地经销商联系或拨打我公司全国统一服务电话(0755-27785090)。 <p>产品介绍</p> <p>充电盒</p>  <p>耳机</p>  <p>触摸区域</p> <p>充电接口</p> <p>快速操作指南</p> 	<p>功能说明</p> <p>1. 包装清单 充电仓×1 耳机×2 TYPE-C充电电缆×1 说明书*1</p> <p>2. 充电盒 本产品为智能充电盒,翻开盖后耳机将自动连接蓝牙设备(针对之前连接成功的设备)</p> <p>3. 蓝牙配对 ① 使用时,打开充电盒,左右耳机的指示灯闪烁并自动组网,组网完成后,左耳指示灯闪烁,右耳不闪烁,打开手机蓝牙搜索“SOAIY SL6”选择并完成配对。 ② 已有配对记录后,打开充电盒,耳机将自动回连最近连接过的一台手机。 ③ 请在5分钟之内完成蓝牙配对,超时未连接,耳机将自动关机。需要将耳机放入充电盒中并合盖,重新操作请参考步骤①。 ④ 使用耳机时请关闭手机音乐播放器的音效模式,以达到最佳音质效果。</p> <p>4. 充电说明 1. 当充电盒指示灯闪烁时请及时充电。 2. 将USB充电线一端连接到充电仓Type-c充电输入口,另一端连接到电源适配器的USB端口。 3. 左右耳电量不足时,会报低电量提示音。请将耳机放入充电盒合盖充电,充电时指示灯长亮,充电完成后指示灯熄灭。 4. 本产品不带适配器销售,消费者若使用电源适配器充电,则应购买配套使用获得CCC认证,并满足标准要求的电源适配器。 5. 当耳机充电接口有异物且接触不良时,请用棉签沾酒精轻轻擦拭清洁耳机充电接口。</p>	<p>使用说明</p> <ol style="list-style-type: none"> 1.开机: 打开充电仓,耳机自动开机。 2.关机: 耳机放入充电仓,合盖后自动关机充电。 3.接听/挂断: 来电时及通话中,单击触摸耳机接听电话或挂断电话。 4.拒接电话: 来电时长按触摸耳机3秒。 5.唤醒 Siri: 连续三击触摸耳机。 6.播放/暂停: 单击左耳或右耳触摸区域。 7.切换歌曲: 双击左耳切换上一曲,双击右耳切换下一曲。 8.调节音量: 长按左耳减小音量,长按右耳加大音量,音量最大时会发出“嘟嘟”的提示音。 <p>产品使用参数</p> <p>产品名称:TWS蓝牙耳机 材质:ABS 蓝牙版本:5.3 蓝牙接收距离:≥10米 产品尺寸:H45.5*W61.5*D24.5mm 耳机电池容量:30mAh 耳机充电时长:约30min 充电仓电池容量:300mAh 充电仓充电时间:约2H 通话时长:约3H 播放时长:约4H 频响范围:20Hz-20KHz 喇叭灵敏度:96±1.5dB 蓝牙AAC、SBC高质量音频解码 无线电核准证书编码:CMIIID:2022DP6952 *根据公司业务发展,产品的功能参数及图片内容等可能随时调整,索爱不能保证相关包装及说明书的及时更新,顾客以实际使用时的功能及内容为准。</p> <p>SOAIY</p>
 <p>SOAIY SL6 TWS Bluetooth Earphones TRUE WIRELESS STEREO</p> <p>Quick Start Guide</p>	<p>Foreword Thank you for purchasing SOAIY product. Before using this product, please read this manual carefully. Please be sure to keep this manual for future reference. All the content has been carefully compiled by our company. Please forgive me for printing and omissions or errors.</p> <p>Precautions</p> <ul style="list-style-type: none"> ① Do not use the machine in extremely hot, cold, dusty and humid environments. ② Do not drop, hit, or violently vibrate during use. ③ Product performance and functions are subject to change without notice. ④ The headset contains batteries and should not be exposed to sunlight, fire or similar excessive heat. ⑤ Do not disassemble the machine without authorization to avoid danger. <p>Product description</p> <p>Charging box</p>  <p>Earphone</p>  <p>Indicator light</p> <p>Touch area</p> <p>Charging port</p> <p>Quick start guide</p> 	<p>Quick start guide</p> <p>1. Boot preparation</p>  <p>2. Headphones on</p>  <p>3. Headphone pairing</p>  <p>4. Headphones off</p>  <p>Function description</p> <ol style="list-style-type: none"> 1. Packing list Charging box *1 Headphones *2 TYPE-C charging cable *1 Manual*1 2. Charging compartment This product is a smart charging box. After opening the cover, the headset will automatically connect to the Bluetooth device (for devices that have been successfully connected before) 3. Bluetooth pairing ① When in use, open the charging box, the left and right earphone indicators will flash and connect automatically. After the connection is complete, the left ear light will flash, but the right ear light will not flash. Turn on the Bluetooth of the mobile phone, search for “SOAIY SL6” to select and complete the pairing. ② After the pairing record is established, open the charging box, and the headset will automatically connect back to the last connected mobile phone. ③ Please complete the Bluetooth pairing within 5 minutes. If the connection is not made within 5 minutes, the headset will automatically shut down. If you want to put the earphones into the charging box and close the cover, please refer to step ① for the re-operation. 4. Instructions for use 1. Please charge in time when the indicator light of the charging compartment flashes. 2. Connect one end of the USB charging cable to the Type-c charging input interface of the charging compartment, and connect the other end to the USB port of the power adapter. 3. When the power of the left and right earphones is low, a low battery warning tone will be reported. Please put the headset into the charging box and close the cover to charge. The indicator light is always on when charging, and the indicator light turns off after the charging is completed. 4. This product is sold without an adapter. If consumers use a power adapter to charge, they should purchase a power adapter that has obtained CCC certification and meets the standard requirements. 5. When there are foreign objects on the charging port of the earphone and the contact is poor, gently wipe it with alcohol to clean the charging port of the earphone. 5. Product parameters Product name: TWS bluetooth headset Material: ABS Bluetooth version: 5.3 Bluetooth receiving distance: >10 m Product size: H45.5*W61.5*D24.5mm Headphone battery capacity: 30mAh Headphone charging time: about 30min Charging compartment battery capacity: 300mAh Charging time: about 2H Talking time: about 3H Playing time: about 4H Frequency range: 20Hz-20KHz Speaker sensitivity: 96±1.5dB Bluetooth AAC, SBC high-quality audio decoding Radio Approval Certificate Code: CMIIID:2022DP6952 *According to the company's business development, the product's functions, parameters and picture content may be adjusted at any time. SOAIY cannot guarantee that the relevant packaging and manuals will be updated in a timely manner. Customers are subject to the actual functions and content in use. <p>SOAIY</p>	<p>Instructions for use</p> <ol style="list-style-type: none"> 1. Power on: open the charging compartment, and the headset will automatically power on. 2. Shutdown: the headset will automatically shut down and charge after it is placed in the charging compartment and closed. 3. Answer/hang up: when there is an incoming call or during a call, click and touch the headset to answer the call or hang up the call. 4. Reject the call: press the call key or hold the earphone for 3 seconds when there is an incoming call. 5. Wake up Siri: touch the earphone three times in a row. 6. Play/pause: click the left or right ear touch area 7. Switch songs: double-click the left ear to switch to the previous song, double-click the right ear to switch to the next song 8. Adjust the volume: long press the left ear to decrease the volume, long press the right ear to increase the volume, and a “beep” prompt will sound when the volume is at maximum. <p>Product parameters</p> <p>Product name: TWS bluetooth headset Material: ABS Bluetooth version: 5.3 Bluetooth receiving distance: >10 m Product size: H45.5*W61.5*D24.5mm Headphone battery capacity: 30mAh Headphone charging time: about 30min Charging compartment battery capacity: 300mAh Charging time: about 2H Talking time: about 3H Playing time: about 4H Frequency range: 20Hz-20KHz Speaker sensitivity: 96±1.5dB Bluetooth AAC, SBC high-quality audio decoding Radio Approval Certificate Code: CMIIID:2022DP6952 *According to the company's business development, the product's functions, parameters and picture content may be adjusted at any time. SOAIY cannot guarantee that the relevant packaging and manuals will be updated in a timely manner. Customers are subject to the actual functions and content in use.</p> <p>SOAIY</p>

 <p>SOAIY SL6 TWS Bluetooth Earphones TRUE WIRELESS STEREO</p> <p>Quick Start Guide</p>	<p>Foreword Thank you for purchasing SOAIY product. Before using this product, please read this manual carefully. Please be sure to keep this manual for future reference. All the content has been carefully compiled by our company. Please forgive me for printing and omissions or errors.</p> <p>Precautions</p> <ul style="list-style-type: none"> ① Do not use the machine in extremely hot, cold, dusty and humid environments. ② Do not drop, hit, or violently vibrate during use. ③ Product performance and functions are subject to change without notice. ④ The headset contains batteries and should not be exposed to sunlight, fire or similar excessive heat. ⑤ Do not disassemble the machine without authorization to avoid danger. <p>Product description</p> <p>Charging box</p>  <p>Earphone</p>  <p>Indicator light</p> <p>Touch area</p> <p>Charging port</p> <p>Quick start guide</p> <img alt="Quick start guide for SL6 TWS earphones, showing 4 main sections: 1. Boot preparation
---	---

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.