


**iKF-Solo  
Wireless Headphones**

Please read this manual carefully before you operating  
You set and retain it for future reference

### WELCOME

Thank you for using the iKF- Solo . We hope you will enjoy it!

Official package including  
Headphone\*1  
Charging/Audio cable(TYPE- C USB)\*1  
User manual\*1



### BEFORE USE

**Important Safety Instructions**

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.

7. Only use attachments/accessories specified by the manufacturer.
8. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in anyway, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

**WARNINGS/CAUTIONS**

- Do NOT use the headphones at a high volume for any extended period.
- To avoid hearing damage, use your headphones at a comfortable, moderate volume level.
- Turn the volume down on your device before placing the headphones on your ears, then turn the volume up gradually until you reach a comfortable listening level.
- Do NOT use your headphones while driving for phone calls or any other purpose.
- Do NOT use the headphones with noise canceling on at any time the inability to hear surrounding sounds may present a danger to yourself or others, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad, etc., and follow applicable laws regarding headphone use.
- Remove the headphones, or use the headphones with noise canceling off and adjust your volume, to ensure you can hear surrounding sounds, including alarms and warning signals.
- Be aware of how sounds that you rely on as reminders or warnings may vary in character when using the headphones.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by iKF void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules standard(s) (e.g., UL, CSA, VDE, CCC).

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with FCC radiation exposure limits set forth for general population.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.


**Getting assistance.**

For assistance with this product, please contact our customer service at the website where you purchased the product, leave a message or email us, we will answer as soon as possible.


Company: Dongguan Oumu Technology Co., Ltd.  
Address: Room 315- 318, Building D, Nanxin Industry International, Nancheng District, Dongguan City, Guangdong Province, China  
Website: http://kf.net.cn  
Email: supportkf@163.com

### HOW TO CHARGE

For the first time use, please fully charge the product.  
Charging: The power indicator light is solid red  
Full power: The red light of the power indicator is off  
Charging time: 2 hours  
**Low battery alarm:** Voice prompt once when the battery is low.



### INSTRUCTION




### HEADPHONE STATUS

**LED indicator**

Turn on: Signal light flashing white and green  
Turn off: The signal light is white for 2 seconds  
Connection succeeded: light is not on  
Incoming call status: Green light is on every 10 seconds  
(When a call comes in, it will prompt the ringtone of the mobile phone synchronously, if the mobile phone does not support synchronization ringtone, prompt tone "Diddiddidd")

### HOW TO CONNECT

1. Long press the power button 2S and hear the prompt that it is turned on;
2. Open the Bluetooth interface of the mobile phone, search for "iKF- Solo", click to connect;
3. After the first pairing and connection is successful, the headset will automatically connect to the last mobile phone with a connection record every time it is turned on, and there is no need to repeat pairing.



### BUTTON CONTROLS

**Call with headset**

|                                |                           |
|--------------------------------|---------------------------|
| Double-tap the power button    | Answer                    |
| Tap the power button 4 times   | Hand up                   |
| Long press the power button 2S | Incoming telegram: Reject |

**Listen to music with headset**

|                            |                         |
|----------------------------|-------------------------|
| Tap the power button       | Play/Pause              |
| Tap the + button           | Volume up               |
| Tap the - button           | Volume down             |
| Long press the + button 2S | Skip track forward      |
| Long press the - button 2S | Skip track backward     |
| Tap the ANC button 4 times | Wake up voice assistant |

**Three modes switch**

Tap the "ANC" button cycle through \*Music Mode/ANC Mode/Transparent Mode\*

**Movie mode**

Turn on :Double- tap the "ANC" button, and you will successfully enter the movie mode when you hear the prompt sound ;  
Turn off :Double- tap the "ANC" button, and you will successfully exit the movie mode when you hear the prompt sound;

**Transparent Mode (Touch control)**

Transparent mode (touch control) is enabled by default, if you are worried about accidental touch, you can turn off the control of the touch panel.

Turn on /off :Triple- tap the power button, and you will successfully enter/exit the transparent touch mode when you hear the prompt; \*Put your hand on the touch panel to turn on the transparent mode to sense the sound of the outside world, and release it to exit the transparent mode

**Game mode**

Turn on :Triple- tap the "ANC" button, and you will successfully enter the game mode when you hear the prompt sound ;  
Turn off :Triple- tap the "ANC" button, and you will successfully exit the game mode when you hear the prompt sound;

**Reset**

In the power- off state, press and hold the power button for 5 seconds to enter the re- pairing state.

**Wired connection**

The audio cable Type- C port is inserted into the headphone, the USB port is connected to the device you want to connect, the Bluetooth function is automatically turned off.  
**\*The USB AUDIO cable supports two functions of headphone charging and computer audio transmission.**

**External microphone**

Insert the configured microphone into the microphone jack, Calls/Voices are clearer.  
**\*The headset can also use an external microphone in wired connection**

### TIPS

1. Make sure the headset and the connected device are within a valid connection range and there are not too many obstacles that interfere with the signal;
2. It is normal for the headset to be disconnected occasionally. Just like WiFi, occasionally the connection is unstable. It may be due to interference in signal transmission, Please wait a moment or change the location to resolve;
3. When the headset cannot be connected to the device, please check whether the headset has power or is connected to other devices;
4. Please fully charge the Headphone once a month. If the Headphone is not used for a long time, the battery of the Headphones may be damaged.
5. The sound insulation and sound leakage of headphones are related to the way of wearing the headphones and the volume of the headphones.
- You can adjust the wearing angle and degree of ear wrapping of the headphones in time according to the actual comfort of use. Please close the ear/head foam part of the headphone as much as possible.
6. Please use a standard- compliant charging head to charge the headset.
7. Do not wear the product for bathing, or use it in the rain, and do not soak the product in water. After each normal use, it is recommended to dry the sweat or stains on the headphone with a dry cloth, paper towel, etc., and then store it.

### LIMITED WARRANTY

**Warranty period: 1 year from the date of product receipt**


During the warranty period of the product, due to the quality of the product itself, please contact us with the warranty card and shopping records to receive a return authorization / free maintenance and shipping instructions.

**Fault Table**

|  |
|--|
| 1. Bluetooth headset cannot hear sound;                  |
| 2. The other side cannot hear the voice during the call; |
| 3. Unable to charge Bluetooth headset                    |

**The following conditions will not provide free repair :**

- 1.Unauthorized maintenance, misuse, collision, neglect, abuse, accident, alteration, or damage or alteration of the appearance of the product;
- 2.The product exceeds the warranty period specified by the company;
- 3.Damage caused by self-disassembly;
- 4.Failures caused by accidents such as water ingress or falling, squeezing, etc.;
- 5.Normal wear and dirt caused by use, such as scratches, damage caused by contact with chemical reagents, contact with sharp objects, etc.;
- 6.Outer packaging and accessories, gifts, services other than the products promised by the sales staff, and additional configurations and gifts;
- 7.Improper storage: If the product is exposed to abnormal humidity and temperature for a long time, the performance is damaged;
- 8.Failure or damage caused by force majeure;



Focus on interesting musical products

We apologize for any inconvenience caused by any typographical or translation errors.If the content is corrected later, please forgive us without notice.

Made in China