


To unlock/prime the drone, move the joysticks as shown in the figures.



and distance of the drone will also be limited to 60ft)


14+ AGES

table of Contents

Precautions for the installation and use of obstacle avoidance equipment......

2. Precautions for the use of gimbal and camera.....

3. Remote control and drone pairing.....



QUICK START GUIDE

Learn more about drones before flying

\* For details, please refer to the instruction manual.

Please ensure that the drone and remote control batteries are fully charged before the flight.



Dimly lit Large vertical Smooth reflective Two-color stripe

ground

the water

2. Precautions for using the PTZ camera:

⚠ ATTENTION

Flight mode switch

Ranger has 2 flight modes: GPS and Optical Flow Modes.

By default, GPS mode (mode 2) is on. This mode needs to locate at least 8 satellites for it to take off. If it can not find 8 satellites it can not take off.

current lens (front lens or down lens).

current lens (front lens or down lens). 

Speed - Speed : Displays the current state of fast and slow. Click

to switch to fast or slow in mobile control mode.

Camera: Click the button to shoot videos according to the

Unlock: After unlocking, one key can be used to take off or drop. Take-off/landing: After the calibration is completed, place the

aircraft horizontally and click the unlock button to start the flight

After the aircraft takes off, the holder will be displayed on the

left side of the screen. At this time, if you move the slider

certain angle; if you move the slider down, the front lens of the aircraft will move downward by a certain angle.

right turn of the aircraft, and the right rocker can control the forward.

towards the left and right.

ward movement of the aircraft, and it can also move the aircraft

The left rocker can control the upward movement, downward movement, left and

After clicking in the upper left corner

album interface. When you click to view

photo or video, users can share photos or

videos to major social platforms

through in the top right corner.

Remote and app usage

(1) Scan the QR code to download and install the app, supports IOS and Android.



Connect Drone WiFi

1. Power on the drone:

2. Find the drone hotspot in your device settings > Wifi Connections

Click the hotspot network (no password), and the phone will connect automatically.

