
press the holes on the longer band onto the metal pin buckle of the shorter band.

loop of the shorter band and tighten.



Heart Rate and Blood


Oxygen Sensors

Charging cable

You can follow these steps to use Cubitt x Reebok: 1 Wear \rightarrow 2 Power On \rightarrow 3 Set up \rightarrow 4 Start Using

Step 2: Adjust to a comfortable tightness, ther

Step 3: Insert the longer band into the second



2 Power On

Support full-screen touch (swipe, tap) Press the Digital Crown until the startup screen appears.



Note: If the watch can't power on, it may be because the battery approximately 10 minutes and wait for it to power on

4 Get Started

touch and hold)


Touchscreen Operation

Set up the Watch

Step 1: Download the Cubitt Pro app

Go to the app store on your phone, search for Cubitt Pro, and install it.

· For Android phones, go to the Google Play. · For iPhone, go to the App Store.



Open the Cubitt Pro app and select "**Set Up a Device**" on the home page. Follow the instructions to pair your " Cubitt x Reebok " via

Crown and Button

the watch face screen.

2. Adjust the volume of prompt tones and phone calls. 2. Long press to activate SOS

the watch, please do not pair directly within the Bluetooth device list in your phone's system settings. 2. To ensure successful pairing, please grant Cubitt Pro app permissions to access Bluetooth, Location, and

Camera on your phone.

1. Press the digital crown to wake up the screen.

1. Toggle between screens or navigate through

2. Press the digital crown to enter the app center from

Step 2: Pair with the App

Bluetooth. Then you can start using the watch.

Press the button

1. Press to start Workout quickly

1. To prevent connection issues between the app and

Attentions:

Search via Bluetooth


Rotate the crown


Press the button




Common Functions

access the Control Center, swipe up on ne watch face screen. Enable features like Silent Mode, Sleep Mode, Always-on Display





Swipe down on the watch face screen.



Change the Watch Face

the watch face gallery.

Record Workouts

To change the watch face, press and

To start your workout recording, access

the Workout app and select a specific

hold the screen for 1 second to access

Health Metrics Measurement When wearing the watch, it automatically

measures health data such as heart rate sleep, stress, and activity. You can also view Add Photos can choose up to 3 and track this data in the applicatior

Install New Watch Faces

preferred watch face.

Face Gallery


new Photo every time

you raise your wrist or

tap the screen. You

New Faces >

Face Gallery page to pick up your it is being charged.




of 5V=1A or above.

4. Pull the watch band to confirm the firm installation.




Remove band

1. Insert the metal pin at position "A" in the hole.



To charge the watch, connect the charging cable to a USB power source. Attach the other end to the charging contact on the back of the watch. The watch will display a charging icon while



Make sure the USB charging plug is at the same side as the

Prior to charging, ensure to clean the charging contacts of the watch to eliminate any lingering sweat or moisture.

Install band

1. Lift the spring bar from the groove 2. Push and hold the spring bar. 2. Push and hold the spring bar. 3. Press the band into the body and release the spring 3. Pull it out gently to remove the



It is advised to remove the watch for approximately one hour daily. If you experience discomfort or irritation like redness, tingling, or a burning sensation, take off the watch and rest your

Key Specifications

Water resistance garde

Body Dimension

Product Name

two finger-widths from your wrist bone. To maintain hygiene, regularly clean your watch and wrist, particularly after workouts and sweating. Avoid using hand soap

Smart Watch

466 × 466

370 mAh

Compatible Operating Systems iOS 13.0 and above, Android 9.0 and above

1.43" HD AMOLED

46.5mm × 46.5mm × 11.3mm

shower gel, dishwashing liquid, or cleaning wipes as they can ensures both contact and fit. cause skin irritation. Instead, use mild soap and fresh water to

For optimal data accuracy, please observe the following guidelines while wearing the watch: I. Wear the watch at a position approximately

2. For comfort, adjust the band to allow a inger's width between it and your wrist. This



Precautions

· Do not replace the built-in battery yourself as it may pose a safety ris · Avoid forcibly opening the watch case, as it may cause short circuits and

· Keep the watch away from environments exceeding 60°C to prevent battery

· While the product complies with 3ATM waterproof standards, it is not

high temperatures, steam, or rapid water flow. Note that the waterproof performance may be compromised if the product

 \cdot Be aware that firmware upgrades can lead to interface and usage changes. For

detailed information, please refer to the product's upgrade instructions


Frequently Asked Questions

If you encounter any problems while using the product, you can access the "Profile \rightarrow Help & Support" section in the Cubitt Pro app for assistance



Product Manual

You can find the complete product manual in Cubitt Pro app at "Profile → User Guide".



overheating.

leakage or explosion.

recommended for activities such as bathing, diving, or water skiing that involve

exempt RSS(s). Operation is subject to the following two conditions:

2. This device must accept any interference, including interference that may

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est

applicables aux appareils radio exempts de licence. L'exploitation est

2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le

1. this device may not cause harmful interference, and

that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particula

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Increase the separation between the equipment and receiver.


Consult the dealer or an experienced radio/TV technician for help.

cause undesired operation of the device.

conforme aux

autorisée aux deux conditions suivantes :

1. This device may not cause interference.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

responsible for compliance could void the user's authority to operate the

Any changes or modifications not expressly approved by the party

2. this device must accept any interference received, including interference

a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of

Reorient or relocate the receiving antenna.

FCC Requirement

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

with Innovation, Science and Economic Development Canada's licence-

CNR d'Innovation, Sciences et Développement économique Canada

1. L'appareil ne doit pas produire de brouillage;

This device contains licence-exempt transmitter(s)/receiver(s) that comply