



802.11n-HT20 - PSD – Ant 1


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 - PSD – Ant 1


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11ax-HE20 - PSD – Ant 1

Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)



802.11ax-HE40 - PSD – Ant 1


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11b - PSD – Ant 2


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11g - PSD – Ant 2

Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT20 - PSD – Ant 2


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 - PSD – Ant 2

Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)

