


JYX

USER MANUAL

MODEL:JYX-60BT



2020-09-10



深圳市佳誉祥音响电子有限公司

绘 图:		品 名:	JYX-60BT英文说明书
电子/结构确认:		版 本:	A/0
业务确认:		规格材质:	115x160mm 157g铜版
核 准:		物料编号:	440-JYX600-BT1

Catalogue

Introduction.....	1
Product functions.....	2-4
Technical Indicators.....	5
Packing list.....	5
FQA.....	6

试用水印

Dear users:

Thanks for your purchasing. Please read the directions carefully before using and follow the correct instructions.

Matters needing attention:


To ensure safety, please read carefully and follow the following safety instructions:

1. The equipment is up to The China Compulsory Certification.
2. The equipment should be used in a dry environment.
3. Do not place a fire source near the equipment.
4. Do not use near water source to avoid corrosion of products and accessories.
5. Do not open or disassemble or repair the battery module by yourself. There will be a risk of explosion if the battery is not replaced properly. Do not put the battery into water, fire or any overheated environment.
6. When taking an airplane, please follow the relevant regulations and regulations of the airline company to turn off this product before the airplane takes off to avoid any hidden danger.
7. The charging cable cannot be squeezed, pulled, bent, knotted, or suspended from heavy objects in order to avoid damage to the insulation layer of it and cause electric shock.


1

Guide to control and setting

TOP PANEL



BACK PANEL



2

Operation Guide

1. **Power:** Press to start/stop, long press for 8 seconds to force reset.
2. **Previous:** Short press to switch to the last program; long press to fast backward.
3. **Next:** Short press to switch to the next program; long press to fast forward.
4. **Play/Pause:** Short press to play/pause; in radio mode, long press for automatic radio station search; In bluetooth mode, long press for True Wireless Stereo(TWS, only valid for the same model)
5. **REC:** Long press to record audio, during this process, short press to stop recording. When there is a recording file in the storage device, short press is to play the recording file. (The recording function is only available when a storage device is plugged in)
6. **Mode:** short press to switch between bluetooth, flash card, TF card and FM radio. In the state that bluetooth has already connected, long press to disconnect.
7. **Audio receiving hole**
8. **Master: Adjust master volume**
9. **Echo:** Adjust echo
10. **MIC VOL:** Adjust the microphone volume
11. **Dynamic microphone jack(6.35mm)**
12. **Condenser microphone jack(3.55mm)**
13. **AUX IN**
14. **TF Card port**
15. **USB port**
16. **5V charging port**
17. **Charging indicator:** The light is red when charging and blue when fully charged.

Bluetooth Connection

1. Turn on bluetooth on your mobile device.
2. Press "Mode" key and switch the speaker to BT mode.
3. Select "JYX-60BT" from available devices. (If JYX-60BT is unavailable, please switch back to Bluetooth mode and try again)

AUX- IN

Plug the 3.5mm audio cable into the AUX IN jack, the speaker will play the audio from input device automatically.

USB and TF Input

When insert USB or TF card into speaker, the speaker will play the audio from USB/TF card automatically.

FM Radio

1. Pull out the antenna on the top of speaker.
2. Press "Mode" key to switch to radio station.
3. Long press "Play/Pause" key to search and save more available stations automatically.
4. The station searching completed when it no longer switch automatically.
5. Press "Next" or "Previous" to select your own station.

REC

1. Plug in a TF card or flash card
2. Long press "REC" to start recording, short press to end recording.
3. Short press "REC" to play the recording audio.

TWS Function

To use this feature, two JYX-60BT systems are required.

1. Turn on the two JYX-60BT and turn them both into Bluetooth mode. Two machines will flash "BLUE" on screen.
2. Long press the "PLAY/PAUSE" button of either of the two machines (Only need to press one button), the other machine will make a prompt tone and stop flashing. TWS function will be activated by then.
3. Connect your device with the speaker and play music.
4. Long press "PLAY/PAUSE" button again to inactivate TWS function.

If you're still wondering about these steps, please contact customer service team for a video tutorial: service-us@szjyx.com.cn

Product Parameters

Model: JYX-60BT
RMS: 7W
Input voltage:5V

Package includes

Speaker system..... 1PC
Charging cable.....1PC
User manual.....1PC
Adjustable shoulder strap.....1PC

FAQ

Q:The system can not start up.

A:Charging the built-in battery;
Check if the adapter is connected securely.

Q:The system provides no sound.

A:Check if the system is power on.
Adjust the volume.

Q:The Bluetooth connection is not available.

A:Move your device closer to the system.
Check to see if the Bluetooth is engaged.

Q:Unable to connect two system with TWS feature.

A:Make sure the two systems are within one meter of each other.

Q:Reset the system.

A:If the system does not respond to any operations,long press "Power"
key for 8 seconds to reset the system.

(Notes:If necessary,contact after-sales team)

Contact Information

SHENZHEN CITY JIAYUXIANG ACOUSTICS ELECTRONIC CO.,LTD.

JIA YU XIANG(HK)INTERNATIONAL ELECTRONICS CO.,LIMITED

Factor address:NO.7th Building,Houhaixufa Industrial Zone,
Loucun,Gongming town,Guangming District,Shenzhen,China

TEL:+(86)-0755-23410725 **FAX:**+(86)-0755-27508507

Website:www.szjyx.com.cn **E-mail:**service-us@szjyx.com.cn

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements, the device can be used in portable exposure condition without restriction