1.4 What is included with your Senquip QUAD

When you open your the Senquip QUAD box, the following are included:


Figure 1.1. 1 x Senquip QUAD

Figure 1.2. 1 x GNSS and 4G LTE combination antenna

Figure 1.3. 1 x 2-hole and 1 x 3-hole gland insert

Figure 1.4. 1 x 3mm Allen key

Figure 1.5. 1 x Getting started guide

1.5 Regulatory Information

USA: Federal Communications Commission (FCC) statement

This device complies with FCC part 15 FCC Rules.

Operation is subject to the following two conditions: 1. This device may not cause harmful interference and 2. This device must accept any interference, including interference that may cause undesired operation of the device.

FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device meets the FCC and IC requirements for RF exposure in public or uncontrolled environments.

1.5.1 Accessing Regulatory Information

You can view the device FCC ID on the Senquip Portal. To view the FCC ID

1. Launch the Senquip Portal.