




H Frontlader heben und senken / Raising and lowering front loader / Lever et abaisser le chargeur frontal / Subir y bajar el cargador frontal / Frontloader omhoog en omlaag




I Schaufel heben und senken / Raising and lowering shovel / Lever et abaisser la pelle / Subir y bajar la pala / Schuif omhoog en omlaag





J Anbaugeräte montieren / Mounting front loader accessories / Monter des accessoires pour chargeur frontal / Montar implementos / Aanbouwapparaten monteren




oder / or / ou / o / of




K Palette aufladen und Parallelführung der Gabel / Loading a pallet and parallel motion of the fork / Charger une palette et guidage parallèle des fourches / Cargar paleta y guiado paralelo de la horquilla / Paletvork laden en parallelgeleiding van de vorken



L Lenkjustierung / Steering adjustment / Ajustage de la direction / Ajuste de dirección / Stuurinrichting afstellen




M Eigenen Modellnamen vergeben / Assign your own model name / Attribuer des noms de modèles propres / Asignar un nombre de modelo propio / Eigen modelnaam geven



SIKUCONTROL
Bedienungsanleitung Traktoren 67XX Serie / Operating instructions for 67XX Series tractors / Mode d'emploi Tracteurs série 67XX / Instrucciones de uso tractores serie 67XX / Gebruikshandleiding tractoren serie 67XX

A Batterien einlegen / Inserting the batteries / Placer les piles / Colocación de las pilas / Batterijen plaatsen



B Systemstart / System start / Démarrage du système / Inicio del sistema / Systeem starten

1 Download SIKUCONTROLAPP:

ANDROID APP ON Google play Available on the App Store

1. **2.**

3

C Systemstart / System start / Démarrage du système / Inicio del sistema / Systeem starten

1

3

D Steuerung / Control / Commande / Control / Besturing

1 **2**

1 **2**

oder / or / ou / o / of

E Licht / Lights / Lumière / Luces / Verlichting

1 **2**

3 **4**

F Blinken / Flashing / Clignotement / Intermitentes / Knipperen

1 **2** **3**

G automatisch Kuppeln / Automatic coupling / Attelage automatique / Acoplamiento automático / Automatisch koppelen

1 **2**

CAUTION: Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with the RF exposure guidelines, place the product at least 20 cm from nearby persons.