FRONT

BACK COVER

FRONT COVER

WARNING LI-ION BATTERY INSIDE

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it



Rating Label Definitions

Direct current symbol



This symbol signifies and declares that this equipment complies with battery charging which complies with California CEC and energy



(BC)

This symbol signifies that the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the

Bluetooth

powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license.

Warranty Information

90-Day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows

To obtain warranty service:

- O obtain warranty service:
 Visit our customer support portal: www.customersupport123.com
 and select "Support".
 Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products eceived damaged as a result of shipping will require you to

Warranty service not provided

Warranty service not provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.



t names, trademarks, and registered trademarks are proper ective owners. All company, product, and service names use ment are for identification purposes only. Use of these nar

Printed in China Designed in the U.S v1. 3/2024



Bluetooth

WIRELESS EARBUDS With Charging Case



Instruction Manual CBTWS201WH

BACK

Before You Begin...

(Caution

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturerapproved batteries, chargers, accessories, and supplies.

- 1. Please charge in a safe environment. When charging the charging bin, the charging bin should be separated from the charger as soon as possible, so as to avoid damage to the charging bin caused by charging for a long time.
- 2. When the music is playing, please adjust the music to the appropriate volume to avoid long-term damage to the hearing under the condition of high volume.
- 3. Try to avoid using the earphone where there is interference ource, otherwise it may affect the earphone signal.
- 4. Try to avoid using the earphone in a corrosive environment, so as not to affect the function of the earphone.

Tips: when you use this bluetooth headset to listen to music or talk, please pay attention to adjust the volume, so as not to affect your listening too much!


In The Box

- Earbuds
- Charging Case USB Charging Cable
- User Manual

Product Specifications

Product model: CBTWS201 Battery specification: earphone 3.7v; Charging bin 3.7v Supported mode: HFP/HSP/A2DP/AVRCP Sensitivity: 105dB ±3dB S.P.L at 1KHz Signal distance: 10 m (in an ideal environment without an nt without any large obstacles) Standby time: about 80 hours Charging time: charge the charging warehouse for about 1hours, and charge the headset for about 1 hour Charging times for the headset: about 2 times

Location of Controls



Take the headset out of the charging bin and start it automatically or long press the left and right multi-function button of the headset for 3 seconds

Put the earphone into the charging chamber and turn it off automatically.

Long press the left and right earphone multifunction keys for 5 seconds to

3. Boot back

When the pairing is successful, the bluetooth headset will first enter the state of reconnect when the second time is started and automatically reconnect the connected phone.

n standby state, click the left or right earphone multifunction button to play music directly, while click the left or right earphone multifunction button to pause playing.

5. Switch songs
Press the left earphone muti_function button for 2 seconds to play music, and then press the right earphone mutifunction button for 2 seconds to play

6. Volume up and down

12. Low battery alert

Double-click the left earphone multifunction button to increase the volume step by step, and double-click the right earphone multifunction button to ease the volume step by step

. Answer incoming calls

When the mobile phone calls, click on the left and right earphone multi-function keys can answer the phone

8. Call hang up
When talking on the mobile phone, you can hang up the phone by clicking the left or right earphone multifunction button.

When the phone calls, long press the left and right earphone multifunction button for 2 seconds to reject the call. 10 Redial

When you are on standby or playing music, you can make the last call in your phone record by three clicks of the left earphone multifunction button.

11. Start voice assistant Three clicks on the right earphone multifunction button can activate apple's Siri or Google voice assistant for voice control of the phone operation.

When the headphone battery is insufficient, the interval of 60 seconds to play a low battery sound, until the headphone low power off.

Getting Started

- 1. Plug the Micro USB charging cable into the charging bin and the Charger at one end. The Charger uses a standard 5V 1A charger to charge the bin.
- 2. Charging the earbuds housing: the headphones can be automatically charged into the charging bin, the red light blinks when charging, and the red light keeps on when fully charged.

Bluetooth Pairing

Charging

- 1. Take it out from the charging bin or press the left and right multi-function area for 3 seconds at the same time, turn it on until the indicator light flashes alternately, enter the pair-ear search matching state, enter the pair-ear automatic matching state, after the successful matching, the main ear automate fracturing state, and the successitu matering, the maintenance indicator lights flash alternately, the auxiliary ear indicator lights turn off, and the pair ear matching success cue tone is played simultaneously. 2. Enable wireless capabilities on your phone or other devices. If it's an android phone or device, click the "Search for wireless devices" option on your phone. If It's an IOS phone or device, it will search for devices automatically After searching for the model of the wireless headset, click enter the match. After the match is successful, the headset will give a notification tone that the connection is successful. The left and right headset lights will turn off and enter the connection standby mode, the right ear was the right vocal tract and the left ear was the left vocal tract.
- 3. The two headphones can also be paired with the mobile phone separately The operation method can be operated according to the operation method of

Compliance Information

FCC Information This device complies with Part 15 of the FCC Rules

CAUTION: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RADIATION EXPOSURE INFORMATION

This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

FRONT

BACK COVER

FRONT COVER

WARNING LI-ION BATTERY INSIDE

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it



Rating Label Definitions

Direct current symbol







This symbol signifies that the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the

Bluetooth

This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license. Warranty Information

90-Day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows

To obtain warranty service:

- O obtain warranty service:
 Visit our customer support portal: www.customersupport123.com
 and select "Support".
 Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products eceived damaged as a result of shipping will require you to

Warranty service not provided

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged. repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.



t names, trademarks, and registered trademarks are propert ective owners. All company, product, and service names use ment are for identification purposes only. Use of these nan

Printed in China Designed in the U.S v1. 3/2024



Bluetooth

WIRELESS EARBUDS With Charging Case







Instruction Manual CBTWS201BK

BACK

Before You Begin...

(Caution

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturerapproved batteries, chargers, accessories, and supplies.

- 1. Please charge in a safe environment. When charging the charging bin, the charging bin should be separated from the charger as soon as possible, so as to avoid damage to the charging bin caused by charging for a long time.
- 2. When the music is playing, please adjust the music to the appropriate volume to avoid long-term damage to the hearing under the condition of high volume.
- 3. Try to avoid using the earphone where there is interference ource, otherwise it may affect the earphone signal.
- 4. Try to avoid using the earphone in a corrosive environment, so as not to affect the function of the earphone.

Tips: when you use this bluetooth headset to listen to music or talk, please pay attention to adjust the volume, so as not to affect your listening too much!


In The Box

- Earbuds
- Charging Case USB Charging Cable
- User Manual

Product Specifications

Product model: CBTWS201 True wireless version: V5.3 Battery specification: earphone 3.7v; Charging bin 3.7v Supported mode: HFP/HSP/A2DP/AVRCP Sensitivity: 105dB ±3dB S.P.L at 1KHz Signal distance: 10 m (in an ideal environment without an nt without any large obstacles) Standby time: about 80 hours Charging time: charge the charging warehouse for about 1hours, and charge the headset for about 1 hour Charging times for the headset: about 2 times

Location of Controls



Take the headset out of the charging bin and start it automatically or long press the left and right multi-function button of the headset for 3 seconds

Put the earphone into the charging chamber and turn it off automatically.

Long press the left and right earphone multifunction keys for 5 seconds to

3. Boot back

When the pairing is successful, the bluetooth headset will first enter the state of reconnect when the second time is started and automatically reconnect the connected phone.

n standby state, click the left or right earphone multifunction button to play music directly, while click the left or right earphone multifunction button to pause playing.

5. Switch songs
Press the left earphone muti_function button for 2 seconds to play music, and then press the right earphone mutifunction button for 2 seconds to play

6. Volume up and down

Double-click the left earphone multifunction button to increase the volume step by step, and double-click the right earphone multifunction button to ease the volume step by step

. Answer incoming calls

When the mobile phone calls, click on the left and right earphone multi-function keys can answer the phone

8. Call hang up
When talking on the mobile phone, you can hang up the phone by clicking the left or right earphone multifunction button.

When the phone calls, long press the left and right earphone multifunction button for 2 seconds to reject the call. 10 Redial

When you are on standby or playing music, you can make the last call in your phone record by three clicks of the left earphone multifunction button. 11. Start voice assistant

Three clicks on the right earphone multifunction button can activate apple's Siri or Google voice assistant for voice control of the phone operation. 12. Low battery alert

When the headphone battery is insufficient, the interval of 60 seconds to play a low battery sound, until the headphone low power off.

Getting Started

1. Plug the Micro USB charging cable into the charging bin and the Charger at one end. The Charger uses a standard 5V 1A charger to charge the bin.

2. Charging the earbuds housing: the headphones can be automatically charged into the charging bin, the red light blinks when charging, and the red light keeps on when fully charged.

Bluetooth Pairing

Charging

1. Take it out from the charging bin or press the left and right multi-function area for 3 seconds at the same time, turn it on until the indicator light flashes alternately, enter the pair-ear search matching state, enter the pair-ear automatic matching state, after the successful matching, the main ear automate fracturing state, and the successitu matering, the maintenance indicator lights flash alternately, the auxiliary ear indicator lights turn off, and the pair ear matching success cue tone is played simultaneously. 2. Enable wireless capabilities on your phone or other devices. If it's an android phone or device, click the "Search for wireless devices" option on your phone. If It's an IOS phone or device, it will search for devices automatically After searching for the model of the wireless headset, click enter the match. After the match is successful, the headset will give a notification tone that the connection is successful. The left and right headset lights will turn off and enter the connection standby mode, the right ear was the right vocal tract and the left ear was the left vocal tract.

3. The two headphones can also be paired with the mobile phone separately The operation method can be operated according to the operation method of

Compliance Information

FCC Information This device complies with Part 15 of the FCC Rules

CAUTION: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RADIATION EXPOSURE INFORMATION

This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.