

105\*75mm  
157g 双铜纸

## "EXPLORER"

### 蓝牙耳机

蓝牙耳机: 蓝牙耳机出厂设置后, 首次开机耳机将进入配对状态。

- 首次打开充电盒, 取出耳机, 自动进入配对状态。
- 打开与耳机配对设备的蓝牙开关, 搜索耳机名称选择并配对连接。
- 耳机恢复出厂设置后, 首次开机耳机将进入配对状态。

### 恢复出厂设置

1. 将放入充电盒中, 保持充电盒盖子打开。长按充电盒背键 10-15s, 充电盒灯键将红白交替闪烁6次, 耳机灯光亮起, 即表示耳机出厂设置。

2. 恢复出厂设置完成后, 关闭充电盒盖, 重新打开进入配对模式。

### 功能使用

您可以通过使用手机下载“ROSELINK”APP, 获取更多功能并自定义耳机设置。  
 - 在应用商店搜索“ROSELINK”APP搜索并下载安装。或扫描二维码下载。

### 警告

1. 请遵守所在国家或地区的相关规定。请在驾车、操作机械或从事需要特别注意外界声音的工作时使用设备。  
 2. 请在恶劣天气下使用设备。雷暴可能导致设备不正确工作或造成电击危险。  
 3. 请将设备放置在阳光直射的地方, 如汽车仪表盘或中控台, 包括, 保修的权利。  
 4. 请勿将设备靠近热源或易燃物。  
 5. 请勿使用加热工具 (如电吹风、微波炉等) 对设备进行干燥处理。  
 6. 请勿擅自拆卸或更改设备及其附件。否则设备及其附件将不在本公司保修范围之内; 设备发生故障时, 请联系制造商或服务中心。电话: 400-888-8888 或访问我们的官方网站。  
 7. 请勿将设备及其附件浸入水中或潮湿环境。  
 8. 请勿使用未经认证的充电器、充电器, 可能引起故障、火灾、爆炸或电击危险。  
 9. 清洁: 维护设备前请关闭电源; 请勿使用腐蚀性化学品, 请禁用有机溶剂清洁剂; 请使用柔软、干燥的纤维擦拭设备。

### 售后服务说明

以下若有与国家政策不符或遗漏之处, 以国家政策为准。

- 自购买之日起的1年内, 因产品质量问题可退货; 30日之内, 因质量问题可申请; 12个月内, 出现产品本身缺陷造成的性能故障, 消费者可享受保修服务。
- 产品在保修期, 用户造成损坏或因使用不当造成故障不在保修范围内, 包括, 保修的权利。
- 本公司对产品的其他配件 (如包装等) 不承担任何责任。
- 所有在保修期内维修或更换下来的零件、配件和附件均由本公司所有。

在用户使用过程中, 符合下列情况之一者不在保修范围内:

- 超过三年有效期。
- 无三包凭证及前机发票, 且无法证明该产品在三包有效期内。
- 未按产品说明书要求使用、维护、保养而造成损坏。
- 因非正常使用造成损坏, 例如: 跌落、碰撞、挤压、火烧、水浸、接触腐蚀性物质等。
- 由于不可抗力因素 (如火灾、地震、雷击等) 而造成故障或损坏。
- 未按照说明书或操作手册中的要求使用而造成损坏的。
- 产品自然损坏 (如摔坏)。

### 产品信息

材料名称	印刷	塑料	皮革	橡胶	金属材料	其他材料
	符合	符合	符合	符合	符合	符合
塑料	X	O	O	O	O	O
皮革	X	O	O	O	O	O
橡胶	X	O	O	O	O	O
金属材料	X	O	O	O	O	O

### 产品中有害物质的名称及含量

材料名称	印刷	塑料	皮革	橡胶	金属材料	其他材料
	符合	符合	符合	符合	符合	符合
塑料	X	O	O	O	O	O
皮革	X	O	O	O	O	O
橡胶	X	O	O	O	O	O
金属材料	X	O	O	O	O	O

### Touch Controls Guide

Function	Left LED	Right LED	Charging Case
Previous Track	***	/	/
Next Track	/	***	/
Volume +	/	+	/
Volume -	/	-	/
Play/Pause	**	**	/
Answer/Hang Up	**	**	/
Game Mode	***	***	/
Active Noise Assistant	***	***	/
Music Cancelling Mode	***	***	/
Switch Light Color	/	/	+

### 故障排除

Q: Unsuccessful pairing with a computer?  
 A: Please ensure that the computer has Bluetooth functionality. If not, you may need to acquire a Bluetooth adapter.

Q: Only one earbud has sound?  
 A: The pairing of the earbuds may not be successful. Please try to clear the Bluetooth pairing information and reconnect.

**Precautions**

- Never disassemble or modify your earbuds for any reasons to avoid any damages and danger.
- Do not keep the earbuds in extreme temperatures (under 0°C or over 45°C).
- Avoid using the indicator close to the eyes of children or animals.
- Do not use the earbuds during a thunderstorm to avoid dysfunction and increasing risk of electrocution.
- Do not use any harsh chemicals or strong detergents to clean the earbuds. Keep them dry.
- Wash out for any sharp edges, uneven metal surfaces, metal parts, accessories, and packages to avoid any potential damage.

### Statement

We provide customer service only for products purchased directly from [ROSELINK (Rose Technics)] or [ROSELINK (Rose Technics)] authorized distributors. If you have purchased from a different seller, please contact that for any exchange or refund request.

Thank you for purchasing authentic ROSELINK (Rose Technics) products. For any assistance, please contact us freely.

**\* FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
 — Reorient or relocate the receiving antenna.  
 — Increase the separation between the equipment and receiver.  
 — Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
 — Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause unintended operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## "EXPLORER"

### 蓝牙耳机

蓝牙耳机: 蓝牙耳机出厂设置后, 首次开机耳机将进入配对状态。

- 首次打开充电盒, 取出耳机, 自动进入配对状态。
- 打开与耳机配对设备的蓝牙开关, 搜索耳机名称选择并配对连接。
- 耳机恢复出厂设置后, 首次开机耳机将进入配对状态。

### 恢复出厂设置

1. 将放入充电盒中, 保持充电盒盖子打开。长按充电盒背键 10-15s, 充电盒灯键将红白交替闪烁6次, 耳机灯光亮起, 即表示耳机出厂设置。

2. 恢复出厂设置完成后, 关闭充电盒盖, 重新打开进入配对模式。

### 功能使用

您可以通过使用手机下载“ROSELINK”APP, 获取更多功能并自定义耳机设置。  
 - 在应用商店搜索“ROSELINK”APP搜索并下载安装。或扫描二维码下载。

### 首次配对

蓝牙耳机: 蓝牙耳机出厂设置后, 首次开机耳机将进入配对状态。

- 首次打开充电盒, 取出耳机, 自动进入配对状态。
- 打开与耳机配对设备的蓝牙开关, 搜索耳机名称选择并配对连接。
- 耳机恢复出厂设置后, 首次开机耳机将进入配对状态。

### 恢复出厂设置

1. 将放入充电盒中, 保持充电盒盖子打开。长按充电盒背键 10-15s, 充电盒灯键将红白交替闪烁6次, 耳机灯光亮起, 即表示耳机出厂设置。

2. 恢复出厂设置完成后, 关闭充电盒盖, 重新打开进入配对模式。

### 功能使用

您可以通过使用手机下载“ROSELINK”APP, 获取更多功能并自定义耳机设置。  
 - 在应用商店搜索“ROSELINK”APP搜索并下载安装。或扫描二维码下载。

### 首次配对

蓝牙耳机: 蓝牙耳机出厂设置后, 首次开机耳机将进入配对状态。

- 首次打开充电盒, 取出耳机, 自动进入配对状态。
- 打开与耳机配对设备的蓝牙开关, 搜索耳机名称选择并配对连接。
- 耳机恢复出厂设置后, 首次开机耳机将进入配对状态。

### 恢复出厂设置

1. 将放入充电盒中, 保持充电盒盖子打开。长按充电盒背键 10-15s, 充电盒灯键将红白交替闪烁6次, 耳机灯光亮起, 即表示耳机出厂设置。

2. 恢复出厂设置完成后, 关闭充电盒盖, 重新打开进入配对模式。

### 功能使用

您可以通过使用手机下载“ROSELINK”APP, 获取更多功能并自定义耳机设置。  
 - 在应用商店搜索“ROSELINK”APP搜索并下载安装。或扫描二维码下载。

### 首次配对

蓝牙耳机: 蓝牙耳机出厂设置后, 首次开机耳机将进入配对状态。

- 首次打开充电盒, 取出耳机, 自动进入配对状态。
- 打开与耳机配对设备的蓝牙开关, 搜索耳机名称选择并配对连接。
- 耳机恢复出厂设置后, 首次开机耳机将进入配对状态。

### 恢复出厂设置

1. 将放入充电盒中, 保持充电盒盖子打开。长按充电盒背键 10-15s, 充电盒灯键将红白交替闪烁6次, 耳机灯光亮起, 即表示耳机出厂设置。

2. 恢复出厂设置完成后, 关闭充电盒盖, 重新打开进入配对模式。

### 功能使用

您可以通过使用手机下载“ROSELINK”APP, 获取更多功能并自定义耳机设置。  
 - 在应用商店搜索“ROSELINK”APP搜索并下载安装。或扫描二维码下载。

### 首次配对

蓝牙耳机: 蓝牙耳机出厂设置后, 首次开机耳机将进入配对状态。

- 首次打开充电盒, 取出耳机, 自动进入配对状态。
- 打开与耳机配对设备的蓝牙开关, 搜索耳机名称选择并配对连接。
- 耳机恢复出厂设置后, 首次开机耳机将进入配对状态。

### 恢复出厂设置

1. 将放入充电盒中, 保持充电盒盖子打开。长按充电盒背键 10-15s, 充电盒灯键将红白交替闪烁6次, 耳机灯光亮起, 即表示耳机出厂设置。

2. 恢复出厂设置完成后, 关闭充电盒盖, 重新打开进入配对模式。

### 功能使用

您可以通过使用手机下载“ROSELINK”APP, 获取更多功能并自定义耳机设置。  
 - 在应用商店搜索“ROSELINK”APP搜索并下载安装。或扫描二维码下载。