



MINGS Mingshi CY-2001



OUTDOOR BLUETOOTH SPEAKER AMBIENT LIGHT USER MANUAL

ITEM DESCRIPTION



ITEM SPECIFICATION

Name: Outdoor Bluetooth Speaker Ambient Light
 Model No.: LCY-2001
 Battery Capacity: 3.7V/5200mAh
 Charging Voltage: 5VDC 2A
 Charging Time: 5-6 hours
 Duration: 6-8 hours
 LED Power: 3W
 Speaker Power: 5W

Driver Unit size: Diameter 50mm 5W
 Frequency Response: 150Hz-20KHz
 Impedance: 40Ω
 Connecting way: By Bluetooth
 Operating Temperature: 0-60 Degrees
 Item Weight: 830g
 Battery: Lithium battery
 Product Size: 120x130x250mm

FEATURES

- Bluetooth Connecting, Wireless Bondage.**
 Bluetooth V5.2+EDR version, More lower power-saving mode, leaving behind the traditional bondage of connectivity, enjoy unlimited music fun.
- Enhanced Bass, Powerful**
 2-inch full-range diaphragm speakers, music reproduction thoroughly, more clear and smooth performance.
- Candle Light, Romantic Atmosphere**
 Adjustable candlelight to create a romantic atmosphere, can also provide clear white light illumination, illuminating the environment around the ground; easy to observe.
- Lithium-ion Power Supply, Long Battery Life**
 Built-in high-capacity lithium polymer battery, to meet the all-day standby anytime, anywhere to enjoy the music.
- Power Indicator, Intuitive Operation**
 Blue LED power indicator is convenient for Bluetooth connection // Red and green dual indicator is convenient for lithium battery charging management.

INSTRUCTIONS

Bluetooth Connection

Step 1: Bluetooth Connection
 1. Press the power button to turn on the device. Long press the power button for 3 seconds, the power symbol shows blue light, there will be voice prompts: do, come, mimi, hair, prompting the power on. Bluetooth symbol at the blue light flashing refined, that the speaker has been Bluetooth search status.

Step 2: Start The Bluetooth Function
 Enter the "Settings" of the device that needs to be connected to the Bluetooth speaker, look for the "Wireless and Network" related section, find the "Bluetooth" option, click on "Bluetooth" to start the Bluetooth function. Bluetooth" to start the Bluetooth function.

Step 3: Search For Bluetooth Devices
 Enter the "Bluetooth Settings" option, executes the "Scan for Bluetooth devices" command. When the scanning is completed, the name of the searched Bluetooth device will be displayed in "Bluetooth Devices".

Step 4: Match And Confirm Connection
 When "IT22" appears in the Bluetooth device list of the connected device, it means the Bluetooth speaker has been found. Please click on the Bluetooth device "IT22", a few seconds after the device will be automatically paired successfully, the speaker will send out a "ding dong" sound prompts "Bluetooth connection successful" voice prompts. At this time, the bluetooth stops flashing, the speaker to work. General state to see the Bluetooth device search connection takes a few seconds, depending on the specific circumstances of the cell phone brand and Bluetooth program. (Some devices require input device matching value "1234", or "0000", to pairing success.)

Step 5: Connection Completed
 At this time, the user through the audio source device playback software to play audio files. LCY2001 Bluetooth digital speakers will show the best side of the music.

Long press the power button for 3 seconds, there is a beep sound hair, microphone, to, do and blue light off, the speaker off.

Music Controls

Previous Song Button

Short press "⏮" to play the previous song/long press >0.5 sec. to decrease the volume

Pause/Play Button

Short press "⏸" to play pause / long press > 0.5 sec mode switching

Next key

Short press "⏭" to play the next song/long press >0.5 seconds volume incremental

Warm tips: Bluetooth connection status, users can control the music playback through the audio device or speaker button, more simple and convenient.

Light Adjustment

Step 1: Turn on the light

Turn the knob to the right, after the ding sound, the light will turn on, and the light yellow light will become brighter slowly until all the light is white.

Step 2: light off

Turn the knob to the left, the light will be dimmed until the ding sound is over, then turn off the switch.

CHARGING USE

1. The use of randomly attached USB cable for lithium battery charging, MICRO USB cable end connected to the speaker "DC5V" slot, USB end connected to the computer corresponding slot can be lithium battery charging.

2. After the charging starts, the power indicator light will show red, indicating that the charging work is normal. When charging is full, it will show green light.

USB TYPE-C charging port. Use a USB power supply that can supply power at DC 5V,1A. If you use a power adapter to supply power, you should purchase an adapter that has obtained 3C certification and meets the standard requirements.

PRECAUTIONS

1. Read and understand all safety guidelines.
2. Obey all warning and guideline information labeled on the product.
3. Please use a charging device that can provide an output DC voltage of 5V/1A to avoid damage to the device.
4. Products with built-in lithium polymer battery, when not in use, please turn off the power.
5. Do not let the product suffer from rain, moisture, dripping or splashing any liquid.
6. Do not let the product near the high temperature heat source, not high temperature baking or blow-drying
7. Do not let the product dropped or hit, or apply heavy pressure on it.

TROUBLESHOOTING

- **Power on and off automatically:** Battery power is insufficient, please charge it and use it.
- **Playing automatically shut down or restart:** the battery is insufficient to cause low voltage can not play, please charge and then use.
- **No sound from speakers:** check if the volume is on; long press the next song button to increase the volume.
- **No function or wrong function of buttons:** Turn off the phone and restart it.
- **Unable to connect Bluetooth function:** firstly, make sure whether to open the Bluetooth function, secondly, there is no Bluetooth device searching, and finally, make sure whether the Bluetooth device is enabled by normal connection.

WARM TIPS

Please charge the lithium battery for 6 hours for the first time use, and 3 hours for usual charging.

It is recommended to use 5V/1A USB charging plug to charge the lithium battery. Charge the lithium battery at least once a month to prevent over-discharge and reduce the battery life.

Lithium batteries that are not used for a long period of time will become dormant and require a longer charging time to activate them. Before activating the lithium battery, it is normal for the machine to be unable to turn on normally due to low voltage, or the sound performance is unstable.

Warranty With This Card Please Keep

WARRANTY CARD

User's File		Day	Month	Year
User's Name	Sex	Age		
Correspondence Address				
Phone Number	Zip code			
Purchase Location				
Reason for Failure				

Warranty Terms

- This promise is only for the normal use of the case of failure, all parts must be purchased for the standard parts of the product and within the warranty period. The following conditions will not be exchanged or warranted.
- Wear and tear on the exterior of the product.

Non-standard parts for purchased products.

- Standard parts of the purchased product that have exceeded the warranty period.
- Damage to or malfunction of standard parts of the product caused by the use of non-approved expansion parts or peripheral equipment.
- Damage or malfunction caused by abnormal reasons (including foreign objects entering the equipment due to poor power supply environment, transportation, movement, bumping, etc.).
- All earthquakes, fires and other natural disasters or accidents (theft, loss) and other force majeure caused by the equipment can not work properly.
- Product failure caused by unauthorized operation: self disassembly, repair, installation or modification.
- No product warranty card and valid proof of purchase.

PACKING LIST

The box includes the following items, if missing, please contact the seller:

- Outdoor Bluetooth Speaker Ambient Light:1
- USB Cable:1
- Instruction Manual:1 Book

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.