

Apple system

1. Turn on the device

Press and hold the button for 5 seconds, the device will beep and turn on.

2. Pair the device

- Open the Find My app.
- Hold the device close to your iPhone, tap the Items tab, tap + and then Add Other Item.
- Tap Connect.
- Type a name for your device, select an emoji.
- Tap Agree to acknowledge that this item will be linked to your Apple ID.
- Tap Finish.

3. Enable Lost Mode

- Open the Find My app, tap the Items tab, then tap your item.
- Under Lost Mode, tap Enable.
- Read the instructions, tap Continue and enter a phone number or email address.
- Confirm the information, customize the lost message, and tap Activate to complete the setup.

4. Remove the device

- Open the Find My app, tap the Items tab, then tap your item.
- Tap Remove Item and then tap Remove to complete the operation.

Note: After removing the device in the app, the device will beep and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state, and the device and app cannot be paired at this time. If you need to pair the device, you need to click the device button once, the device will ring and the light will flash once. At this point, the device enters the pairing state and can be re-paired with the app.

- Open the Find My app, tap the Items tab, then tap your item.
- Under Lost Mode, tap Enable.
- Read the instructions, tap Continue and enter a phone number or email address.
- Confirm the information, customize the lost message, and tap Activate to complete the setup.

Apple-System

- Einschalten: Klicken Sie den Drücke 5 Sekunde, um den Schlüsselfinder sich einzuschalten und dann das Gerät piept.
- Öffnen Sie die „Wo ist? “ App mit dem iOS-System.
- Klicken Sie: Objekte.
- Klicken Sie: Objekte hinzuzufügen.
- Klicken Sie: Anderes unterstütztes Objekt.
- Klicken Sie: Das Gerät mit der Wörter **F11XD**.
- Umbenennen Sie das Gerät, wählen Sie ein Bild und schließen Sie die Kopplung ab.
- Aktivieren Sie den Modus "Verloren" und geben Sie die Telefonnummer ein. Dann funktioniert das Find My-Netzwerk.
- Sie können das Gerät benutzen.
- Gerät Entfernen: Um das Gerät in der App zu entfernen, können Sie Element entfernen auswählen. Hinweis: Nach dem Entfernen des Geräts in der App piept das Gerät und das Licht blinkt sechsmal, es wird nicht heruntergefahren und befindet sich im Kopplungsmodus. Wenn innerhalb von 10 Minuten keine erneute Kopplung erfolgt, verlässt das Gerät den Kopplungsstatus. Wenn Sie ein Gerät zu

diesem Zeitpunkt koppeln möchten, müssen Sie einmal auf die Gerätetaste klicken, das Gerät piept und die Leuchte blinkt einmal. Zu diesem Zeitpunkt wechselt das Gerät in den Kopplungszustand und kann erneut mit der App gekoppelt werden.

Android system

1 Download Findthing App

Search for "Findthing" on the Google play, or scan the below QR code to download the Findthing App.



2 Sign up

Open Findthing App, and sign up.

3 Turn on Bluetooth and Location service

Note: Please do not pair the device in the phone's Bluetooth list, otherwise, the device will not be connected to the App.

4 Pair the device

Tap the "+" button in Findthing App, and pair the device.

5 Ring the device

6 Attach the device to the things you care about

* More introductions and FAQ please refer to the 'help' section in Findthing App.

Android-System

1 Findthing App herunterladen

Suchen Sie im Google Play nach "Findthing" oder scannen Sie den folgenden QR-Code, um die Findthing App herunterzuladen.



2 Melden Sie sich an

Öffnen Sie die Findthing App und melden Sie sich an.

3 Schalten Sie den Bluetooth- und Standortdienst ein

Hinweis: Bitte koppeln Sie das Gerät nicht über die Bluetooth-Liste des Telefons. Andernfalls wird das Gerät nicht mit der App verbunden.

4 Koppeln Sie das Gerät

Tippen Sie in der Findthing App auf die Schaltfläche "+" und koppeln Sie das Gerät.

5 Rufen Sie das Gerät

Tippen Sie in der App auf Anrufen. Das Gerät wird piepen.

Legal notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Watch, iPad, iPadOS, iPod touch, Mac, macOS, and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Instructions for device button

1. Power on

After installing the battery, long press the button for five seconds, the device will beep, the light will flash three times, and the device will be turned on.

2. Device status confirmation

Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.

3. The device enters the pairing state again

After removing the device in the app, the device will beep and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state. If you want to pair a device at this time, you need to click the device button once, the device will beep, and the light will flash once. At this time, the device enters the pairing state and can be paired with the app again.

6 **Schließen Sie das Gerät an die Dinge an, die Ihnen wichtig sind**

4. Factory Reset

First, remove the item from Find My app then, after the device is powered on, double-click the device button. The device will beep. Long press the device button for eight seconds until the device beeps and the light flashes three times. Release the button to complete factory reset. The device can now be paired.

5. Power off

When the device is on, press the device button 5 times in 2 seconds. The device will beep, the light will flash three times, the device will be powered off.

FAQ:

1. When can the device be located?

When an item is separated from its owner for a period of time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the location of the device.

2. How to confirm whether the device has been turned on?


Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.

3.How is my privacy protected?


Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. So not even Apple or **hustala** knows the location of your device or the identity of the device that helps find it.

4. How to replace the battery:

- Open the device from the notch side.
- Replace the battery with a new one. (Positive pole upward).
- Assemble the device and long press the button for 5 seconds to restart it.



Product overview



Hinweise zur Verwendung der Drücke

1. Einschalten: Einsetzen Sie Akkus und klicken den Drück 5 Sekunden dann das Gerät piept und das Licht dreimal blinkt. Es wir erzeugt, dass dasn Gerät schon eingeschaltet wird.

2. Status Hinweise: Doppelklicken Sie auf die Gerätedrück, das Gerät piept und die Leuchte blinkt dreimal , in diesem Situation funktioniert das Gerät . Wenn das Gerät nicht klingelt, ist das Gerät ausgeschaltet. Drücken Sie den Drücke fünf Sekunden , um das Gerät einzuschalten.













3. Das Gerät wechselt wieder in den Pairing-Zustand: Nach dem Entfernen des Geräts in der App piept das Gerät und das Licht blinkt sechsmal, es wird nicht heruntergefahren und befindet sich im Kopplungsmodus. Wenn 10 Minuten lang keine erneute Kopplung erfolgt, verlässt das Gerät den Kopplungsstatus und das Gerät und die App können zu diesem Zeitpunkt nicht gekoppelt werden. Wenn Sie das Gerät koppeln müssen, müssen Sie einmal auf die Gerätetaste klicken, das Gerät klingelt und

das Licht blinkt einmal. An diesem Punkt wechselt das Gerät in den Kopplungszustand und kann erneut mit der App gekoppelt werden.

4.Zurücksetzen auf die Werkseinstellungen: Nach dem Löschen des Geräts in der „Wo ist? “ App. Nachdem das Gerät eingeschaltet wurde, doppelklicken Sie auf die Gerätedrücke und das Gerät piept und das Licht blinkt, und drücken Sie dann 8 Sekunden die Gerätedrücke, bis das Gerät piepst und das Licht dreimal blinkt. Lassen Sie die Taste los. Das Zurücksetzen auf die Werkseinstellungen ist abgeschlossen. Mit der „Wo ist? “ App neu koppeln.

5. Ausschalten: Wenn das Gerät eingeschaltet ist, drücken Sie die Gerätetas hintereinander innerhalb von 2 Sekunden, das Gerät gibt einen Aufforderungston aus und die Anzeigelampe blinkt dreimal und das Gerät wechselt in den Abschaltzustand.

Regulatory Safety Information

	WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.	Safety Statement
	If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poison Information Centre for fast expert advice.	
	KEEP BATTERIES OUT OF REACH OF CHILDREN	
	*Keep in original package until ready to use	
	*Call a local poison control center for treatment information. Australia: 13 11 26 Canada: 1-800-268-6017(Ontario), 1-800-567-6911(B.C.), 1-800-463-5060 (Quebec) US: 800-498-8666.Verify suitable, emergency call numbers for your country.	
	*Do not use if the compartment is not secure.	
	*Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous.	
	*Risk of fire and burns.	
	*Do not recharge, disassemble, heat (-20°C +70°C)or incinerate.	
	European Union-Disposal Information The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.	
		Article 12 Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.
		Article 14 The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations. The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.



FAQ:

1. Wie kann das Gerät durch ein anderen iPhone gefunden werden? Wenn das Gerät für etwa 15 Minuten vom iPhone des Besitzers getrennt ist, kann das Gerät von anderen iPhones gefunden werden, und der Eigentümer kann beginnen, den Standort des Geräts abzurufen.

2.Wie überprüfen, ob das Gerät eingeschaltet wurde? Doppelklicken Sie auf die Gerätedrück, das Gerät piept und die Leuchte blinkt dreimal und es wird angezeigt, dass das Gerät funktioniert. Wenn das Gerät nicht klingelt, ist das Gerät ausgeschaltet. Drücken Sie den Drücke fünf Sekunden, um das Gerät einzuschalten.

3. Wie die Batterie austauschen:
1) Hebeln Sie das Gehäuse am Griff an der Seite des Geräts auf.
2) Nehmen Sie die leere Batterie heraus und legen Sie eine neue Batterie (Standardbat-terie) mit dem Pluspol nach oben ein. Nachdem Sie die Hülle des Geräts installiert haben, Drücken Sie die Gerätedrücke 5

Sekunden,umdasGerat einzuschalten. Nachdem Sie die Hülle des Geräts installiert haben, Drücken Sie die Gerätedrücke 5 Sekunden,umdasGerat einzuschalten.

