WIRELESS SPEAKER USER MANUAL 201



Thank you for choosing our Wireless Speaker 201, Sincerely hope you will enjoy your music and phone call freely

Safety Instructions

Read this manual carefully before you use our Wireless Speaker and keep this manual for future reference.

- 1.Keep the device away from heat, direct sunlight and sharp edges.
- 2.Keep the device away from naked flames.
- 3.Do not insert any metal objects into the device in case of short circuit!
- 4.To avoid a static charge, please do not use the device in an extremely dry climate.
- 5.Do not repair the unit by yourself but contact an authorized specialist to help you.

Product overview





Accessories included 1 pc USB charging cable

Charging Integrated Battery

This Wireless speaker is powered support by integrated rechargeable Lithium Battery.

Charge the battery as follows:

- Insert the charging cable into the DC 5V socket on the unit. Connect the USB plug into a PC or AC / DC adapter. The LED indicator turns red and the battery is being charged.
- 2. When the battery is fully charged, the red LED indicator goes out.

Pairing ST-201 to Mobile phone or other device

Active the Wireless speaker pairing mode by button, the blue LED is flashing, means the speaker is ready for pairing.

Switch off the mobile phone buet ooth, the speaker will disconnected.

Tips:

Please make sure the speaker is in power on mode when you are trying to activate the pairing mode.

1.Turn on your mobile Phone and activate the bluet ooth function.

2.Search for bluet ooth devices, ST-201 will show up.

3.Pair your device with ST-201. If password is needed, type in "0000", after 201 is paired with your device, voice reminder says: bluet ooth connected, means the speaker had connected with your device.

Tips:

Once this speaker is paired and connected to your mobile phone, next time when you switch on this speaker, it will connect to your mobile phone automatically as long as the bluet ooth in your mobile phone is on.

Button description

On/Off:To switch on or off the device.

k
k
k
For the previous song,long press for turning down the volume.
k
N
Short press for the next songlong press for turning up the volume.

Phone:To pick up or hang up a phone call.

I Playlpause the music.

Notes &tips:

1.You can press Phone Button twice quickly to redial the last phone No. Call. Long press the Phone answering Button \bigcirc 3 seconds, disconnected from the connection between phone and bluet ooth speaker.

Troubleshooting:

Symptoms	Causes	Solutions
Can not switch the speaker on	Batery empty	Charge the baery
Unable to pair t he speaker	Speaker is already switched on, and it's not in pairing mode	Refer to he section of "Paring 201 to mobile phone or other device"
During working no sound suddenly	Battery out of charge	Charge the battry
Buttons can not work or strange sound ocurd suddenly	Product need to be reseted	Press the RESET button

Technical Specifications

bluet ooth support: 5.1

Maximum RF Range: 10 meters

Transmitting frequency: 2.4GHZ

Power supply: DC 5V/100-120mA
Battery: 3.7V 1200mA lithium
Charging time: Approx. 3-4 hours
Operating time: Approx. 12 hours
Unit weight: Approx. 137g

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.