

INSTRUCTIONS

Operation

Speaker automatically detects the external device to identify Bluetooth/AUX-IN mode. Inserting SD card automatically recognizes the player, SD card is priority over Bluetooth.

Button Instructions

- 1.**[POWER]**: press this button for 3 seconds to turn it on, press this button for 3 seconds again to turn it off. Press this button one time to play the music, press it again to pause.
- 2.**[-]**: Previous song/Volume down keep pressing the – button to adjust the volume down; short press this button to play the previous track
- 3.**[+]**: Next song/Volume keep pressing this button to adjust the volume up; short press this button, play the next track
- 4.**[M]**: press this button to switch between the functions: Bluetooth, AUX-IN, SD card.
- 5.**[LIGHT]**: press this button to turn on or off the light or switch between multiple color & light modes.
- 6.**[AUX-IN]**: AUX jack
- 7.**[TF]**: Insert SD card to play MP3 music

Connecting via Bluetooth

- 1.If the speaker is on and there is no AUX-IN or SD card, it will enter Bluetooth mode and the blue light will flash while Bluetooth is waiting for connection. Once connected, the blue light will flash 3 times, then remain on.
- 2.Turn on the Bluetooth function of mobile devices (cell phones, computers, etc.), search for Bluetooth devices, “Bandit Sports Speaker”, then you can complete device pairing.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.