







HM-20中性说明书

成品尺寸:50*70mm 80g双胶纸 风琴折

<p>Bluetooth headset TWS无线耳机</p>  <p>使用指南 User Guide</p>	<p>产品概述</p>  <p>开机/关机</p> <p>开机: 铲开充电盒子盖子两边耳机自动开机进入组对状态, 白灯快闪3次, (手动开机)长按MFB触摸键约2秒。</p> <p>关机: 耳机放入充电盒, 盖上盖子进入充电状态, 耳机自动关机断开连接, 蓝灯快闪3次, (手动关机)长按MFB键触摸约4秒。</p>	<p>配对方式</p> <p>1. 打开充电盒, 取出耳机, 耳机自动开机; 请将蓝牙耳机和手机(或其他的连接设备)的距离在50CM的范围内, 越近越好。</p>  <p>2. 打开手机蓝牙界面, 耳机开机, 耳机蓝白交替闪烁, 搜索对应的型号蓝牙耳机, 点击配对, 配对完成白灯快闪3次, 连接手机成功。</p>	<p>功能操作</p> <ul style="list-style-type: none">开机: 铲开充电盒子盖子, 两边耳机自动开机进入组对状态, 白灯快闪3次, (手动开机)长按MFB触摸键约2秒。关机: 耳机放入充电盒, 盖上盖子进入充电状态, 耳机自动关机并断开连接, 蓝灯快闪3次, (手动关机)长按MFB触摸键约4秒。配对方式: 关机状态下按MFB键约3秒, 进入配对模式, 手机可搜索对应的型号, 耳机配对完成后, 白灯快闪3次, 第二次使用耳机自动配对。接听/挂断电话: 任意单击左右MFB触摸键接听电话/通话中任意单击左右MFB触摸键挂断电话。拒接来电: 任意长按左右MFB触摸键约2秒。播放/暂停音乐: 任意单击左右MFB触摸键。上下曲: 双击左右MFB触摸键(下一曲), 双击R耳MFB触摸键(下一曲)。语音提示切换: 在配对模式三连击MFB键→切换语音。游戏模式/音乐模式: 连接状态下, 触摸MFB键3下进入游戏模式, 游戏模式状态下, 触摸MFB键3下切换为音乐模式。语音助手: 连接状态下长按MFB键约2秒松手→启动语音助手。	<p>注意</p> <ul style="list-style-type: none">针对可拆卸电池的产品, 电池务必回收或妥善处理, 针对不可拆卸电池的产品, 禁止拆解。如果长期期内不打算使用本产品, 请将它储存在干燥的环境中, 并每月至少为耳机充电一次以延长寿命, 避免极端的温度和灰尘。
--	---	--	---	---

<p>Bluetooth headset</p>  <p>User Guide</p>	<p>Product overview</p>  <p>Power on/off</p> <p>Power On: turn on the cover of the charging case on both sides of the earphones, it will automatically turn on and connect to each other, the white light will flash 3 times. (manual boot) touch the MFB button about 2 seconds.</p> <p>Power off: put the earphone into the charging case, cover the case, the earphone will turn off automatically when the earphone is charged, the indicator will flash blue light 3 times. (manual boot) touch the MFB button 4 seconds.</p>	<p>Headset Pairing</p> <p>1. Open the charging case, remove the earphones from the case, it will automatically keep the Bluetooth earphones and the phone (or other connected device) within 50cm. (as close as possible).</p>  <p>2. Turn on the Bluetooth interface of the phone, turn on the earphone, and the indicator lights of the earphones will flash the blue and white light. Search the pairing name and click to pairing, the indicator lights will flash 3 times when pairing successful, and the phone is successfully connected.</p>	<p>Function operation</p> <ul style="list-style-type: none">Power On: turn on the cover of the charging case on both sides of the earphones, it will automatically turn on and connect to each other, the white light will flash 3 times, (manual boot) touch the MFB button about 2 seconds.Power off: put the earphone into the charging case, cover the case, the earphone will turn off automatically when the earphone is charged, the indicator will flash blue light 3 times. (manual boot) touch the MFB button 4 seconds.Pairing: when the earphone is off, touch the MFB button about 4 seconds to turn it on, then enter pairing mode. The phone will search pairing name of the earphone, the indicator light will flash white light 3 times when pairing successful. The earphone will automatically pairing in next time.Answer / hang up the call: touch the left or right MFB button to answer the call, touch the left or right MFB button to hang up the call during calling.Reject calls: touch the left or right MFB button for 2 seconds.Play / pause music: touch the left or right MFB button to play / pause music.Previous / next track: Double touch the left MFB button to the previous track and double touch the right MFB touch button to next track.Voice prompt switching: triple touch the left or right MFB button to switch language in pairing mode.Game mode / music mode: triple touch the left or right MFB button to game mode, then triple touch the left or right MFB button from game mode to music mode.Voice Assistant: touch the MFB button for 2 seconds to activate the voice assistant.	<p>Specifications</p> <ul style="list-style-type: none">Battery capacity of headset: 70mAhBattery capacity of charging box: 450mAhOperating Range: ≥10mCharge Time: 1.5HCharging Port: Type-C <p>Matters needing attention</p> <ul style="list-style-type: none">Do not use corrosive cleaning agents to clean the product.Do not allow this product to heat or be near fire sources, such as cooking stoves.Do not expose this product to direct sunlight for a long time.Do not dispose of this product in fire to avoid explosion.Do not attempt to disassemble this product for any modification, as it does not contain any repairable components.Do not use this product in the rain.If you do not intend to use this product for a long time, please store it in a dry environment and monthly Charge your headphones at least once to extend their life and avoid extreme temperatures and dust. <p>Warning</p> <ul style="list-style-type: none">Batteries must be recycled or properly disposed when the product Batteries could removable. Do not disassemble the battery when the product Batteries could not removable.If the battery is not used properly, it may explode or leak, causing burns and other injuries. If the battery leaks, be careful and dispose of the battery immediately in accordance with local laws and regulations on battery handling.
---	---	---	--	---

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.