

### 规格与参数

充电电压: 5V	无线连接名称: BT
蓝牙方案: 蓝讯	充电电流: 200MA

### 使用方法说明

开关连接操作	开机:	长按3秒
	关机:	长按3秒
	配对中:	耳配对模式下自行配对
	配对成功:	安卓/iOS均可配对成功
	开机搜索最长时间:	5分钟无连接关机
	自动回连:	连接后关机再开机, 可自动回连
	模式切换:	长按开机键1S
	RGB灯开关:	双击V-键
	一拖二:	支持
	中英文切换:	未连接双击开机键
	取消配对:	手机端取消配对

### 规格与参数

充电电压: 5V	无线连接名称: BT
蓝牙方案: 蓝讯	充电电流: 200MA

### 使用方法说明

开关连接操作	开机:	长按3秒
	关机:	长按3秒
	配对中:	耳配对模式下自行配对
	配对成功:	安卓/iOS均可配对成功
	开机搜索最长时间:	5分钟无连接关机
	自动回连:	连接后关机再开机, 可自动回连
	模式切换:	长按开机键1S
	RGB灯开关:	双击V-键
	一拖二:	支持
	中英文切换:	未连接双击开机键
	取消配对:	手机端取消配对

音乐模式	上一曲:	单击V-	
	下一曲:	单击V+	
	音量加:	长按V+	
	音量减:	长按V-	
	召唤语音助手:	三击开机键/单击退出	
	3.5音频输入:	输入3.5音频关机	
电话模式	来电:	来电报号	
	接听电话:	单击电话键	
	来电拒接:	长按1秒电话键	
	挂断拒接:	单击电话键	
	未号重播:	双击电话键	
	播放/暂停:	单击播放键	
TF卡模式	上一曲:	单击V-	
	下一曲:	单击V+	
	音量加:	长按V+	
	音量减:	长按V-	
	FM模式	上一曲:	单击V-
		下一曲:	单击V+
音量加:		长按V+	
音量减:		长按V-	

音乐模式	上一曲:	单击V-	
	下一曲:	单击V+	
	音量加:	长按V+	
	音量减:	长按V-	
	召唤语音助手:	三击开机键/单击退出	
	3.5音频输入:	输入3.5音频关机	
电话模式	来电:	来电报号	
	接听电话:	单击电话键	
	来电拒接:	长按1秒电话键	
	挂断拒接:	单击电话键	
	未号重播:	双击电话键	
	播放/暂停:	单击播放键	
TF卡模式	上一曲:	单击V-	
	下一曲:	单击V+	
	音量加:	长按V+	
	音量减:	长按V-	
	FM模式	上一曲:	单击V-
		下一曲:	单击V+
音量加:		长按V+	
音量减:		长按V-	

### Specifications

Charging voltage: 5V	Wireless Connection Name: BT
Bluetooth scheme: Blue News	Charging current: 200MA

### Instructions

Switch connection operation	Boot:	Hold down for 3 seconds
	Shutdown:	Hold down for 3 seconds
	In the pairing:	Self-matching in ear matching mode
	Successful pairing:	Android/iOS can be paired successfully
	Maximum startup search time:	5 minutes no connection shutdown After connection, shut down and then
	Automatic link back:	turn on, can be automatically connected back
	Mode switch:	Hold down the power button for 1S
	RGB light switch:	Double click the V- key
	One drag two:	support
	Switch between Chinese and English:	Double-click the power button if it is not connected
	To cancel the pairing:	Cancel the pairing on the phone

### Specifications

Charging voltage: 5V	Wireless Connection Name: BT
Bluetooth scheme: Blue News	Charging current: 200MA

### Instructions

Switch connection operation	Boot:	Hold down for 3 seconds
	Shutdown:	Hold down for 3 seconds
	In the pairing:	Self-matching in ear matching mode
	Successful pairing:	Android/iOS can be paired successfully
	Maximum startup search time:	5 minutes no connection shutdown After connection, shut down and then
	Automatic link back:	turn on, can be automatically connected back
	Mode switch:	Hold down the power button for 1S
	RGB light switch:	Double click the V- key
	One drag two:	support
	Switch between Chinese and English:	Double-click the power button if it is not connected
	To cancel the pairing:	Cancel the pairing on the phone

### 规格与参数

充电电压: 5V	无线连接名称: BT
蓝牙方案: 蓝讯	充电电流: 200MA

### 使用方法说明

开关连接操作	开机:	长按3秒
	关机:	长按3秒
	配对中:	耳配对模式下自行配对
	配对成功:	安卓/IOS均可配对成功
	开机搜索最长时间:	5分钟无连接关机
	自动回连:	连接后关机再开机, 可自动回连
	模式切换:	长按开机键1S
	RGB灯开关:	双击V-键
	一拖二:	支持
	中英文切换:	未连接双击开机键
	取消配对:	手机端取消配对

音乐模式	上一曲:	单击V-
	下一曲:	单击V+
	音量加:	长按V+
	音量减:	长按V-
	召唤语音助手:	三击开机键/单击退出
	3.5音频输入:	输入3.5音频关机
电话模式	来电:	来电报号
	接听电话:	单击电话键
	来电拒接:	长按1秒电话键
	挂断拒接:	单击电话键
	未号重播:	双击电话键
	播放/暂停:	单击播放键
TF卡模式	上一曲:	单击V-
	下一曲:	单击V+
	音量加:	长按V+
	音量减:	长按V-
FM模式	上一曲:	单击V-
	下一曲:	单击V+
	音量加:	长按V+
	音量减:	长按V-

### Specifications

Charging voltage: 5V	Wireless Connection Name: BT
Bluetooth scheme: Blue News	Charging current: 200MA

### Instructions

Switch connection operation	Boot:	Hold down for 3 seconds
	Shutdown:	Hold down for 3 seconds
	In the pairing:	Self-matching in ear matching mode
	Successful pairing:	Android/IOS can be paired successfully
	Maximum startup search time:	5 minutes no connection shutdown after connection, shut down and then
	Automatic link back:	turn on, can be automatically connected back
	Mode switch:	Hold down the power button for 1S
	RGB light switch:	Double click the V- key
	One drag two:	support
	Switch between Chinese and English:	Double-click the power button if it is not connected
	To cancel the pairing:	Cancel the pairing on the phone

Music mode	Previous song:	Click V-
	Next song:	Click V+
	Volume Plus:	Press and hold V+
	Volume decrease:	Press and hold V-
	Call voice assistant:	Three clicks/click to exit
	3.5 Audio input:	Input 3.5 audio power off
Telephone mode	Incoming call:	Call number
	Answer the phone:	Click the phone key
	Call rejection:	Long press 1s Phone key
	Hang up reject:	Click the phone key
TF mode	Last replay:	Double-click the phone key
	On/Off:	Click play
	Previous song:	Click V-
	Next song:	Click V+
FM mode	Volume Plus:	Press and hold V+
	Volume decrease:	Press and hold V-
	Previous song:	Click V-
	Next song:	Click V+
FM mode	Volume Plus:	Press and hold V+
	Volume decrease:	Press and hold V-

### 注意事项

- 请不要使用暴力对待本产品, 也不要重物挤压, 远离高温高湿环境。
- 远离wifi路由器及其他高频发射设备, 这样会影响本机的信号接收, 造成声音的卡断及断连。
- 请在有效环境 (10米) 中使用本产品, 并且接收信号之间不要有实体阻挡 (例如墙)。
- Please do not use violence to treat this product, nor squeeze it with heavy objects, and keep away from high temperature and high humidity environment.
- Keep away from wifi routers and other high-frequency transmission equipment, which will affect the signal reception of the machine.Cause sound jamming and disconnection.
- Please use this product in an effective environment (10 meters), and do not have between receiving signals solid blocking (such as walls).

THANKS! 感谢您购买本产品

## 产品说明书 INSTRUCTIONS

使用前请仔细阅读本说明书

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in porlable exposure condition without restriction.