


Wireless Speaker User Manual



I. Buttons Operation

- ① "∧" Previous song under MP3 mode.
 - ② "||" Press: Play /Pause..
 - ③ "+" Increase volume.
 - ④ "∨" Next song under MP3 mode.
 - ⑤ Cancel the original sound in TF card mode.
 - ⑥ "-" Decrease volume.
 - ⑦ Mic Volume increase/decrease.
 - ⑧ Remix increase/decrease.
 - ⑨ Charging port.
 - ⑩ TF card port.
 - ⑪ Audio port.
 - ⑫ USB disk port.
- "⊕" Hold: ON/OFF, Press: Mode switching

II. Wireless Karaoke

1. Supply power: Hold "⊕" button to start the product.
2. Wireless connection: enable the wireless of mobile phone, click to connect, successful connection if prompt tone is produced.
3. Adjust sound: adjust the sound volume of micro and the reverberation to suitable level.
4. Start Karaoke

III Recording with mobile phone

1. Connect the recording wire: insert the MICRO plug of the recording wire into the MICRO interface of Karaoke Treasure, and the 3.5mm interface into the earphone jack of the mobile phone
2. Open the Karaoke software in the mobile phone. such as: Kugou Music or other recording Apps, select your favorable song, record the song according to the above mentioned singing method

3. Test and save the song: operate according to the instructions of Karaoke software.

Note: Recording cable must be purchased

Technical Parameters

Output Power: 3W

Frequency Range: 100HZ-10KHZ

Max Sound Pressure Level: >115DB 1KHZ TDH <1%

Reverberation Mode: sound effect reverberation

Power Supply: Built-in 18650 Li-battery

Battery Capacity: 600mAh

Charging Power: DC5V

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.