

Up to 14 Hours(VERIES BY VOLUME LEVEL AND AUDIO CONTENT)

Up to 39 ft(12M)

To extend battery life, fully charge at least once every 3 months. Battery life will vary according to usage patterns and environmental conditions.

Do not expose the SOWO product to liquids without removing all cable connections and closing the cap tightly. Do not expose the SOWO product

200mm(L)\*90mm(W)\*55mm(T)

DC 5 V 2A

500g

to water while charging. It may cause permanent damage to the speaker or product, and to the power source.

Music Playtime:

Dimension(W x D x H):

Charging:

Weight:

Wireless Transmission Distance: