



# User Manual



## ESC SOUNDS ENDURANCE



## HOW TO WEAR:

## GETTING STARTED:

### Charging:

The ESC Sounds Endurance contain a rechargeable Lithium-ion battery, which should be fully charged prior to first use of the product.

### Open Mode

Hear your

surroundings while

walking, running

and working

### Skip Track:

Press and hold the “-” for one second to skip back to the previous track.

### Swim (MP3) Mode:

Quickly press and release the Multifunction Button two times to alternate between Bluetooth and MP3 (Swim) mode.

### Play/Pause

When music is playing, press and quickly release the Multifunction Button once to pause the song and then repeat the action to resume playing.

### Basic Parameters

Bluetooth Version: 5.3

Bluetooth Distance: Up to 10 meters

Bluetooth Profile: A2DP/HFP/AVRCP

Music Formats Supported: MP3/WMA/M4A/APE/FLAC

### Power On:

Press down the Multifunction Button for three seconds until you hear an ascending tone to indicate the earbud has powered on.

### Latency Mode:

Quickly press and release the Multifunction Button four times to activate and deactivate Latency Mode.

### Power Off:

To decline an incoming call, press and hold down the Multifunction Button for 1 second.

### Decline Call:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Pairing to Device:

After powering on, the ESC Sounds Endurance will automatically open on your computer, via the USB Drive. Locate and select your MP3 music files on your computer, then simply drag and drop them in to the ESC Sounds Endurance folder. Then select the ESC Sounds Endurance from your computer, unplug the charging cable, and your MP3 files will be stored on your ESC Sounds Endurance.

### Volume Up and Down

Quickly press and release the “+” button to increase the volume and quickly press and release the “-” to decrease the volume.

### Guarantee

Your ESC Sounds Endurance are guaranteed for a period of 6 months from date of purchase.

### Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Product Disposal Instructions:

The symbol shown below on the product packaging means that the product is classified as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its working life. The waste of Electrical or Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the landfill.



### Product Disposal Instructions for Residential Users:

When you have no further use for it, please dispose of the product as per your local authority's recycling processes.

For more information, please contact your local authority.

### Product Disposal Instructions for Business Users:

Business users should contact their supplier and check the terms and conditions of the purchase contract and ensure that this product is not mixed with other commercial waste for disposal.