




### Internal Photos of the EUT




XM-3120, XM-3820S, XM-3920, XM-5020, XM-5220, XM-5320,  
XM-6020, XM-6220, XM-7220, XM-6220-WIF, XM-7320











ANT














XM-3120S-DP, XM-3120S-DP-H, XM-3320S-DP, XM-3120S-DP-WIFI,  
SQ-3120S-DP-WIFI





















ANT















XM-3820, XM-3120SZ, XM-3120SZ-H, XM-1920, XM-A120, XM-3120SZ-WIFI,  
SQ-3120SZ-WIFI, XM-3120SZ-H-WIF





ANT

