

1

2

3

4

5

6

修改区域

描述

日期

担当

1

XXXXXXXXXXXXXXXXXXXXXXXXXXXX

XXXXXXXX

XXXXXX

A

A



HOPESTAR -P72
便携式无线音箱

无线标准: 5.3
传输距离: 10米
输出功率: 30W
播放时间: 4~6小时
频率响应: 80Hz-20KHz
扬声器: 66mm 4D 15W*2
输入电源: 5V 1A
电池类型: 18650 锂离子电芯 4000mAh
音频信号输入接口: 标准 Ø3.5mm 耳机插孔(立体声)

特点:
1. 无线连接
2. 记忆功能, 断点续播
3. 支持U盘/ FM / TF / AUX 播放模式
4. 内置锂离子电池
5. 支持MP3音乐格式解码
6. 使用高品质扬声器, 发出声音更自然和细腻
7. 防水
8. 1+1 双声道功放
9. 支持收音功能

无线扬声器说明书

HOPESTAR

无线扬声器 - P72

技术规格:

无线标准: 5.3
传输距离: 10米
输出功率: 30W
播放时间: 4~6小时
频率响应: 80Hz-20KHz
扬声器: 66mm 4D 15W*2
输入电源: 5V 1A
电池类型: 18650 锂离子电芯 4000mAh
音频信号输入接口: 标准 Ø3.5mm 耳机插孔(立体声)

特点:


1. 无线连接
2. 记忆功能, 断点续播
3. 支持U盘/ FM / TF / AUX 播放模式
4. 内置锂离子电池
5. 支持MP3音乐格式解码
6. 使用高品质扬声器, 发出声音更自然和细腻
7. 防水
8. 1+1 双声道功放
9. 支持收音功能

无线扬声器 - P72

HOPESTAR

使用说明:

1. 按键“+”
单击: 音量增加
长按: 下一曲
2. 按键“-”
单击: 音量减少
长按: 上一曲
3. 开关机键
长按/开机 3秒/次
4. 灯光按钮
单击: 切换灯光模式
长按: 开/关灯
5. 暂停/播放键
单击: 播放/暂停
单击: 退出/返回蓝牙连接
长按: 退出/返回蓝牙连接
6. 系列键
单击: 串联/退出串联
长按: 切换功能
7. Type-C 接口
插入Type-C充电线时, 默认为设备充电
在收音机功能时, 将插入充电线 作为收音天线
8. TF插孔
插入TF卡时, 默认为TF卡播放模式
9. USB插孔
插入U盘时, 默认为USB播放模式
10. AUX插孔
标准 Ø3.5mm 耳机插孔, 插入时, 默认为AUX播放模式



P72 按键指示剖面图

无线扬声器 - P72

无线扬声器 - P72

使用说明:

1. 无线配对
1.1. 使用无线配对前, 请先打开音频电源, 它已经是默认的无线模式。
1.2. 打开无线设备, 搜索HOPESTAR-P72, 连接配对, 连接成功后, 开始播放音乐体验。
2. 适用于各种手机配件无线技术, 无线适配器, 无线播放器。
3. 音量指示
3.1. 开/关有语音提示音:
3.2. 音量增加时最大音量有语音提示, 最小音量无语音提示。
3.3. 当电量低时显示3次自动关机。
4. 一键切换
4.1. 单击默认进入无线模式。
模式切换顺序: 无线模式-FM模式-TF卡模式-U盘模式-AUX模式
4.2. 模式: 音质优秀。
5. TWS操作说明
在默认开/关时按下, 单击其中一个TWS按键, 听到“嘟”的一声进入TWS搜索, 当TWS连接成功, 请连接指示灯亮, 主耳机指示灯亮, 耳机长亮。
6. 播放指示灯
无线播放状态: 白灯闪烁, 约0.5秒/次;
无线配对状态: 白灯常亮
待机状态: 白灯闪烁约1秒/次;
7. 充电指示灯
充电时红灯亮 充电完成灯灭
8. 音量
开机默认音量70%音量。

无线扬声器 - P72

无线扬声器 - P72

产品保修

用户名: _____
联系电话: _____
购买日期: _____
产品编号: _____
维护故障: _____

注意: 产品保修期为6个月

正面

B

B

HOPESTAR -P72
Portable Wireless Speaker



无线标准: 5.3
传输距离: 10 meters
输出功率:30W
播放时间: 4~6 hours
Frequency effect: 80Hz-20KHz
Speaker: 66mm 4D 15W*2
Input power: 5V 1A
Battery type: 18650 lithium ion battery 4000mAh
Audio signal input interface: standard Ø3.5mm headphone jack (stereo)

Features:

1. Wireless connection
2. Memory function, breakpoint resuming
3. Support U disk / FM / TF card / AUX playback mode
4. Built-in lithium ion battery
5. Support Mp3 music format decoding
6. Using high-fidelity speakers, the sound is more natural and delicate
7. Level 5 waterproof
8. 1+1 device serial connection function
9. Support FM radio function

WIRELESS SPEAKER INSTRUCTIONS

HOPESTAR

Wireless speaker - P72

Technical Specifications:

无线标准: 5.3
传输距离: 10 meters
输出功率:30W
播放时间: 4~6 hours
Frequency effect: 80Hz-20KHz
Speaker: 66mm 4D 15W*2
Input power: 5V 1A
Battery type: 18650 lithium ion battery 4000mAh
Audio signal input interface: standard Ø3.5mm headphone jack (stereo)

Features:


1. Wireless connection
2. Memory function, breakpoint resuming
3. Support U disk / FM / TF card / AUX playback mode
4. Built-in lithium ion battery
5. Support Mp3 music format decoding
6. Using high-fidelity speakers, the sound is more natural and delicate
7. Level 5 waterproof
8. 1+1 device serial connection function
9. Support FM radio function

Wireless speaker - P72

HOPESTAR

Button instruction:

1. Press the “+” button
Click: Volume Up
Long press: Next song
2. Press the “-” button
Click: Volume decrease
Long press: Previous track
3. On/Off button
Long press: on/off for about 3 seconds per time
4. Light button
Click: Current Light Mode/Long press: turn on/off lights
5. Pause/Play key
Click: Play/Pause
Long press: Exit/Reconnect to Bluetooth connection
Double click in wireless mode to make a callback call;
Click: Answer/hang up
Press and hold for 2 seconds during an incoming call to reject the call.
Click: Make in radio mode, long press: Retreat
6. Series key
Click: Series/Exit Series/Long press: Switch functions.
7. Type-C jack
1. Charging cable interface, when inserting Type-C charging cable, defaults to device charging
2. When using the radio function, it is necessary to insert a charging cable as the radio antenna. The radio function is necessary for normal use.
8. TF jack
When inserting a TF card, default to TF card playback mode
9. USB jack
When inserting a USB drive, it defaults to USB playback mode
10. AUX jack
Standard Ø 3.5mm headphone jack, defaults to AUX playback mode when inserted



P72 button indication section view

Wireless speaker - P72

Wireless speaker - P72

Directions for use:

1. Wireless pairing
1.1. Before using wireless pairing, first turn on the audio power. If it is already the default wireless model.
1.2. Turn on the wireless device, search for HOPESTAR-P72, connect and pair connect. After successful, start playing music experience.
2. Suitable for various mobile phone accessories wireless technology, wireless adapter, wireless player.
3. Voice prompt
3.1. There is a voice prompt when turning on/off.
3.2. When the volume is increased to the maximum volume, there will be a voice prompt, and the minimum volume will not have a voice prompt.
3.3. Automatically shut down after detecting low battery three times.
4. Mode switching
4.1. Enter wireless mode by default when power on.
4.2. Mode: Push-rotation priority.
5. TWS operating instructions
Open any two speakers at the same time, click one of the TWS serial keys. When you hear the beep to enter TWS search, when TWS connection is successful, the connection prompt sounds, the host indicator flashes, and the copilot lights up.
6. Play indicator
Wireless search status: white light flashing fast, about 0.5 seconds/time.
Wireless pairing status: White light is always on
Playback status: White light flashes slowly for about 1 second/time.
7. Charging indicator
The red light is on when charging, and the red light is off when fully charged.
8. Volume
Turn on the default speaker volume at 70%.

Wireless speaker - P72

Wireless speaker - P72

Product warranty

Username: _____
Contact number: _____
Date of purchase: _____
Product number: _____
Maintenance failure: _____

Note: The product warranty is 6 months

反面

C

C

D

D

HOPESTAR P72说明书
成品尺寸: 122.5x70mm
材质工艺: 128g双铜, 单张双面四色印刷, 风琴折

HOPESTAR

订单编号:

料号:

文件编号:

设计: Zep 2024-01-28

业务:

电子:

结构:

名称: P72 中性 说明书

审核:

核准:

页次: 1/1

版次: 1.0

1

2

3

4

5

6

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.