

Ipapencil

S1-2520-PG

Button & Indicator light

Type-C Charging port

Built-in Battery

Replaceable nib

User Manual

Please carefully use this user manual before using and keep it well for future using.

Compatible with 2018-2024 iPad

| | |
|----------------------------------|-------------------------|
| IPad Pro 11 inch 1. Gen - 2018 | A1986/A2013/A1934/A1979 |
| IPad Pro 11 inch 2. Gen - 2020 | A2228/A2068/A2230/A2231 |
| IPad Pro 11 inch 3. Gen - 2021 | A2377/A2459/A2461/A2460 |
| IPad Pro 11 inch 4. Gen - 2022 | A2759/A2435/A2761/A2762 |
| IPad Pro 12.9 inch 3. Gen - 2018 | A1876/A2014/A1885/A1983 |
| IPad Pro 12.9 inch 4. Gen - 2020 | A2229/A2069/A2232/A2233 |
| IPad Pro 12.9 inch 5. Gen - 2021 | A2378/A2461/A2379/A2462 |
| IPad Pro 12.9 inch 6. Gen - 2022 | A2436/A2764/A2437/A2766 |
| IPad Air 10.5 inch 3. Gen - 2019 | A2152/A2123/A2153/A2154 |
| IPad Air 10.5 inch 4. Gen - 2020 | A2316/A2324/A2325/A2072 |
| IPad Air 10.5 inch 5. Gen - 2022 | A2589/A2591 |
| IPad Mini 7.9 inch 5. Gen - 2019 | A2133/A2124/A2126/A2125 |
| IPad Mini 8.3 inch 5. Gen - 2021 | A2587/A2569/A2569 |
| IPad 9.7 inch 8. Gen - 2018 | A1889/A1554 |
| IPad 10.2 inch 7. Gen - 2019 | A2197/A2209/A2198 |
| IPad 10.2 inch 8. Gen - 2020 | A2270/A2428/A2429/A2430 |
| IPad 10.2 inch 9. Gen - 2021 | A2602/A2804/A2603/A2605 |
| IPad 10.9 inch 10. Gen - 2022 | A2656/A2751/A2771 |
| IPad Air M2 11 inch - 2024 | A2802/A2803/A2804 |
| IPad Air M2 13 inch - 2024 | A2888/A2889/A2890 |
| IPad Pro M4 11 inch - 2024 | A2888/A2887/A3008 |
| IPad Pro M4 13 inch - 2024 | A2888/A2888/A3007 |

Not compatible with 2017 and earlier iPads

| | |
|---------------------------------------------|----------------------------------------------------------------------------------------|
| IPad (1.-5. Gen) - 2010-2017 | A1219/A1337/A1396/A1395 A1387/A1416/A1430/A1403 A1458/A1459/A1460/A1822 A1823 |
| IPad Mini (1.-4. Gen) - 2012-2015 | A1483/A1454/A1455/A1448 A1490/A1491/A1599/A1600 A1538/A1550 |
| IPad Air (1.-3. Gen) - 2013-2014 | A1474/A1475/A1476/A1566 A1567 |
| IPad Pro 9.7 inch - 2016 | A1673/A1674/A1675/A1701 |
| IPad Pro 10.5 inch - 2017 | A1708/A1821/A1544/A1653 |
| IPad Pro 12.9 inch (1.-3. Gen) - 2015-2017* | A1670/A1671/A1821 |

Other: iPhone, Samsung, Huawei, Microsoft, Surface, Lenovo, Acer, Dell, Xiaomi, other brands

Bluetooth

After linking the Bluetooth

- One-Click: Open multitasking
- Double-click: Back to home page
- View real-time pencil battery leave.

turn on iPad pen > bluetooth
Bluetooth name: LPUNCD Pencil

How to add widget to show battery level on iPad?

Screen swipe right from left side > Edit > + > Battery > Add widgets

Instructions for use

1. The iPad version is no less than 12.2.

2. Open the settings memo-close apple per Graffiti function.

3. Turn on settings Bluetooth and turn off the connection of the original apple pen. (after setting above, you can use the product normally.)

*Go to Settings > Apple pencil > Close Only Draw with Apple Pencil

1. Do not expose the product to places accessible to children to prevent misuse or injury.

2. Please do not dispose of the used products, but send them to the designated recycling station or contact the after-sales service for recycling.

Function

Press the pen switch for 2 seconds, the indicator light will be light on quickly, when you press again, the indicator light will be shut off. The stylus pen standby for 20 mins then will be automatically shut off.

Button Indicator Light

Use the USB-C cable for charging. Connect the end to the pen connector and the other end to a computer, adapter, or other device.

Removable nib for easy replacement. No need to worry about wear and tear! (Simply twist the tip for easy removal/installation).

Instructions for use

Tilt Sensitivity

You can change the size of the brush by changing the tilt angle of the pen on the iPad. Please note that not all brush types are tilt-sensitive (e.g. the fountain pen tool). If you have any question during use, please feel free to contact us.

*No pressure sensitivity

Magnetic design

Our iPad pen can be magnetically attached to the iPad, making it very easy to carry.

*Doesn't support magnetic charging

Palm Rejection

With the palm rejection, you can naturally rest your palm on the iPad when drawing and writing without accidentally operating it.

Charging Indication

Green light: in using / full charged
Red light: in charging / low power

Product Specification

| | |
|----------------------|-----------------------------------------------|
| Product Name | ipad pencil (bluetooth style) |
| Main Functions | Drawing, Writing, Taking Notes, Teaching |
| Materials | Aluminum alloy pen body (POM plastic pen nib) |
| Measurement | 9.9mm pen body and 1.5mm pen nib |
| Using Hours | 18 hours |
| Charging Time | 15min |
| Sleeping Protect | 20 Mins do not using Pencil will turn off |
| Product Colors | Multi-colour |
| Standard Accessories | USB-C to USB-C charging cable |
| Package | Charging Cable, User Manual |

Common Faults & Solutions

| Faults | Solutions |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Lag, Delay | 1. Check that the nib is fitted properly and try again. 2. Replace the nib with another one and try again. 3. Check that the steel screen protector is not badly damaged or too thick. 4. Restart iPad and try again. |
| Cannot write | 1. Check that the pen is turned on. 2. Check that the pen is compatible with the iPad. 3. Check that the app supports the writing function. 4. Check that the iPad is connected to the original pencil. If so, disconnect it. |
| Won't turn on | 1. Check that the pen is powered off. 2. Use the pen in accordance with the user manual. |

Made in China

Ipapencil

S1-2520-PG

Taste & Anzeigeleuchte

Type-C Ladenanschluss

Eingebaute Batterie

Austauschbare Spitze

Benutzerhandbuch

Bitte lesen Sie dieses Benutzerhandbuch vor dem Gebrauch sorgfältig durch und bewahren Sie es für die spätere Verwendung gut auf.

Kompatibel mit 2018-2024 iPad

| | |
|----------------------------------|-------------------------|
| IPad Pro 11 inch 1. Gen - 2018 | A1986/A2013/A1934/A1979 |
| IPad Pro 11 inch 2. Gen - 2020 | A2228/A2068/A2230/A2231 |
| IPad Pro 11 inch 3. Gen - 2021 | A2377/A2459/A2461/A2460 |
| IPad Pro 11 inch 4. Gen - 2022 | A2759/A2435/A2761/A2762 |
| IPad Pro 12.9 inch 3. Gen - 2018 | A1876/A2014/A1885/A1983 |
| IPad Pro 12.9 inch 4. Gen - 2020 | A2229/A2069/A2232/A2233 |
| IPad Pro 12.9 inch 5. Gen - 2021 | A2378/A2461/A2379/A2462 |
| IPad Pro 12.9 inch 6. Gen - 2022 | A2436/A2764/A2437/A2766 |
| IPad Air 10.5 inch 3. Gen - 2019 | A2152/A2123/A2153/A2154 |
| IPad Air 10.5 inch 4. Gen - 2020 | A2316/A2324/A2325/A2072 |
| IPad Air 10.5 inch 5. Gen - 2022 | A2589/A2591 |
| IPad Mini 7.9 inch 5. Gen - 2019 | A2133/A2124/A2126/A2125 |
| IPad Mini 8.3 inch 5. Gen - 2021 | A2587/A2569/A2569 |
| IPad 9.7 inch 8. Gen - 2018 | A1889/A1554 |
| IPad 10.2 inch 7. Gen - 2019 | A2197/A2209/A2198 |
| IPad 10.2 inch 8. Gen - 2020 | A2270/A2428/A2429/A2430 |
| IPad 10.2 inch 9. Gen - 2021 | A2602/A2804/A2603/A2605 |
| IPad 10.9 inch 10. Gen - 2022 | A2656/A2751/A2771 |
| IPad Air M2 11 inch - 2024 | A2802/A2803/A2804 |
| IPad Air M2 13 inch - 2024 | A2888/A2889/A2890 |
| IPad Pro M4 11 inch - 2024 | A2888/A2887/A3008 |
| IPad Pro M4 13 inch - 2024 | A2888/A2888/A3007 |

Nicht kompatibel mit 2017 und früheren iPads

| | |
|---------------------------------------------|----------------------------------------------------------------------------------------|
| IPad (1.-5. Gen) - 2010-2017 | A1219/A1337/A1396/A1395 A1387/A1416/A1430/A1403 A1458/A1459/A1460/A1822 A1823 |
| IPad Mini (1.-4. Gen) - 2012-2015 | A1483/A1454/A1455/A1448 A1490/A1491/A1599/A1600 A1538/A1550 |
| IPad Air (1.-3. Gen) - 2013-2014 | A1474/A1475/A1476/A1566 A1567 |
| IPad Pro 9.7 inch - 2016 | A1673/A1674/A1675/A1701 |
| IPad Pro 10.5 inch - 2017 | A1708/A1821/A1544/A1653 |
| IPad Pro 12.9 inch (1.-3. Gen) - 2015-2017* | A1670/A1671/A1821 |

Other: iPhone, Samsung, Huawei, Microsoft, Surface, Lenovo, Acer, Dell, Xiaomi, other brands

Bluetooth

Nach dem Verbinden des Bluetooth

- Ein-Klick: Multitasking öffnen
- Doppel-Klick: Zurück zur Hauptseite
- Batteriestand des iPad-pencil auf dem iPad anzeigen

iPad Pencil einschalten > Bluetooth
Name des Bluetooth: LPUNCD Pencil

Wie fügt man ein Widget zur Anzeige des Batteriestands auf dem iPad hinzu?

Wischen Sie von der linken Seite des Bildschirms nach rechts > Editieren > + > Batterie > Widgets hinzufügen

Gebrauchsanweisung

1. Die iPad-Version ist nicht unter der Version 12.2.

2. Öffnen Sie die Einstellungen memo-close apple per Graffiti-Funktion.

3. Bluetooth öffnen und die ursprüngliche Apple Pencil-Verbindung deaktivieren. (nach der Einstellung oben, können Sie das Produkt normal verwenden.)

*Gehen Sie zu Einstellungen > Apple Pencil > Nur mit Apple Pencil zeichnen/schließen

1. Setzen Sie das Produkt nicht an Orten aus, die für Kinder zugänglich sind, um Missbrauch oder Verletzungen zu vermeiden.

2. Bitte entsorgen Sie die gebrauchten Produkte nicht sondern geben Sie sie an die dafür vorgesehene Recycling-Station ab oder wenden Sie sich an den Kundendienst für das Recycling.

Funktion

2 Sekunden lang auf den Stiftschalter drücken, die Anzeigeleuchte leuchtet schnell auf. Wenn erneut gedrückt wird, erlischt das Licht. iPad Stift hat einen Energiesparmodus. 20 Minuten der Nichtbenutzung automatisch abgeschaltet.

Taste & Anzeigeleuchte

Verwenden Sie das USB-C-Kabel zum Aufladen. Schließen ein Ende an den Stiftanschluss und das andere Ende an einen Computer, einen Adapter oder ein anderes Gerät.

Abnehmbare Feder für einfachen Austausch. Kein Grund zur Sorge über Verschleiß! (Drehen Sie einfach die Spitze, um sie leicht zu entfernen/einzubauen).

Hinweise zur Verwendung

Neigungsempfindlichkeit

Sie können die Größe des Pinsels ändern indem Sie den Neigungswinkel des Stifts auf dem iPad ändern. Bitte berücksichtigen Sie dass nicht alle Pinseltypen neigungsempfindlich sind (z. B. der Füllfederhalter Werkzeug). Wenn Sie während der Nutzung irgendeine Frage haben, können Sie uns gerne kontaktieren

*Keine Druckempfindlichkeit

Magnetisches Design

Unser iPad-Pencil kann magnetisch am iPad befestigt werden, wodurch er sehr leicht zu tragen ist.

* Unterstützt nicht magnetisches Laden

Handflächenabweisung

Mit der Handflächenabweisung können Sie Ihre Handfläche beim Zeichnen und Schreiben ganz natürlich auf das iPad legen, ohne es versehentlich zu bedienen.

Anzeige des Ladezustands

Grüne Lampe in Gebrauch/voll aufgeladen
Rote Lampe im Ladevorgang/schwache Batterie

Spezifikation des Produkts

| | |
|--------------------|-----------------------------------------------------------------|
| Name des Produkts | ipad pencil (bluetooth style) |
| Hauptfunktionen | Zeichnen, Schreiben, Notizen machen, Unterrichten |
| Materialien | Stiftgehäuse aus Aluminiumlegierung (Spitze aus POM-Kunststoff) |
| Maßung | 9,9 mm Stiftgehäuse und 1,5 mm Spitze |
| Betriebsdauer | 18 Stunden |
| Aufladezeit | 15 Minuten |
| Schlafen im Schlaf | Bei 20 Minuten Nichtbenutzung schaltet sich der Pencil aus |
| Produktfarben | Mehrfarben |
| Standard-Zubehör | USB-C-auf-USB-C-Ladekabel |
| Paket | Ladekabel, Benutzerhandbuch |

Häufige Fehler & Lösungen

| Fehler | Lösung |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Verzögerung/Rückstand | 1. Überprüfen Sie, ob die Spitze richtig eingesteckt ist und versuchen Sie es erneut. 2. Tauschen Sie die Spitze gegen eine andere aus und versuchen Sie es erneut. |
| Nicht schreiben können | 3. Überprüfen Sie, ob der Bildschirmenschutz aus Stahl nicht stark beschädigt oder zu dick ist. 4. Starten Sie das iPad erneut und versuchen Sie es erneut. |
| Nicht einschalten | 1. Überprüfen Sie, ob der Stift eingeschaltet ist. 2. Überprüfen Sie, ob der Stift mit dem iPad kompatibel ist. 3. Überprüfen Sie, ob die App die Schreibfunktion unterstützt. 4. Überprüfen Sie, ob das iPad mit dem Original-Stift verbunden ist. Wenn ja, trennen Sie es. |

In China hergestellt

FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- FCC RF Radiation Exposure Statement:
- 1.This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
 - 2.This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.
- This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.