


SUPERNOTE

Mode:A6 X2-W

Battery capacity: 2700mAh

input: 5.0 V $\overline{\text{---}}$ 2.0 A




IC: 32144-A6X2
HVIN: A6-X2



YU10674-23006
R-R-QNY-A6X2-W




FCC ID: 2BE5Y-A6-X2



株式会社社会成洋

Made in China
5 GHz band (W52): Indoor use only.



Activate your Supernote

- 1 Power on**
Long press the power button to power on your Supernote device.
- 2 Setup**
Follow the on-screen instructions to start your first note.

To view the complete User Guide, visit: support.supernote.com

Other items included: USB cable, screw driver

Check product certifications:

Settings > My device > Product Certification

