
材质:120G书写纸 折叠尺寸:96*96mm 风琴折



折叠后此面为封面

ATK

QUICK START



01 按键和配件说明 / Introduction / 紹介 / 소개

1 Type-C□ Type-C Port

Type-C インタフェース

Type-C 인터페이스

Scroll Wheel マウスホイール

마우스 휠

5 LED指示灯

6 前进侧键

7 后退侧键

LED Indicato

LED 표시등

前進側キー

전진 측면 키


Back Button

後退側キー

뒤로 측면 키

LEDインジケータ

Forward Button



8 脚贴区

Feet

フィート

9 光学传感器

光センサ 광학 센서

10 DPI切换键

DPI Button

DPIボタン

電源スイッチ

전원 스위치

DPI 버튼

11 无线开关 Power Switch

Optical Sensor

9

USER GUIDE

用户指南

烈空Z1 SERIES

빠른 시작 1. 充电/有线使用 Charge / Wired Mode 充電/有線モード 충전 / 유선 모드

02 快速开始 / Quick Start / クイックスタート



2. 无线使用 / Wireless Mode / ワイヤレスモード / 무선 모드





按击底部DPI切换键可以快速切换DPI, 免驱提供以下DPI档位和状态指示 / Press the DPI

03 DPI调节 / DPI Set / DPI設定 / DPI 튜닝

button to quickly switch the DPI. The free drive provides the following DPI set and status indications / DPIボタンを押すと、DPIをすばやく切り替えることができます。無償ド ライブには、以下のDPI設定とステータスインジケータが用意されています / DPI 버튼을 눌러 DPI를 빠르게 전환합니다.무료 드라이브는 다음과 같은 DPI 설정 및 상태 지침을 제공합니다



更多DPI设置需要使用驱动修改,支持50~36000DPI之间的设置 / The DPI can be set between 50 to 36000 DPI by software. / DPIは、ソフトウェアを介して50~36000 DPIの 間に設定することができる / DPI는 소프트웨어를 통해 50에서 36000 DPI 사이를 설정할 수

있습니다

04 回报率设置 / Polling Rate Set / ポーリングレート 設定 / 수익률 설정

可通过驱动直接修改回报率 / Set the rate by software / ソフトウェアを使用して速度 を設定します / 소프트웨어를 통해 속도를 설정합니다

05 电量状态指示 / Battery Indication / 電力量状態指示 / 전력 상태 표시

1) 指示灯红灯闪烁: 电量小于20%, 请充电 / Blinking In Red: 20% Battery, please charge / 赤色点滅: 20% バッテリ、充電してください / 빨간색 깜박임: 20% 배터리 충전 2) 指示灯黄灯闪烁: 充电中 / Blinking In Yellow: Charging / 黄色点滅: 充電 /

노란색 깜박임: 충전

3) 指示灯常亮: 充电完成,恢复至绿色 / Staying in Green: Charging completed /

緑のまま:充電完了 /녹색 유지: 충전 완료

FCC Warning Statement
Changes or modifications not expressly approved by the party responsible for compliance could void the
user's authority to operate the equipment. This equipment has been tested and found to comply with the
limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to
provide reasonable protection against harmful interference in a residential installation. This equipment
generates uses and can radiate radio frequency energy and, if not installed and used in accordance with
guarantee that interference will not ocur in a particular installation. If this equipment does cause harmful
interference to radio or television reception, which can be determined by turning the equipment off and
on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Recrient or relocate the receiving antenna.

- Increase the senaration between the equipment and receiver.

-- Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is

-- Consult the dealer or an experienced radio/TV technician for help

펙号: ATK Z1 PRO MAX

制造商: 深圳意义之塔科技有限公司 地址:深圳市南山区粤海街道高新区社区高新南七道138号惠恒大楼-期4楼4219

(1) This device may not cause harmful interference. and

FCC RF Radiation Exposure Statement

❷ 驱动下载

Software Download

소프트웨어 다운로드

WWW. ATK. PRO

ソフトウェアのダウンロード

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(2) this device must accept any interference received, including interference that may cause undesired

This equipment should be installed and operated with minimum distance 5mm between the radiator and your body

るので、コードを読み取って最新の説明書を見ることができます/ 제품이 끊임없이 업그레이

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter 2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment

드되기 때문에 코드를 스캔해서 최신 설명서를 볼 수 있다







