

- Function description: 1. Long press the power button for 2 seconds, the product is in standby state, and the

- In tong press the power dution to 2 sections, the product is instandly state, and the indicator light is steady on;

  2. In the standby mode, click the vibration button to switch one frequency each time, and the frequency mode is 3+7 mode.

  Press and hold the power button for 2 seconds to turn off the product;

  3. When charging, the light flashes, full of long bright;

  4. When used, magnetic metal is attached to the outside of the underwear to hold the product in place. product in place.

# 三、设备操控

设备,开启手机蓝牙,点击"我的设备"的图标;开启您的畅玩之旅,五种模式等你来玩。

\*注意:互动模式必须先添加对方好友,通过后方可互动。

\* Note: The interactive mode must be added to each other's friends before you can











旋转,伸缩,加热,放电,震动等等功能。 up to 18 frequencies Spin, stretch, heat, discharge vibrate And so on.



划动模式:中间位置震动力度最小,越边缘位置震动力度越大可以保存您刚才划动的节奏。 Stroke mode: The middle 可以根据手机播放的音乐来震动。 It vibrates according to the music playing on the phone. Small, the more the edge of

### 晃动模式 Sloshing mode



Shake your phone

晃动手机玩具根据您换的的幅度来震 动,幅度越大震动的越有力 Shake the mobile phone toy according to the amplitude of your change to shake, the larger the amplitude of the vibration more powerful

### 远程互动模式 Remote interaction mode

Click this icon if there is no connection device

Invite each other video

操控对方设备



注意:远程互动需先在APP里面添加成好 5.7。 5.7能互动时候是有玩具的这方要请 方来控制自己的设备 Note: Remote interaction needs to be

added as a friend in the APP before interaction. When the party with toys needs to ask the other party to control their devices

他在上海,她在北京。可以边视频,边聊天,边控制设备。 He is in Shanghai and she is in Beijling. You can video, chat, and control the device

Please clean the product thoroughly before and after each use. Before cleaningKeep the product in the shutdown state and the product is in the closed state with clean waterRinse the main part with the deodorization soap, and then rinse with clean water Wash, and wipe dry with a towel. Do not use alcohol, petroleum based solvents orClean with acetone cleaner. Please store the product in a cool, clean and cool conditionin the air and dry place, ensure the products avoid high temperature, heavy pressure and humidity. If the product is outThe current situation of automatic shutdown may be caused by insufficient power, and start self protectionPlease charge the protection mode in time.

As a close partner of users, it is the common responsibility of users and us to use this massager safely and healthily. Now remind the majority of users: This product is only suitable for adults aged 18 years old, please keep away from children. Do not use too much force during use, please pay attention to avoid injury. Do not mix this product with others. If you are not comfortable during use, please stop the product immediately. The product must be inspected regularly for damage and the use shall be stopped immediately if any damage is found. After the product is abandoned, it shall be disposed and recycled to the corresponding recycling station of the waste electrical and electronic products according to the disposal of the waste electrical and electronic products.



[感谢您使用本产品,请在使用前认真阅读本册!] Thank You For Using This Product. Please Read This Book Carefully Before Using It!

## 规格参数/Specifications

产品名称:魔法穿戴 功能使用:遥控/小程序/APP 震动模式:10种震动 材质:硅胶 额定电流:230mA 供电方式:磁吸充电 电池容量:90mAh 额定电压:3.7V 最大噪音:≤50db 防水效能:IPX6 产品尺寸:79\*30\*24mm 充电时间:1-2H 使用时长:≦45min APP款配件说明·魔法空戴一个, 磁吸金属件一个, 说明书一份, 充由线一条。 小程序款配件说明:魔法穿戴一个,磁吸金属件一个,说明书一份,充电线一条。

Product name: SEX TOY

Function use: remote control/small program /APP Vibration mode: 10 kinds of vibration Material: Silicone Rated current: 230mA

Rated current: 230mA
Power supply: magnetic charging
Battery capacity: 90mAh
Rated voltage: 3.7V
Waterproof performance: IPX6
Maximum noise: ≤50db
Product size: 79\*30\*24mm

APP accessories description: a sex toy, a magnetic metal, a manual, a charging cable. Small sequence accessories description: spice goods, magnetic suction metal one, manua one, charge line one.

## 一、下载及安装APP

使用前请前往苹果 苹果商店搜索"LoveSpouse"

Please go to Apple Apple Store to search for "LoveSpouse" before us 使用前请安卓

谷歌商店搜索"LoveSpouse"

Please search Android Google Store for "LoveSpousei" before use

3:打开APP;

4:注册账号;

5:进入操作页面;

6:设备绑定(如图所示);

即为产品已连接APP。

APP connection step description;
1: Product boot;
2: Mobile phone to turn on Bluetooth;
3: Open the APP;
4: Registered account number;
5: Enter the operation page;
6: Device binding(as photo);
7: The product flashes once when it is

(二、设备绑定) APP连接步骤说明: 1:产品开机; 2:手机打开蓝牙;









扫描二维码下载

Add device | Binding code | My equipment (國1) 自从至加口商环华区域,照一 (國1) 出现扫描框,扫描外包装盒或说明书上的设备识别码,如果扫描不 达为可以手动输入识别码下面数字扫描成功后 注:产品型号不同,识别码是不一样的。这个二维码只是个例子

(Figure 1) After the first login, bind the device and click "+"

\* Note: The identification code is different for different product models. This QR code is just an example

## (使用注意)

每次使用本产品前后,请将其进行彻底清洗。清洗前确保产品处于关机状 态,并且产品处于闭合状态用清水和除菌香皂漂洗主体部分后,再用干净 的清水进行冲洗,最后用毛巾擦拭干。请勿用含酒精、石油基溶剂或丙酮 的清洁剂进行清洗。请将本产品贮藏于凉爽、通风、干燥处,保证产品避免 高温、重压、潮湿。若产品出现自动关机的情况。可能是电量不足导致。启动 自我保护模式,请及时充电。

## 安全事宜

作為廣大用戶親密的伴侶.能夠安全健康的使用此按摩器是用戶和我們共 同的責任。現提醒廣大用戶:本品僅適合年滿18歲成年人使用,請遠離兒童 放置。使用過程中,請勿過度用力,請留意避免受傷,請勿與他人混用本產品 使用過程由如有不適 請立即停用太品, 須定期檢查產品是否指懷 發租捐 壞應立即停止使用。本產品廢棄後,應按廢舊電器電子產品處理,回收至相 應的廢舊電器電子產品回收站。



# FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.