



使用说明书 操作の説明 Operating instructions

使用产品前请阅读产品说明书一内含保修卡，图片仅供参考
製品をご使用になる前に、保証書を封入した製品説明書をお読みください
Before using the product, please read the product manual, which includes a warranty card.
The pictures are for reference only

一、产品参数

产品结构:



1.指示灯 2.充电口 3.触摸位置 4.音频输出 5.充电触点

产品参数

无线版本:V5.3	输入电压电流:5V1A~2A
无障碍距离:>10M	阻抗:32Ω
耳机电池容量:35mAh	产品颜色:黑色、云岩白
仓电池容量:400mAh	数据线:Type-c
音乐时间:约6小时	
充电时间约1.5小时	
佩戴方式:耳挂式	

02

二、产品操作



1、耳机取下后自动开机，且伴有语音提示 Power on 白灯冰蓝交替闪烁，在开机状态，自动进入配对状态
2、打开手机或相关设备，搜索“OWS-G05 点击连接使用”



3、正确佩戴使用

03

三、产品充电

充电状态:

- 耳机充电
将“Type-c”充电线插入充电接口中,耳机放入充电仓自动进入关机状态充电
状态时，白灯亮；满电状态灯灭。
- 电量低
在电压低电时，白灯闪3下，且伴有语音提示相隔60秒一次



TYPE-C充电口

4个电量指示灯，每颗表示25%电量

04

四、产品使用

功能	操作说明	提示
配对名称	OWS-G05	Tone
配对	手机蓝牙搜索“OWS-G05”点击连接	Tone
开机	充电仓开盖后耳机自动开机	Tone
关机	充电仓关闭上盖后耳机自动关机	Tone
播放/暂停	连接状态单击一下左耳或右耳触摸键区域	Tone
接电话	单击一下左耳或者右耳触摸区域进入通话模式	Tone
挂电话	通话状态下单击一下左耳或者右耳触摸区域	Tone
拒接电话	来电状态下长按 2s,左耳或者右耳触摸区域	Tone
上一曲	连击两下左耳触摸区域切换到上一曲	Tone
下一曲	连击两下右耳触摸区域切换到下一曲	Tone
音量加減	进入音乐播放模式时，长按左耳触摸键区域音量增加;长按右耳触摸键区域音量减小，伴有“嘟”语音提示	Tone
自动回连	连接过的设备，开机状态下自动回连	Tone
语音助手	三击左/右耳触摸区域，唤醒语音助手	Tone
中英文切换	两个耳机开机配对后点击其中一边耳机四	Tone
充电自动关机	下播放状态,休眠、待机,充电都会关机	Tone

05

五、充电说明

充电中数码管根据电量闪烁显示
给本产品充电时，请使用产品标配充电线，使用5V 1A的充电器。
注意事项:不要使用超过5V 1A的快充充电器，以免对充电造成损伤。

部件名称	有害物质					
	铅 (pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多联苯 (PBB)	多溴二苯醚 (PBDE)
插针	×	0	0	0	0	0
喇叭连	×	0	0	0	0	0
外壳组装	0	0	0	0	0	0
金属/塑料	0	0	0	0	0	0
其他部件	0	0	0	0	0	0

06

本表格依据GB/T 26572-2011的规定编制
0:表示该有害物质至少在该部件所有均匀材质中的含量均GB/T26572-2011规定限量要求以下
x:表示该有害物质至少在该部件的某一均与材料中含量超出GB/T26572-20115规定的限量要求
注意事项:本产品有X的原因是:现阶段没有可提供选择代替技术或者配件。

六、产品保修卡

用户资料			
产品型号			
产品编号			
购买日期			
顾客姓名			

保修记录			
保修日期	故障及处理方法	完成日期	顾客签名

保修条款
一、用户购机时，随机带有说明书及保修卡。用户填好后妥善保管，以做保修凭证。
二、自购机之日起，一年内本产品在日常使用情况下出现质量问题，用户持保修卡享受免费维修服务。
三、以下不属于维修范围内:
*保修卡无销售单位签字或盖章:
*人为或不可抗拒因素造成损坏
*机器正常磨损;
四、如因人为，超过保修期机不可抗拒因素造成的故障，我们将收取适当零件费用，免收人工费用。

07



08

Product parameter

Product structure:




1.Indicator light 2. Charging port 3. Touch the location 4. Audio output 5. Charging contact

Product parameter

Wireless version :V5.3	Input voltage current:5V1A~2A
Barrier free distance :>10M	Impedance :32Ω
Headphone battery capacity :35mAh	Product color:Black, dolomite white
Warehouse battery capacity :400mAh	Data cable :Type-c
Music time: about 6 hours	
Charge time is about 1.5 hours	
How to wear: Earhook type	

02

product operation



1. The headset will be turned on automatically after it is taken off, and the Power on white light will flash ice-blue alternately with a voice prompt. When it is turned on, it will automatically enter the pairing state
2. Open the mobile phone or related device and search for "OWS-G05 click and connect to use".



3. Wear and use correctly

03

Product charging

Charging state:
1. Charge your headphones
Insert the "Type-c" charging cable into the charging port. When the earphone is put into the charging bin and automatically enters the shutdown state, the white light will be on. The indicator in full power state is off.
2. The battery is low
When the voltage is low, the white light flashes for 3 times, and the voice prompt signals once every 60 seconds



Charge indicator light

Four power indicators, each indicating 25% power

04

Product use

function	Operating instruction	prompt
Pairing name	" OWS-G05 "	Tone
pairing	Mobile phone Bluetooth search "ows-g05" and click Connect	Tone
Turn on	After opening the charging compartment cover, the headphones will automatically turn on	Tone
Shut down	The earphones automatically turn off when the charging compartment lid is closed	Tone
Play/pause	Connection Status Click the left or right ear touch key area	Tone
Answer the phone	Click on the left or right ear touch area to enter talk mode	Tone
Hang up	During a call, click the left or right earphone touch area	Tone
Reject a call	In the incoming call state, press and hold for 2s to touch the left earphone or right earphone	Tone
Previous song	Double click on the touch area of the left earphone to switch to the previous song	Tone
Next song	Double tap the right earphone touch area to switch to the next song	Tone
Volume increase and decrease	When entering the music playing mode, long press the left earphone touch button area to increase the volume; Long press the touch button area of the right earphone. The volume decreases and a beep sound is displayed	Tone
Automatic link back	The connected device automatically connects back when the device is started	Tone
Voice assistant	Three strokes left/right earphone touch area to wake up the language assistant	Tone
Switch between English and Japanese	After the two earphones are powered on and paired, click on one side earphone four	Tone
Charging automatic shutdown	Play state, hibernate, standby, charging will shut down	Tone

05

製品パラメータです

製品構成です:



1.ランプです 2.充電口です 3.位置をタッチします 4.音声出力です 5.充電触点です

製品パラメータです

無線バージョン:V5.3です	入力電圧電流:5V1A~2Aです。
バリアフリー距離:>10Mです	インピーダンス:32オメガ
バッテリー容量は35mAhです	製品カラー: 黒、雲岩白
バッテリー容量は400mAhです	ケーブル:type-cです。
音楽時間:約6時間です	
充電時間は約1.5時間です	
装着方法: 耳掛け式	

02

製品の操作です



1. イヤホンを取った後、自動的に電源を入れます。Power on という音声メッセージを待っています。白いランプが青いランプが交互に点滅します。電源を入れた状態は、自動的にペアリング状態になります
2. スマートフォンや関連機器を開き、「OWS-G05 リックで接続して使用」と検索します



3. 正しくつけて使うことです

03

製品の充電です

充電状態です
1.イヤホンの充電です
「type-c」充電ケーブルを充電ポートに差し込み、イヤホンを充電ボックスに入れて自動的に電源オフ状態になると、ホワイトランプが点灯します。満充電状態ではランプが点灯します。
2.電力量が少ないです
電圧が低い時、白色灯は3回点滅して、音声案内を伴って60秒に1回知らせます



充電ランプです

4つのランプがありそれぞれ25%の電力を示しています

04

製品の使用です

機能です	操作説明書です	ヒントです
ペア名です	"OWS-G05"	Toneです
ペアリングです	携帯電話のBluetooth検索「ows-g05」をクリックして接続します	Toneです
電源を入れます	充電器が蓋を開けるとイヤホンが自動的に起動する	Toneです
シャットダウン	充電器が蓋を開るとイヤホンが自動的にオフになる	Toneです
再生/一時停止です	接続状態左耳または右耳のタッチキー領域をクリックします	Toneです
電話に出る	通話モードになります左耳または右耳のタッチエリアをクリックします	Toneです
電話を切りめます	通話中にイヤホンまたは右イヤホンのタッチエリアをクリックします	Toneです
電話を拒否します	着信の状態を2sを長押し。左または右のイヤホンタッチエリアです	Toneです
前の曲です	左イヤホンのタッチエリアをダブルクリックして前の曲に切り替えます	Toneです
次の曲です	右のイヤホンタッチを2回連打して次の曲に切り替えます	Toneです
ボリューム加減	音楽に入ってからモードを再生します。長押しして左のイヤホンはキー領域をタッチして音量が増加します音量は小さくなって。右のイヤホンをタッチして長押しボタン領域、「を待って」音声のヒントを知らせてみます	Toneです
自動連動です	接続した機器は、電源を入れた状態で自動的に戻ります	Toneです
音声アシスタントです	左/右のイヤホンタッチ領域を3回クリックして、言語アシスタントを起動します	Toneです
中英語日本語切り替え	2つのイヤホンの電源を入れてペアリングしたら片方をクリックします4	Toneです
充電するとオフになります	ダウ再生、スリープ、スタンバイ、充電が停止します	Toneです

05

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.