

Veggo A Love-Infused Hand Warmer: Personalized Just for You, Your Cozy Companion

- Please be sure to use and store the product in accordance with the 'User Manual' regulations. Please read the 'User Manual' carefully and keep it for reference. If you have any questions during use, you can contact the VIBIS team through the purchasing channel.
- Precautions
 - If the product is damaged, stop using it immediately. Do not touch any internal components to avoid electric shock;
 - Do not store this product in unconventional environments.
 - Avoid using this product in areas of the body sensitive to heat. The heat generated by this product has been tested by VIBIS Laboratories and is within the safe temperature range for the human body. However, individual sensitivity to heat may vary. Avoid using the product on areas of the body that are sensitive to heat to prevent burns or other adverse effects.
 - Use the original wireless charging base for Veggo to charge it whenever possible. Avoid using other wireless chargers that may cause charging issues due to insufficient power.
 - Different areas of the body may have different levels of sensitivity to temperature. Adjust the settings gradually (based on your own usage and skin tolerance), starting from the 'Low' setting.
 - Keep this product out of the reach of children.
 - Individuals with physical disabilities, mental disorders, or a lack of relevant experience and knowledge (including children) must use and store this product under the supervision and guidance of a guardian.
 - Regularly clean the outer surface of the product with a dry/wet cloth or tissue to prevent dirt from affecting the product's contact sensitivity and to avoid poor contact on the wireless charging area due to dirt.
 - Keep this product and the corresponding power adapter in a dry condition.
 - If your skin becomes slightly warm and red after use, this is a normal reaction due to the product's heating.
 - The recommended operating environment temperature for this hand warmer is between -20° C and 50° C.

- Do not use this product near flammable or explosive materials (including sprayers, gas stations, etc.), as it may cause a fire or other hazards.
- If the product does not work after turning on the power, stop using it immediately. Check for the cause of the problem on this manual or contact the VIBIS team through the original purchase channel for assistance.
- When using the Veggo wireless charging base to charge devices like phones and headphones, ensure that the device supports wireless charging and has not been affected by external factors (including but not limited to moisture or dust issues).
- Product Introduction
 - Veggo is a wireless charging hand warmer with 3-level temperature adjustment. It is primarily designed to provide warmth to the body in cold environments and can also offer a degree of therapeutic heating.
 - The Veggo comes with a wireless charging base that supports wireless charging for devices such as smartphones and headphones, with a maximum output power of 20W.
 - You can adjust the temperature level (L/M/H) according to the specific body area's heating needs.
 - Veggo hand warmers are designed for home, office, and personal portable use. Product testing results align with the VIBIS team's expectations for Veggo, combining the functionality of a hand warmer with portability, wireless charging, and a multi-functional charging base.

Veggo Hand Warmer Specifications:	
Brand	Vibis
Product	Veggo Hand Warmer
Model	VBVE0001
Dimensions	80*68*28mm
Colors	Cosmic Grey、 Neon Green、 Viva Magenta、 Barbie Pink、 Navy Blue、 Champagne Gold
Materials	Aluminum Alloy, ABS, PC
Weight	94g

Battery Capacity	2000mAh
Charging Time	3 hours

Veggo Wireless Charging Dock Specifications:	
Brand	Vibis
Product	Veggo Wireless Charging Dock
Model	VBHLT0001
Dimensions	169*88*16mm
Colors	Wood Grain&Black
Materials	ABS
Weight	210g
Output Power	15W

- Product Structure:

Heating Area

1. Wireless Charging Receiver
2. Touch Button
 - (1) Long press for 2 seconds to power on/off.
 - (2) Double-tap to switch between modes (L Mode: 45° C, M Mode: 55° C, H Mode: 65° C).
 - (3) Short press while powered on to view the current battery level and mode.
3. LED Display Screen (Left side displays remaining battery, Right side shows L/M/H for temperature modes).

Wireless Charging

1. Wireless Charging Transmitter (15W, for charging Vibis Hand Warmer).
2. Wireless Charging Indicator Light (Red breathing pattern - Charging, Solid green - Fully charged).

Wireless Charging

1. TYPE-C Charging Port (For connecting to the TYPE-C charging port and other TYPE-C connectors on the base).
2. TYPE-C Charging Plug (Foldable for storage, used for connecting between multiple bases).

FCC Radiation Exposure Statement

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure