













尺寸: 90X90mm
材质: 80克双胶纸, 双面印刷 折页效果

MCHOSE 鼠标  — G3 用户指南 — 无线鼠标	 Type-C 接口 无线1 指示灯 无线2 指示灯 模式切换键 (带指示灯) 电源开关 ON 指示灯 OFF 指示灯 USB 接收器 (置于盖子内部) 温馨提示: 本说明书中的图片均为示意图, 可能与实物有偏差, 请以实物为准。	2.4G 连接  无线连接  无线连接方式与无线1相同, 可以通过短按【模式切换键】切换模式。无线1、2 的配对名称均为【G3 Mouse】。 清除配对记录 在无线模式下, 短【模式切换键】、【滚轮键】, 长按3秒清除配对记录。鼠标充满1、无线2指示灯闪烁表示清除成功。可在无线模式下重新进行连接。 在无线1、无线2模式下, 长按【模式切换键】、【滚轮键】已连接的设备, 则再次连接该设备, 会自动再次连接设备。	有线连接  有线连接  有线连接: 单击【DPI切换键】可循环切换为高、中、低三档。 DPI DPI档位: 单击【DPI切换键】可循环切换为高、中、低三档。 指示灯: 第一档DPI指示灯亮, 第二档DPI指示灯亮, 第三档DPI指示灯亮, 第四档DPI指示灯亮, 第五档DPI指示灯亮, 第六档DPI指示灯亮。	省电模式 鼠标关闭电源下, 5秒钟进入省电模式, 每30秒可唤醒, 15秒钟进入休眠模式, 点击按键可唤醒。 充电  当【指示灯】红色闪烁时, 请及时给鼠标充电。通过充电器的USB接口与电脑连接, 即可为鼠标充电。充电过程中【指示灯】红灯常亮, 充满时熄灭。 充电说明 1. 建议连接使用USB Type-C 接口显示器进行充电; 2. 首次使用时请先充电至电量满后再使用; 3. 请勿使用劣质或非标准电源适配器进行充电; 4. 请勿使用非原装USB数据线进行充电; 5. 充电时请勿使用鼠标或充电接口; 6. 长时间不使用时应将鼠标充电接口盖好。 充电说明: 请勿将鼠标充电接口与充电设备(充电器/数据线/USB线)连接。	规格参数 型号: G3 充电电流: 0.35A/0.5A 充电电压: 5V/5.2V 充电接口: Type-C 注意: 本设备经过测试, 符合 FCC 法规第 15 部分对 B 类数字设备的限制。这些限制旨在提供合理的保护, 防止有害干扰住宅安装。该设备产生、使用并可以辐射无线电频率能量, 如果不符合限制可能会妨碍使用。可能会对无线电通信造成有害干扰。但是不能保证在特定安装中不会发生干扰。如果该设备确实对无线电通信造成有害干扰, 您可以通过关闭打开设备电源来解决问题。我们鼓励用户尝试通过以下一些或多项措施来纠正干扰。 • 重新调整或重新校准天线。 • 将设备连接到接地线和接地电路不同的电路插座上。 • 请向当地经销商或生产商/服务提供商/技术人员寻求帮助。 • 本设备符合 FCC 法规第 15 部分对 B 类数字设备的限制, 但不能保证在特定安装中不会发生干扰。 • 本设备符合 FCC 法规第 15 部分对 B 类数字设备的限制, 但不能保证在特定安装中不会发生干扰。 (2) 该设备必须接受接收的任何干扰, 包括可能导致不能操作性的干扰。	保修卡 尊敬的顾客: 感谢您购买本公司产品。在保修期内如果产品出现任何质量问题, 请联系我们。我们将为您提供此保修卡, 以便我们为为您提供完善的售后服务。 产品型号: _____ 用户姓名: _____ 出厂编号: _____ 保修地址: _____ 购买日期: _____ 保修联系人: _____ 购买地址: _____ 联系电话: _____ 销售员: _____ 邮箱: _____ 执行标准: GB4943.1-2022
MCHOSE  — G3 USER MANUAL — WIRELESS MOUSE	 Type-C interface Wireless indicator light Wireless indicator light Mode switching key (Press press to match code) Power switch ON indicator OFF switch key USB receiver (Place inside the lid) Warm reminder: The pictures in this manual are schematic diagrams and may differ from the actual objects. Please refer to the actual objects.	2.4G CONNECTION  WIRELESS CONNECTIONS  The connection method of Wireless 2 is the same as that of Wireless 1. You can switch modes by short pressing the Mode Switch Key. The pairing names of Wireless 1 and Wireless 2 are both: 【G3 Mouse】. CLEAR PAIRING RECORD In wireless mode, use the Mode Switch button + Mouse Wheel and press & hold for 3 seconds to clear up the matched record. The Wireless1 and Wireless2 indicators will flash for 5 seconds to indicate successful clearing. You can connect two devices in wireless mode. Impressions: The Mode Switch button + Mouse Wheel mode to disconnect the connected device. If there is no new device connected, after switching to the different channel, the disconnected device will be automatically reconnected.	WIRED CONNECTION  有线连接  有线连接: 单击【DPI切换键】可循环切换为高、中、低三档。 DPI DPI档位: 单击【DPI切换键】可循环切换为高、中、低三档。 指示灯: 第一档DPI指示灯亮, 第二档DPI指示灯亮, 第三档DPI指示灯亮, 第四档DPI指示灯亮, 第五档DPI指示灯亮, 第六档DPI指示灯亮。	POWER SAVING MODE The mouse will go to first level Auto-Sleep mode after 5 minutes of sitting idle and go to second level Auto-Sleep mode after 15 minutes of sitting idle. Press any button to wake it up. CHARGE  When the Indicator Light flashes red, please charge the mouse in time. Connect the mouse to the computer through the standard USB cable to charge the mouse. During the charging process, the Indicator Light will flash red, not be green when fully charged. CHARGING INSTRUCTIONS 1. It is recommended to only use the computer USB interface to charge the mouse. 2. Do not use a third charging cable adapter to charge the mouse. 3. Do not use after non-standard power adapter to charge the mouse. 4. Do not use an overcharge and overcurrent power adapter to charge the mouse. 5. Please stop using from high-temperature equipment when charging. 6. Please turn off the power switch when not in use for a long time. The device charging instructions also apply to other devices with charging functions. Please refer to the user manual for more details.	SPECIFICATIONS Model: G3 Charging current: 0.35A/0.5A Charging voltage: 5V/5.2V Charging interface: Type-C NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. Therefore, it is designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.	WARRANTY CARD Thanks for your purchase. Please contact us if you have any quality issue with the product during the warranty period. Please provide this warranty card so that we can serve you better. Model: _____ Username: _____ Serial number: _____ Warranty address: _____ Purchase date: _____ Warranty contact: _____ purchase address: _____ contact number: _____ seller: _____ 执行标准: GB4943.1-2022