

TROUBLESHOOTING

If there are any problems, please try to solve them in the following ways .

Problem or breakdown	Solution
Non atomization	1. Check if the power is on; 2. Check if the time period is set during the non-working period; 3. Check if the air pump is working; 4. Check if the air intake seal is leaking or if the seal is broken; 5. The suction pipe is blocked or detached;
Small atomization	1. Check if the intake seal is broken and the suction pipe is blocked; 2. Check if the atomization system and the essential oil bottle seal are damaged or fall off;
Oil leakage	1. Check whether the atomization system is damaged ; 2. Check whether the sealing rings of atomization system and essential oil bottles are damaged or fall off ; 3. Check whether the essential oil bottle is tightened ;
Abnormal noise	1. Check whether the air pump is loose or not, and re-fix the air pump; 2. Check whether the air pump is damaged, replace the new air pump ;

EQUIPMENT MAINTENANCE

In order to ensure the best aroma effect, please check and maintain the equipment regularly, as follows:


1. Open the device remove the used essential oil bottle;
2. Pour proper amount of alcohol into the essential oil bottle and clean it;
3. After cleaning, pour in a small amount of alcohol, install the essential oil bottle on the equipment, turn on the equipment and work for 5 to 10 minutes;
4. Turn off the power after cleaning the equipment;
5. Take out the essential oil bottle, put in the essential oil, install it on the equipment.

AFTER SALES SERVICE


The equipment is sold within one year from the date of sale. Providing paid maintenance beyond the warranty period. The following man-made or accidental damage is not covered by the warranty:

1. Use a power adapter that is not equipped with this device or an insecure power supply socket to cause the device to be short-circuited;
2. Do not attempt to disassemble the device, otherwise it is deemed to automatically give up the warranty;
3. It is not used in accordance with the specifications correctly, the equipment is damaged by the leakage of essential oil after the water is injected and the essential oil is inverted.
4. If you encounter any after-sales problems, you can contact the authorized sales service providers in each region or contact our sales center.


PRODUCT INSTRUCTIONS



INSTALLATION INSTRUCTIONS




1. Insert the key first , turn90 degrees counterclockwise to unlock.
2. Pull up the atomizer.
3. Turn counterclockwise to unscrew the essential oil bottle and add essential oil.




1. Drill positioning holes in the wall at appropriate locations and fix the hanging board with screws.
2. After inserting it into the notch on the back of the chassis ,lock the screw at the bottom.


ACCESSORIES:




Power Adapter



PE Trachea



Quick Connector



Key *2




Plastic Wall Plug *3



Self-tapping Screws *3

⚠ NOTES

1. Please place the device on the flat position, do not tilt it.
2. Do not mix water into the essential oil.
3. Please operate and maintain the device refer to the instruction. Do not dismantle or modify the device.
4. Please use alcoholic solution to wash the bottle and atomize core when the device has not been used for a long time.
5. Please wash atomize core with alcoholic solution when the device operate for 2 months.



APP OPERATION AND SETTINGS

I. Download and install the APP

Please enter the Apple Store, Google App Market, Android App Market and enter SCENT ONLINE to download the control APP.

Download APP "SCENT ONLINE" to remote control, set working time scent concentration, ect.




II. Connection operation

Note: 1. Before operation, please connect the mobile phone to WIFI and turn on the mobile phone Bluetooth.
2. After opening the APP, register an account and log in, please agree to the location and network permissions of the APP, otherwise the fragrance device may not be successfully bound


1. Click Add device




2. Select the device




3. Enter WiFi password, case sensitive




4. Bind network progress




5. The binding is successful and you can also group your devices



6. Operation interface, Tap the clock icon to adjust the device




7. Support 7-segment timing 20-level fragrance concentration




III. Device sharing (three ways)


1. Members added, Click My - Family Management - My Home - Add Members



2. Device ID sharing added Model Device Settings - Device Details - Copy ID



3. QR code sharing, Click My Device Sharing - Select Model



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.