



802.11ax-HE80 - Ant 2

Channel 7 (5985MHz)

The Reference Level




The Mask Data




Channel 55 (6225MHz)

The Reference Level




The Mask Data




Channel 87 (6385MHz)

The Reference Level




The Mask Data




802.11ax-HE80 - Ant 2

Channel 135 (6625MHz)

The Reference Level




The Mask Data




Channel 151 (6705MHz)

The Reference Level




The Mask Data




Channel 167 (6785MHz)

The Reference Level




The Mask Data




802.11ax-HE160 - Ant 2

Channel 15 (6025MHz)

The Reference Level



The Mask Data




Channel 47 (6185MHz)

The Reference Level




The Mask Data




Channel 79 (6345MHz)

The Reference Level




The Mask Data




802.11ax-HE160 - Ant 2

Channel 143 (6665MHz)

The Reference Level



The Mask Data



802.11be-EHT20 - Ant 2

Channel 1 (5955MHz)

The Reference Level




The Mask Data




Channel 49 (6195MHz)

The Reference Level




The Mask Data




Channel 93 (6415MHz)

The Reference Level




The Mask Data




802.11be-EHT20 - Ant 2

Channel 129 (6595MHz)

The Reference Level




The Mask Data




Channel 157 (6735MHz)

The Reference Level




The Mask Data




Channel 181 (6855MHz)

The Reference Level




The Mask Data




802.11be-EHT40 - Ant 2

Channel 3 (5965MHz)

The Reference Level




The Mask Data




Channel 51 (6205MHz)

The Reference Level




The Mask Data




Channel 91 (6405MHz)

The Reference Level




The Mask Data




802.11be-EHT40 - Ant 2

Channel 131 (6605MHz)

The Reference Level




The Mask Data




Channel 155 (6725MHz)

The Reference Level




The Mask Data




Channel 179 (6845MHz)

The Reference Level




The Mask Data




802.11be-EHT80 - Ant 2

Channel 7 (5985MHz)

The Reference Level




The Mask Data




Channel 55 (6225MHz)

The Reference Level




The Mask Data




Channel 87 (6385MHz)

The Reference Level




The Mask Data




802.11be-EHT80 - Ant 2

Channel 135 (6625MHz)

The Reference Level




The Mask Data




Channel 151 (6705MHz)

The Reference Level




The Mask Data




Channel 167 (6785MHz)

The Reference Level



The Mask Data




802.11be-EHT160 - Ant 2

Channel 15 (6025MHz)

The Reference Level




The Mask Data




Channel 47 (6185MHz)

The Reference Level




The Mask Data




Channel 79 (6345MHz)

The Reference Level




The Mask Data




802.11be-EHT160 - Ant 2

Channel 143 (6665MHz)

The Reference Level




The Mask Data




802.11be-EHT320 - Ant 2

Channel 31 (6105MHz)

The Reference Level




The Mask Data



Channel 63 (6265MHz)

The Reference Level



The Mask Data

