

Operation instructions

To customers

Thank you for your trust in our company and congratulations on having our high-tech products. This product is original, novel and fashionable in the shape and can bring you dynamic enjoyment with excellent sound quality. Please read this manual carefully before operating. If you have any question, please contact local franchiser or consult with our company directly. Please keep this manual carefully for future reference.

PS: the function with "*" in this manual represent the optional functions.

Safety warning

The machine uses AC 220V whose safety range is 110V-240V,

The power cord cannot be squeezed, bent, knotted or hang heavy objects to prevent the insulation layer of the power cord from being damaged to cause electrical shock.

Do not make the machine get wet. It is strictly forbidden to place liquids and combustibles around the machine to prevent electric shock, fire, explosion and other hazards.

Do not block the hole near the switch of the rear panel to avoid poor heat dissipation which would influence the service life of the machine.

If the machine suddenly smokes or other abnormal phenomenon appears, please quickly pull off the power plug to avoid accidents, and contact local franchiser for maintenance as soon as possible.

If this machine is not used for a long time, please pull off the power plug to avoid being burned down by lightning strike.

Main technical parameters


MODEL	Q7S		
POWER	70W		
SIZE	270*140*200mm		
WEIGHT	3.5kg		
SPEAKER	5.25inch*1+2inch*4		
BATTERY	26650MAH*3		


Product List

Machine *1	Wireless Microphone *1	
The Power Adapter *1	Hand Belt *1	
Audio line *1	Remote Controller *1	

Operation Panel Description

Note: If the machine cannot be shut down normally, it can be forcibly shut down by inserting toothpicks into the restart hole.





Note: Press and hold the input to select audio mute, press and hold again to unmute, press and hold the previous song or the next song to adjust the headphone volume.



Remote Control Button Description



- 1. Mute
- 2. Mode change
- 3. Microphone volume increase
- 4. Microphone delayed change
- 5. Microphone Reverberation change
- 6. Microphone volume decrease
- 7. Music volume increase
- 8. Music bass increase
- 9. Music treble increase
- 10. Previous track
- 11. Pause/Play
- 12. Next track
- 13. Music bass decrease
- 14. Music treble decrease
- 15. Music volume decrease
- 16. Numeric kevs
- 17. Ingles or Cycles
- 18. Battery status

How to use the microphone

- 1. Turn on the machine and the microphone (install the microphone with battery)
- 2. Adjust microphone volume and reverberation to a suitable position
- 3. The TREBLE and BASS adjustment works on both the microphone and the music.
- 4.If the shape of battery on the screen flickers, it means low power.
- 5.Do not hold the microphone facing the speaker to avoid howling.
- PS: The capacitive microphone interface does not support 48V capacitive microphone.

How to use the Bluetooth

- 1. Once the machine is turned on, press the M key repeatedly until bL appears on the screen and flashes.
- 2. Enter the cell phone setting-Bluetooth, start the bluetooth scanning and find the device Q7S.
- 3. Click on Q7S and connect. When it is connected successfully, the bL mark on the screen will stop flickering and there is a tone.
- 4. Long press the PIAY/PAUSE key to disconnect the bluetooth.

How to connect the machine with other device with audio line

- 1.Turn on the machine and press the M key repeatedly until "line" appears on the screen.
- 2.Insert one end of the audio line into the "AUX"hole, and insert the other end into the audio output interface of other device(computer, mobile phone, etc.)

How to use the USB disk

- 1.Turn on the machine, insert the U disk card with copied songs into the USB interface of the speaker (pay attention to the orientation), and it will play automatically. The screen will show the playing time.
- 2.Press the PREVIOUS key or the NEXT key to switch songs or use the remote controller to choose songs.
- 3. Songs are sorted in the order of copying

Charging method

- 1.Press the power key on the remote controller to check the power. When the power is too low, there will be prompt tone and the volume will decrease.
- 2.Plug in the charger to charge the machine and the charging indicator light is on. When the machine is fully charged,the light is off.
- 3.If you do not use the machine for a long time, please charge the machine once 2-3 months to avoid battery damage.
- 4. When the power is exhausted, the machine will turn off automatically. It may need to be charged to activate under the shutdown status.
- 5.The machine can be charged when it is on or off. The volume cannot be too loud when it is on and charging ,or it will influence the service life of the machine.

Live broadcast/Recording

- 1.Connection Method: Insert one end of the OTG cable to the OTG interface of the machine, and the other end to the mobile phone or the computer.
- 2.OTG cable required for live broadcast must be purchased separately.
- 3. The USB disk cannot be used during OTG live broadcast.
- * Some version can be matched with the wireless sound card of our company to enhance the live broadcast function.

Warranty Card

Our company guarantees to our customers that the "Shengyou" brand product has complete parts and functions with anti-counterfeit sticker, and provides perfect after-sales service. From the date of purchase, you can enjoy "three-guarantee" policy (replace within one month, repair within three months and guarantee to repair within one year) with the invoice and warranty card.

The product cannot be repaired for free in the following cases:

- 1.If the product is damaged due to the user's storage, transportation or improper use (such as not operating according to the instruction manual), our company will not repair it for free.
- 2. This product is high-end speaker series. The maintenance should be sent to a professional warranty unit. Users should not dismantle and repair it without authorization, or the consequences will be borne by themselves.

User name	Tel.	
User address		
Product model	Machine No.	
Sales unit	Purchase date	
Remark		

Please keep the warranty card carefully.

This manual has been carefully checked to ensure its accuracy. If there is any printing error, our company will not bear the consequences.

In case of any design change, we reserve the right of final interpretation of the contents of this manual without further notice.

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

Note: The design specifications and features of thisproduct are subject to update without prior notice

Enterprise WeChat



Manufacturer: Shenzhen ShengYou Electric Appliance Co., Ltd

Service hotline: 4007777558 Email: 1123612932@qq.com

Company website: www.sen-yoo.com

Company Address: 6th Floor, Building A, No. 5001, Bao'an

Avenue, Shenzhen